



SIM7500_SIM7600 Series_ AT Command Manual

LTE Module

SIMCom Wireless Solutions Limited

Building B, SIM Technology Building, No.633, Jinzhong Road

Changning District, Shanghai P.R. China

Tel: 86-21-31575100

support@simcom.com

www.simcom.com

| | |
|------------------------|--|
| Document Title: | SIM7500_SIM7600 Series_AT Command Manual |
| Version: | 2.00 |
| Date: | 2020.8.6 |
| Status: | Released |

GENERAL NOTES

SIMCOM OFFERS THIS INFORMATION AS A SERVICE TO ITS CUSTOMERS, TO SUPPORT APPLICATION AND ENGINEERING EFFORTS THAT USE THE PRODUCTS DESIGNED BY SIMCOM. THE INFORMATION PROVIDED IS BASED UPON REQUIREMENTS SPECIFICALLY PROVIDED TO SIMCOM BY THE CUSTOMERS. SIMCOM HAS NOT UNDERTAKEN ANY INDEPENDENT SEARCH FOR ADDITIONAL RELEVANT INFORMATION, INCLUDING ANY INFORMATION THAT MAY BE IN THE CUSTOMER'S POSSESSION. FURTHERMORE, SYSTEM VALIDATION OF THIS PRODUCT DESIGNED BY SIMCOM WITHIN A LARGER ELECTRONIC SYSTEM REMAINS THE RESPONSIBILITY OF THE CUSTOMER OR THE CUSTOMER'S SYSTEM INTEGRATOR. ALL SPECIFICATIONS SUPPLIED HEREIN ARE SUBJECT TO CHANGE.

COPYRIGHT

THIS DOCUMENT CONTAINS PROPRIETARY TECHNICAL INFORMATION WHICH IS THE PROPERTY OF SIMCOM WIRELESS SOLUTIONS LIMITED COPYING, TO OTHERS AND USING THIS DOCUMENT, ARE FORBIDDEN WITHOUT EXPRESS AUTHORITY BY SIMCOM. OFFENDERS ARE LIABLE TO THE PAYMENT OF INDEMNIFICATIONS. ALL RIGHTS RESERVED BY SIMCOM IN THE PROPRIETARY TECHNICAL INFORMATION , INCLUDING BUT NOT LIMITED TO REGISTRATION GRANTING OF A PATENT , A UTILITY MODEL OR DESIGN. ALL SPECIFICATION SUPPLIED HEREIN ARE SUBJECT TO CHANGE WITHOUT NOTICE AT ANY TIME.

SIMCom Wireless Solutions Limited

Building B, SIM Technology Building, No.633 Jinzhong Road, Changning District, Shanghai P.R. China
Tel: +86 21 31575100
Email: simcom@simcom.com

For more information, please visit:

<https://www.simcom.com/download/list-863-en.html>

For technical support, or to report documentation errors, please visit:

<https://www.simcom.com/ask/> or email to: support@simcom.com

Copyright © 2020 SIMCom Wireless Solutions Limited All Rights Reserved.

Version History

| Version | Date | Chapter | What is new |
|---------|----------|---------|-------------|
| V2.00 | 2020.8.6 | | New version |

SIMCom
Confidential

Contents

| | |
|---|-----------|
| Version History | 3 |
| Contents | 4 |
| 1. Introduction | 16 |
| 1.1 Scope of the document..... | 16 |
| 1.2 Related documents..... | 16 |
| 1.3 Conventions and abbreviations..... | 16 |
| 1.4 AT Command syntax..... | 16 |
| 1.4.1 Basic syntax..... | 17 |
| 1.4.2 S Parameter syntax..... | 17 |
| 1.4.3 Extended Syntax..... | 17 |
| 1.4.4 Combining AT commands on the same Command line..... | 18 |
| 1.4.5 Entering successive AT commands on separate lines..... | 18 |
| 1.5 Supported character sets..... | 18 |
| 1.6 Flow control..... | 19 |
| 1.6.1 Software flow control (XON/XOFF flow control)..... | 19 |
| 1.6.2 Hardware flow control (RTS/CTS flow control)..... | 19 |
| 1.7 Definitions..... | 20 |
| 1.7.1 Parameter Saving Mode..... | 20 |
| 1.7.2 Max Response Time..... | 20 |
| 2. AT Commands According to V.25TER | 21 |
| 2.1 Overview of AT Commands According to V.25TER..... | 21 |
| 2.2 Detailed Description of AT Commands According to V.25TER..... | 22 |
| 2.2.1 A/ Re-issues the Last Command Given..... | 22 |
| 2.2.2 ATD Mobile Originated Call to Dial A Number..... | 22 |
| 2.2.3 ATD<mem><n> Originate call from specified memory..... | 24 |
| 2.2.4 ATD<n> Originate call from active memory(1)..... | 25 |
| 2.2.5 ATD<str> Originate call from active memory(2)..... | 26 |
| 2.2.6 ATA Call answer..... | 27 |
| 2.2.7 ATH Disconnect existing call..... | 28 |
| 2.2.8 ATSO Automatic answer incoming call..... | 28 |
| 2.2.9 +++ Switch from data mode to command mode..... | 29 |
| 2.2.10 ATO Switch from command mode to data mode..... | 30 |
| 2.2.11 ATI Display product identification information..... | 30 |
| 2.2.12 AT+IPR Set local baud rate temporarily..... | 31 |
| 2.2.13 AT+ICF Set control character framing..... | 32 |
| 2.2.14 AT+IFC Set local data flow control..... | 33 |
| 2.2.15 AT&C Set DCD function mode..... | 34 |
| 2.2.16 ATE Enable command echo..... | 35 |

| | | | |
|-----------|---|---|-----------|
| 2.2.17 | AT&V | Display current configuration..... | 35 |
| 2.2.18 | AT&D | Set DTR function mode..... | 36 |
| 2.2.19 | AT&S | Set DSR function mode..... | 37 |
| 2.2.20 | ATV | Set result code format mode..... | 37 |
| 2.2.21 | AT&F | Set all current parameters to manufacturer defaults..... | 38 |
| 2.2.22 | ATQ | Set Result Code Presentation Mode..... | 38 |
| 2.2.23 | ATX | Set CONNECT Result Code Format..... | 39 |
| 2.2.24 | ATV | Set CONNECT Result Code Format About Protocol..... | 40 |
| 2.2.25 | AT&E | Set CONNECT Result Code Format About Speed..... | 41 |
| 2.2.26 | AT&W | Save the user setting to ME..... | 41 |
| 2.2.27 | ATZ | Restore the user setting from ME..... | 42 |
| 2.2.28 | AT+CGMI | Request manufacturer identification..... | 42 |
| 2.2.29 | AT+CGMM | Request model identification..... | 43 |
| 2.2.30 | AT+CGMR | Request revision identification..... | 44 |
| 2.2.31 | AT+CGSN | Request product serial number identification..... | 44 |
| 2.2.32 | AT+CSCS | Select TE character set..... | 45 |
| 2.2.33 | AT+CIMI | Request international mobile subscriber identity..... | 46 |
| 2.2.34 | AT+CIMIM | Request another international mobile subscriber identity..... | 47 |
| 2.2.35 | AT+GCAP | Request overall capabilities..... | 47 |
| 3. | AT Commands for Status Control..... | | 49 |
| 3.1 | Overview of AT Commands for Status Control..... | | 49 |
| 3.2 | Detailed Description of AT Commands for Status Control..... | | 49 |
| 3.2.1 | AT+CFUN | Set phone functionality..... | 50 |
| 3.2.2 | AT+CPIN | Enter PIN..... | 51 |
| 3.2.3 | AT+CICCID | Read ICCID from SIM card..... | 52 |
| 3.2.4 | AT+CSIM | Generic SIM access..... | 53 |
| 3.2.5 | AT+CRSM | Restricted SIM access..... | 54 |
| 3.2.6 | AT+SPIC | Times remain to input SIM PIN/PUK..... | 59 |
| 3.2.7 | AT+CSPN | Get service provider name from SIM..... | 59 |
| 3.2.8 | AT+CSQ | Query signal quality..... | 60 |
| 3.2.9 | AT+AUTOCSQ | Set CSQ report..... | 62 |
| 3.2.10 | AT+CSQDELTA | Set RSSI delta change threshold..... | 63 |
| 3.2.11 | AT+CATR | Configure URC destination interface..... | 64 |
| 3.2.12 | AT+CPOF | Power down the module..... | 65 |
| 3.2.13 | AT+CRESET | Reset the module..... | 65 |
| 3.2.14 | AT+CACM | Accumulated call meter..... | 66 |
| 3.2.15 | AT+CAMM | Accumulated call meter maximum..... | 67 |
| 3.2.16 | AT+CPUC | Price per unit and currency table..... | 68 |
| 3.2.17 | AT+CCLK | Real time clock management..... | 70 |
| 3.2.18 | AT+CMEE | Report mobile equipment error..... | 71 |
| 3.2.19 | AT+CPAS | Phone activity status..... | 72 |
| 3.2.20 | AT+SIMEI | Set IMEI for the module..... | 73 |
| 3.2.21 | AT+SMEID | Request Mobile Equipment Identifier..... | 74 |
| 3.2.22 | AT+CSVM | Voice Mail Subscriber number..... | 75 |
| 3.2.23 | Indication of Voice Mail..... | | 76 |

| | | |
|-----------|---|------------|
| 3.3 | Summary of CME ERROR codes..... | 76 |
| 3.4 | Summary of CMS ERROR codes..... | 79 |
| 4. | AT Commands for Network..... | 81 |
| 4.1 | Overview of AT Commands for Network..... | 81 |
| 4.2 | Detailed Description of AT Commands for Network..... | 81 |
| 4.2.1 | AT+CREG Network registration..... | 81 |
| 4.2.2 | AT+COPS Operator selection..... | 83 |
| 4.2.3 | AT+CLCK Facility lock..... | 85 |
| 4.2.4 | AT+CPWD Change password..... | 87 |
| 4.2.5 | AT+CCUG Closed user group..... | 88 |
| 4.2.6 | AT+CUSD Unstructured supplementary service data..... | 90 |
| 4.2.7 | AT+CAOC Advice of Charge..... | 91 |
| 4.2.8 | AT+CSSN Supplementary service notifications..... | 92 |
| 4.2.9 | AT+CPOL Preferred operator list..... | 94 |
| 4.2.10 | AT+COPN Read operator names..... | 95 |
| 4.2.11 | AT+CNMP Preferred mode selection..... | 96 |
| 4.2.12 | AT+CNBP Preferred band selection..... | 98 |
| 4.2.13 | AT+CNAOP Acquisitions order preference..... | 101 |
| 4.2.14 | AT+CPSI Inquiring UE system information..... | 102 |
| 4.2.15 | AT+CNSMOD Show network system mode..... | 106 |
| 4.2.16 | AT+CEREG EPS network registration status..... | 107 |
| 4.2.17 | AT+CTZU Automatic time and time zone update..... | 109 |
| 4.2.18 | AT+CTZR Time and time zone reporting..... | 110 |
| 5. | AT Commands for Call Control..... | 113 |
| 5.1 | Overview of AT Commands for Call Control..... | 113 |
| 5.2 | Detailed Description of AT Commands for Call Control..... | 113 |
| 5.2.1 | AT+CVHU Voice hang up control..... | 113 |
| 5.2.2 | AT+CHUP Hang up call..... | 114 |
| 5.2.3 | AT+CBST Select bearer service type..... | 115 |
| 5.2.4 | AT+CRLP Radio link protocol..... | 116 |
| 5.2.5 | AT+CR Service reporting control..... | 118 |
| 5.2.6 | AT+CRC Cellular result codes..... | 119 |
| 5.2.7 | AT+CLCC List current calls..... | 120 |
| 5.2.8 | AT+CEER Extended error report..... | 122 |
| 5.2.9 | AT+CCWA Call waiting..... | 122 |
| 5.2.10 | AT+CHLD Call related supplementary services..... | 124 |
| 5.2.11 | AT+CCFC Call forwarding number and conditions..... | 125 |
| 5.2.12 | AT+CLIP Calling line identification presentation..... | 127 |
| 5.2.13 | AT+CLIR Calling line identification restriction..... | 128 |
| 5.2.14 | AT+COLP Connected line identification presentation..... | 130 |
| 5.2.15 | AT+VTS DTMF and tone generation..... | 131 |
| 5.2.16 | AT+VTD Tone duration..... | 132 |
| 5.2.17 | AT+CSTA Select type of address..... | 133 |
| 5.2.18 | AT+CMOD Call mode..... | 134 |

| | |
|---|------------|
| 6. AT Commands for Phonebook..... | 136 |
| 6.1 Overview of AT Commands for Phonebook..... | 136 |
| 6.2 Detailed Description of AT Commands for Phonebook..... | 136 |
| 6.2.1 AT+CPBS Select Phonebook memory storage..... | 136 |
| 6.2.2 AT+CPBR Read Phonebook entries..... | 138 |
| 6.2.3 AT+CPBF Find Phonebook entries..... | 139 |
| 6.2.4 AT+CPBW Write Phonebook entry..... | 140 |
| 6.2.5 AT+CNUM Subscriber number..... | 142 |
| 7. AT Commands for SIM Application Toolkit..... | 143 |
| 7.1 Overview of AT Commands for SIM Application Toolkit..... | 143 |
| 7.2 Detailed Description of AT Commands for SIM Application Toolkit..... | 143 |
| 7.2.1 AT+STIN SAT Indication..... | 143 |
| 7.2.2 AT+STGI Get SAT information..... | 144 |
| 7.2.3 AT+STGR SAT respond..... | 147 |
| 7.2.4 AT+STK STK switch..... | 148 |
| 7.2.5 AT+STKFMT Set STK pdu format..... | 149 |
| 7.2.6 AT+STENV Original STK PDU Envelope Command..... | 150 |
| 7.2.7 AT+STSM Get STK Setup Menu List with PDU Mod..... | 150 |
| 8. AT Commands for GPRS..... | 152 |
| 8.1 Overview of AT Commands for GPRS..... | 152 |
| 8.2 Detailed Description of AT Commands for GPRS..... | 152 |
| 8.2.1 AT+CGREG GPRS network registration status..... | 152 |
| 8.2.2 AT+CGATT Packet domain attach or detach..... | 154 |
| 8.2.3 AT+CGACT GPRS network registration status..... | 155 |
| 8.2.4 AT+CGDCONT Define PDP context..... | 156 |
| 8.2.5 AT+CGDSCONT Define Secondary PDP Context..... | 158 |
| 8.2.6 AT+CGTFT Traffic Flow Template..... | 160 |
| 8.2.7 AT+CGQREQ Quality of service profile (requested)..... | 163 |
| 8.2.8 AT+CGEQREQ 3G quality of service profile (requested)..... | 166 |
| 8.2.9 AT+CGQMIN Quality of service profile (minimum acceptable)..... | 170 |
| 8.2.10 AT+CGEQMIN 3G quality of service profile (minimum acceptable)..... | 173 |
| 8.2.11 AT+CGDATA Enter data state..... | 177 |
| 8.2.12 AT+CGPADDR Show PDP address..... | 178 |
| 8.2.13 AT+CGCLASS GPRS network registration status..... | 179 |
| 8.2.14 AT+CGEREP GPRS event reporting..... | 180 |
| 8.2.15 AT+CGAUTH Set type of authentication for PDP-IP connections of GPRS..... | 182 |
| 9. AT Commands for SMS..... | 185 |
| 9.1 Overview of AT Commands for SMS Control..... | 185 |
| 9.2 Detailed Description of AT Commands for SMS Control..... | 185 |
| 9.2.1 AT+CSMS Select message service..... | 186 |
| 9.2.2 AT+CPMS Preferred message storage..... | 187 |
| 9.2.3 AT+CMGF Select SMS message format..... | 188 |
| 9.2.4 AT+CSCA SMS service centre address..... | 189 |
| 9.2.5 AT+CSCB Select cell broadcast message indication..... | 190 |

| | | | |
|------------|--|--|------------|
| 9.2.6 | AT+CSMP | Set text mode parameters..... | 191 |
| 9.2.7 | AT+CSDH | Show text mode parameters..... | 192 |
| 9.2.8 | AT+CNMA | New message acknowledgement to ME/TA..... | 193 |
| 9.2.9 | AT+CNMI | New message indications to TE..... | 195 |
| 9.2.10 | AT+CGSMS | Select service for MO SMS messages..... | 197 |
| 9.2.11 | AT+CMGL | List SMS messages from preferred store..... | 198 |
| 9.2.12 | AT+CMGR | Read message..... | 202 |
| 9.2.13 | AT+CMGS | Send message..... | 206 |
| 9.2.14 | AT+CMSS | Send message from storage..... | 207 |
| 9.2.15 | AT+CMGW | Write message to memory..... | 208 |
| 9.2.16 | AT+CMGD | Delete message..... | 210 |
| 9.2.17 | AT+CMGMT | Change message status..... | 211 |
| 9.2.18 | AT+CMVP | Set message valid period..... | 212 |
| 9.2.19 | AT+CMGRD | Read and delete message..... | 213 |
| 9.2.20 | AT+CMGSEX | Send message..... | 214 |
| 9.2.21 | AT+CMSSEX | Send multi messages from storage..... | 215 |
| 9.2.22 | AT+CMGP | Set cdma/evdo text mode parameters..... | 216 |
| 10. | AT Commands for SSL..... | | 218 |
| 10.1 | Overview of AT Commands for SSL..... | | 218 |
| 10.2 | Detailed Description of AT Commands for SSL..... | | 218 |
| 10.2.1 | AT+CCHSTART | Start SSL service..... | 218 |
| 10.2.2 | AT+CCHSTOP | Stop SSL service..... | 219 |
| 10.2.3 | AT+CCHOPEN | Connect to SSL server..... | 220 |
| 10.2.4 | AT+CCHCLOSE | Disconnect from SSL server..... | 221 |
| 10.2.5 | AT+CCHSEND | Send data to SSL server..... | 222 |
| 10.2.6 | AT+CCHRECV | Read the cached data that received from the server..... | 223 |
| 10.2.7 | AT+CCHADDR | Get IPV4 address..... | 225 |
| 10.2.8 | AT+CCHCFG | Configure the client context..... | 225 |
| 10.2.9 | AT+CCHSSLCFG | Set the SSL context..... | 227 |
| 10.2.10 | AT+CCHMODE | Configure the mode of sending and receiving data..... | 228 |
| 10.2.11 | AT+CCHSET | Configure the report mode of sending and receiving data..... | 229 |
| 10.2.12 | AT+CSSLCFG | Configure the SSL context..... | 230 |
| 10.2.13 | AT+CCERTDOWN | Download certificate into the module..... | 234 |
| 10.2.14 | AT+CCERTLIST | List certificates..... | 235 |
| 10.2.15 | AT+CCERTDELE | Delete certificates..... | 236 |
| 10.3 | Command result <err> codes..... | | 237 |
| 10.4 | Unsolicited result codes..... | | 238 |
| 11. | AT Commands for TCPIP..... | | 239 |
| 11.1 | Overview of AT Commands for TCPIP..... | | 239 |
| 11.2 | Detailed Description of AT Commands for TCPIP..... | | 239 |
| 11.2.1 | AT+NETOPEN | Start TCPIP service..... | 239 |
| 11.2.2 | AT+NETCLOSE | Stop TCPIP service..... | 241 |
| 11.2.3 | AT+CIPOPEN | Setup TCP/UDP client socket connection..... | 241 |
| 11.2.4 | AT+CIPCLOSE | Destroy TCP/UDP client socket connection..... | 245 |
| 11.2.5 | AT+CIPSEND | Send TCP/UDP data..... | 246 |

| | | | |
|------------|---|---|------------|
| 11.2.6 | AT+CIPRXGET | Retrieve TCP/UDP buffered data..... | 250 |
| 11.2.7 | AT+IPADDR | Get IP address of PDP context..... | 253 |
| 11.2.8 | AT+CIPHEAD | Add an IP header when receiving data..... | 253 |
| 11.2.9 | AT+CIPSRIP | Show remote IP address and port..... | 254 |
| 11.2.10 | AT+CIPMODE | Select TCP/IP application mode..... | 255 |
| 11.2.11 | AT+CIPSENDMODE | Set sending mode..... | 256 |
| 11.2.12 | AT+CIPTIMEOUT | Set TCP/IP timeout value..... | 257 |
| 11.2.13 | AT+CIPCCFG | Configure parameters of socket..... | 258 |
| 11.2.14 | AT+SERVERSTART | Startup TCP server..... | 259 |
| 11.2.15 | AT+SERVERSTOP | Stop TCP server..... | 261 |
| 11.2.16 | AT+CIPACK | Query TCP connection data transmitting status..... | 262 |
| 11.3 | DNS&PING..... | | 263 |
| 11.3.1 | AT+CDNSGIP | Query the IP address of given domain name..... | 263 |
| 11.3.2 | AT+CDNSGHNAME | Query the domain name of given IP address..... | 264 |
| 11.3.3 | AT+CIPDNSSET | Set DNS query parameters..... | 265 |
| 11.3.4 | AT+CPING | Ping destination address..... | 266 |
| 11.3.5 | AT+CPINGSTOP | Stop an ongoing ping session..... | 267 |
| 11.4 | Information Elements related to TCP/IP..... | | 268 |
| 11.5 | Description of <err_info>..... | | 269 |
| 11.6 | Description of <err>..... | | 270 |
| 12. | AT Commands for FTPS..... | | 271 |
| 12.1 | Overview of AT Commands for FTPS..... | | 271 |
| 12.2 | Detailed Description of AT Commands for FTPS..... | | 271 |
| 12.2.1 | AT+CFTPSSTART | Start FTP(S) service..... | 271 |
| 12.2.2 | AT+CFTPSSTOP | Stop FTP(S) Service..... | 272 |
| 12.2.3 | AT+CFTPSLOGIN | Login to a FTP(S) server..... | 273 |
| 12.2.4 | AT+CFTPSLOGOUT | Logout FTP(S) server..... | 274 |
| 12.2.5 | AT+CFTPSMKD | Create a new directory on FTP(S) server..... | 275 |
| 12.2.6 | AT+CFTPSRMD | Delete a directory on FTP(S) server..... | 276 |
| 12.2.7 | AT+CFTPSDELETE | Delete a file on FTP(S) server..... | 277 |
| 12.2.8 | AT+CFTPSCWD | Change the current directory on FTP(S) server..... | 277 |
| 12.2.9 | AT+CFTPSPWD | Get the current directory on FTPS server..... | 278 |
| 12.2.10 | AT+CFTPSTYPE | Set the transfer type on FTP(S) server..... | 279 |
| 12.2.11 | AT+CFTPSLIST | List the items in the directory on FTP(S) server..... | 280 |
| 12.2.12 | AT+CFTPSGETFILE | Get a file from FTP(S) server to module..... | 282 |
| 12.2.13 | AT+CFTPSPUTFILE | Put a file from module to FTP(S) server..... | 283 |
| 12.2.14 | AT+CFTPSGET | Get a file from FTP(S) server to serial port..... | 284 |
| 12.2.15 | AT+CFTPSPUT | Put a file to FTP(S) server through serial port..... | 285 |
| 12.2.16 | AT+CFTPSSINGLEIP | Set FTP(S) data socket address type..... | 287 |
| 12.2.17 | AT+CFTPSCACHERD | Output cached data to MCU..... | 288 |
| 12.2.18 | AT+CFTPSABORT | Abort FTP(S) Operations..... | 288 |
| 12.2.19 | AT+CFTPSSIZE | Get the File Size on FTP(S) server..... | 289 |
| 12.3 | Summary of result codes for FTPS..... | | 290 |
| 12.3.1 | Summary of Command result <errcode>..... | | 290 |
| 12.3.2 | Summary of Unsolicited Result Codes..... | | 291 |

| | | |
|------------|---|------------|
| 13. | AT Commands for HTTPS..... | 292 |
| 13.1 | Overview of AT Commands for HTTPS..... | 292 |
| 13.2 | Detailed Description of AT Commands for HTTPS..... | 292 |
| 13.2.1 | AT+HTTPINIT Start HTTP(S) service..... | 292 |
| 13.2.2 | AT+HTTPTERM Stop HTTP(S) Service..... | 293 |
| 13.2.3 | AT+HTTPPARA Set HTTP(S) Parameters value..... | 293 |
| 13.2.4 | AT+HTTPACTION HTTP(S) Method Action..... | 295 |
| 13.2.5 | AT+HTTPHEAD Read the HTTP(S) Header Information of Server Response..... | 296 |
| 13.2.6 | AT+HTTPREAD Read the Response Information of HTTP(S) Server..... | 297 |
| 13.2.7 | AT+HTTPDATA Input HTTP(S) Data..... | 298 |
| 13.2.8 | AT+HTTPPOSTFILE Send HTTP Request to HTTP(S) server by File..... | 299 |
| 13.2.9 | AT+HTTPREADFILE Receive HTTP(S) Response Content to a file..... | 300 |
| 13.3 | Summary of result codes for HTTPS..... | 301 |
| 13.3.1 | Summary of HTTP(S) Response Code..... | 301 |
| 13.3.2 | Summary of HTTP(S) error Code..... | 303 |
| 14. | AT Commands for HTP..... | 304 |
| 14.1 | Overview of AT Commands for HTP..... | 304 |
| 14.2 | Detailed Description of AT Commands for HTP..... | 304 |
| 14.2.1 | AT+CHTPSERV Set HTP server info..... | 304 |
| 14.2.2 | AT+CHTUPDATE Updating date time using HTP protocol..... | 305 |
| 14.2.3 | Unsolicited HTP Codes..... | 306 |
| 15. | AT Commands for NTP..... | 307 |
| 15.1 | Overview of AT Commands for NTP..... | 307 |
| 15.2 | Detailed Description of AT Commands for NTP..... | 307 |
| 15.2.1 | AT+CNTP Update system time..... | 307 |
| 15.2.2 | Unsolicited NTP Codes..... | 308 |
| 16. | AT Commands for MQTT(S)..... | 309 |
| 16.1 | Overview of AT Commands for MQTT(S)..... | 309 |
| 16.2 | Detailed Description of AT Commands for MQTT(S)..... | 309 |
| 16.2.1 | AT+CMQTTSTART Start MQTT service..... | 309 |
| 16.2.2 | AT+CMQTTSTOP STOP MQTT service..... | 310 |
| 16.2.3 | AT+CMQTTACCQ Acquire a client..... | 311 |
| 16.2.4 | AT+CMQTTREL Release a client..... | 312 |
| 16.2.5 | AT+CMQTTSSLCFG Set the SSL context..... | 313 |
| 16.2.6 | AT+CMQTTWILLTOPIC Input the will topic..... | 314 |
| 16.2.7 | AT+CMQTTWILLMSG Input the will message..... | 315 |
| 16.2.8 | AT+CMQTTDISC Disconnect from server..... | 316 |
| 16.2.9 | AT+CMQTTCONNECT Connect to MQTT server..... | 317 |
| 16.2.10 | AT+CMQTTTOPIC Input the publish message topic..... | 319 |
| 16.2.11 | AT+CMQTTPAYLOAD Input the publish message body..... | 320 |
| 16.2.12 | AT+CMQTTTTPUB Publish a message to server..... | 321 |
| 16.2.13 | AT+CMQTTSUBTOPIC Input a subscribe message topic..... | 322 |
| 16.2.14 | AT+CMQTTSUB Subscribe a message to server..... | 323 |
| 16.2.15 | AT+CMQTTUNSUBTOPIC Input a unsubscribe message topic..... | 324 |

| | | | |
|------------|---|---|------------|
| 16.2.16 | AT+CMQTTUNSUB | Unsubscribe a message to server..... | 325 |
| 16.2.17 | AT+CMQTTCFG | Configure the MQTT Context..... | 326 |
| 16.3 | Summary of result codes for MQTT(S)..... | | 328 |
| 16.3.1 | Summary of Command result <err> codes..... | | 328 |
| 16.3.2 | Summary of Unsolicited Result Codes..... | | 329 |
| 17. | AT Commands for GPS..... | | 331 |
| 17.1 | Overview of AT Commands for GPS..... | | 331 |
| 17.2 | Detailed Description of AT Commands for GPS..... | | 331 |
| 17.2.1 | AT+CGPS | Start/Stop GPS session..... | 332 |
| 17.2.2 | AT+CGPSINFO | Get GPS fixed position information..... | 333 |
| 17.2.3 | AT+CGPSCOLD | Cold Start GPS..... | 334 |
| 17.2.4 | AT+CGPSHOT | Hot Start GPS..... | 335 |
| 17.2.5 | AT+CGPSURL | Set AGPS default server URL..... | 335 |
| 17.2.6 | AT+CGPSSSL | Set AGPS transport security..... | 336 |
| 17.2.7 | AT+CGPSAUTO | Start GPS automatic..... | 337 |
| 17.2.8 | AT+CGPSNMEA | Configure NMEA sentence type..... | 338 |
| 17.2.9 | AT+CGPSNMEARATE | Set NMEA output rate..... | 339 |
| 17.2.10 | AT+CGPSMD | Configure AGPS MO method..... | 340 |
| 17.2.11 | AT+CGPSFTM | Start GPS test mode..... | 340 |
| 17.2.12 | AT+CGPSDEL | Delete the GPS information..... | 341 |
| 17.2.13 | AT+CGPSXE | Enable/Disable GPS XTRA function..... | 342 |
| 17.2.14 | AT+CGPSXD | Download XTRA assistant file..... | 343 |
| 17.2.15 | AT+CGPSXDAUTO | Download XTRA assistant file automatically..... | 344 |
| 17.2.16 | AT+CGPSINFOCFG | Download Report GPS NMEA-0183 sentence..... | 344 |
| 17.2.17 | AT+CGPSPMD | Configure positioning mode..... | 346 |
| 17.2.18 | AT+CGPSMSB | Configure based mode switch to standalone..... | 347 |
| 17.2.19 | AT+CGPSHOR | Configure positioning desired accuracy..... | 348 |
| 17.2.20 | AT+CGPSNOTIFY | LCS respond positioning request..... | 349 |
| 17.2.21 | AT+CGNSSINFO | LCS Get GNSS fixed position information..... | 349 |
| 17.2.22 | AT+CGNSSMODE | LCS Configure GNSS support mode..... | 351 |
| 17.2.23 | AT+CGPSIPV6 | Set AGPS IPV6 Addr&Port..... | 352 |
| 17.2.24 | AT+CGPSXTRADATA | Query the validity of the current gpsOne XTRA Data..... | 353 |
| 18. | AT Commands for LBS..... | | 354 |
| 18.1 | Overview of AT Commands for LBS..... | | 354 |
| 18.2 | Detailed Description of AT Commands for LBS..... | | 354 |
| 18.3 | AT Commands for Open/Close Network..... | | 354 |
| 18.3.1 | Overview of AT Commands for Open/Close Network..... | | 354 |
| 18.3.2 | Detailed Description of AT Commands for Open/Close Network..... | | 354 |
| 18.3.3 | Unsolicited Open/Close network command <err> Codes..... | | 357 |
| 19. | AT Commands for Hardware..... | | 361 |
| 19.1 | Overview of AT Commands for Hardware Related..... | | 361 |
| 19.2 | Detailed Description of AT Commands for Hardware Related..... | | 361 |
| 19.2.1 | AT+CVALARM | Low and high voltage Alarm..... | 362 |
| 19.2.2 | AT+CVAUXS | Set state of the pin named VREG_AUX1..... | 363 |

| | | | |
|------------|--|--|------------|
| 19.2.3 | AT+CVAUXV | Set voltage value of the pin named VREG_AUX1..... | 363 |
| 19.2.4 | AT+CADC | Read ADC value..... | 364 |
| 19.2.5 | AT+CADC2 | Read ADC2 value..... | 365 |
| 19.2.6 | AT+CMTE | Control the module whether power shutdown when the module's temperature upon the critical temperature..... | 366 |
| 19.2.7 | AT+CPMVT | Low and high voltage Power Off..... | 367 |
| 19.2.8 | AT+CDELTA | Set the module go to recovery mode..... | 368 |
| 19.2.9 | AT+CRIIC | Read values from register of IIC device..... | 368 |
| 19.2.10 | AT+CWIIC | Write values to register of IIC device..... | 369 |
| 19.2.11 | AT+CBC | Read the voltage value of the power supply..... | 370 |
| 19.2.12 | AT+CPMUTEMP | Read the temperature of the module..... | 370 |
| 19.2.13 | AT+CFDISK | SD Card/EMMC Flash..... | 371 |
| 20. | AT Commands for File System..... | | 373 |
| 20.1 | Overview of AT Commands for File System..... | | 373 |
| 20.2 | Detailed Description of AT Commands for File System..... | | 374 |
| 20.2.1 | AT+FSCD | Select directory as current directory..... | 374 |
| 20.2.2 | AT+FSMKDIR | Make new directory in current directory..... | 375 |
| 20.2.3 | AT+FSRMDIR | Delete directory in current directory..... | 376 |
| 20.2.4 | AT+FSLS | List directories/files in current directory..... | 377 |
| 20.2.5 | AT+FSDEL | Delete file in current directory..... | 378 |
| 20.2.6 | AT+FSRENAME | Rename file in current directory..... | 379 |
| 20.2.7 | AT+FSATTRI | Request file attributes..... | 379 |
| 20.2.8 | AT+FSMEM | Check the size of available memory..... | 380 |
| 20.2.9 | AT+FSLOCA | Select storage place..... | 381 |
| 20.2.10 | AT+FSCOPY | Copy an appointed file..... | 382 |
| 20.2.11 | AT+CFTRANRX | Transfer a file to EFS..... | 384 |
| 20.2.12 | AT+CFTRANRX | Transfer a file from EFS to host..... | 385 |
| 21. | AT Commands for AUDIO..... | | 387 |
| 21.1 | Overview of AT Commands for AUDIO..... | | 387 |
| 21.2 | Detailed Description of AT Commands for AUDIO..... | | 387 |
| 21.2.1 | AT+CREC | Record wav audio file..... | 387 |
| 21.2.2 | AT+CRECAMR | Record amr audio file..... | 388 |
| 21.2.3 | AT+CCMXPLAYWAV | Play wav audio file..... | 390 |
| 21.2.4 | AT+CCMXSTOPWAV | Stop playing wav audio file..... | 391 |
| 21.2.5 | AT+CCMXPLAY | Play audio file..... | 392 |
| 21.2.6 | AT+CCMXSTOP | Stop playing audio file..... | 393 |
| 22. | AT Commands for TTS..... | | 394 |
| 22.1 | Overview of AT Commands for TTS..... | | 394 |
| 22.2 | Detailed Description of AT Commands for TTS..... | | 394 |
| 22.2.1 | AT+CDTAM | TTS play path, local or remote..... | 394 |
| 22.2.2 | AT+CTTS | TTS operation, play or stop..... | 395 |
| 22.2.3 | AT+CTTSPARAM | TTS Parameters, set or get..... | 397 |
| 23. | AT Commands for FOTA..... | | 399 |
| 23.1 | Overview of AT Commands for FOTA..... | | 399 |

| | | |
|------------|---|------------|
| 23.2 | Detailed Description of AT Commands for FOTA..... | 399 |
| 23.2.1 | AT+CAPFOTA Start/Close FOTA Service..... | 399 |
| 23.2.2 | AT+CSCFOTA Configure parameters and download upgrade package..... | 400 |
| 24. | AT Commands for UIM hotswap..... | 402 |
| 24.1 | Overview of AT Commands for UIM hotswap..... | 402 |
| 24.2 | Detailed Description of AT Commands for UIM hotswap..... | 402 |
| 24.2.1 | AT+UIMHOTSWAPON Set UIM hotswap function on..... | 402 |
| 24.2.2 | AT+UIMHOTSWAPLEVEL Set UIM card detection level..... | 403 |
| 25. | AT Commands for HSIC_LAN..... | 405 |
| 25.1 | Overview of AT Commands for HAIC_LAN..... | 405 |
| 25.2 | Detailed Description of AT Commands for HSIC_LAN..... | 405 |
| 25.2.1 | AT+CENABLELAN Enable LAN function..... | 405 |
| 25.2.2 | AT+CLANMODE Set LAN mode..... | 406 |
| 25.2.3 | AT+CLANCTRL Set LAN configure..... | 407 |
| 25.2.4 | AT+CHSICSLEEP Allow HSIC Device Go to AutoSleep..... | 408 |
| 26. | AT Commands for Ecall..... | 410 |
| 26.1 | Overview of AT Commands for Ecall..... | 410 |
| 26.2 | Detailed Description of AT Commands for Ecall..... | 410 |
| 26.2.1 | AT+CECALLS Make e-call..... | 410 |
| 26.2.2 | AT+CECALLE Hang up e-call..... | 411 |
| 26.2.3 | AT+CECALLCFG Configure e-call MSD information..... | 412 |
| 26.2.4 | AT+CECALLPOS Set position information..... | 413 |
| 26.2.5 | AT+CECALLTIME Set timestamp..... | 414 |
| 26.2.6 | AT+CECALLVERSION Set MSD serialize version..... | 415 |
| 26.2.7 | AT+CECALLTOUT Set T5,T6,T7 timeout value..... | 416 |
| 26.2.8 | AT+CMSDMESSAGEID Set the initiatory message identifier of msd data Description 417 | |
| 26.2.9 | AT+CMSDOIDDATA Set the optional additional data..... | 417 |
| 26.2.10 | AT+CMSD Input hex Minimum set of data..... | 418 |
| 26.2.11 | AT+CMSDCONTROL Set the control data in Minimum set of data..... | 419 |
| 27. | AT Commands for MIFI..... | 420 |
| 27.1 | Overview of AT Commands for MIFI W58..... | 420 |
| 27.2 | Overview of AT Commands for MIFI W58L(RTL)..... | 420 |
| 27.3 | Detailed Description of AT Commands for MIFI..... | 421 |
| 27.3.1 | AT+CWMAP Open/Close WIFI..... | 421 |
| 27.3.2 | AT+CWSSID SSID setting..... | 422 |
| 27.3.3 | AT+CWBICAST Broadcast setting..... | 423 |
| 27.3.4 | AT+CWAUTH Authentication setting..... | 423 |
| 27.3.5 | AT+CWMOCH 80211 mode and channel setting..... | 425 |
| 27.3.6 | AT+CWISO Client isolation setting..... | 426 |
| 27.3.7 | AT+CWDHCP Get the current DHCP configuration..... | 427 |
| 27.3.8 | AT+CWNAT NAT type setting..... | 427 |
| 27.3.9 | AT+CWCLICNT Get client number connected to the WIFI..... | 428 |
| 27.3.10 | AT+CWRSTD Restore to default setting..... | 429 |

| | | | |
|------------|---|--|------------|
| 27.3.11 | AT+CWMAPCFG | WIFI configuration setting..... | 429 |
| 27.3.12 | AT+CWLANSRV | LAN SERVER setting..... | 431 |
| 27.3.13 | AT+CWLANMSG | Send message..... | 432 |
| 27.3.14 | AT+CWLANMGET | Manual get cached bytes..... | 433 |
| 27.3.15 | AT+CWMACADDR | Get MAC address..... | 434 |
| 27.3.16 | AT+CWNENETCNCT | Query the connection to the network..... | 435 |
| 27.3.17 | AT+CWSTAIP | Get STA mode IP address..... | 435 |
| 27.3.18 | AT+CWSTASCAN | Scan WIFI network..... | 436 |
| 27.3.19 | AT+CWSTACFG | STA mode configuration setting..... | 437 |
| 27.3.20 | AT+CWSTAINIT | STA mode setting..... | 438 |
| 27.3.21 | AT+CWUSRINFO | Auth info of wifi data call setting..... | 439 |
| 28. | AT Commands for BT..... | | 441 |
| 28.1 | Overview of AT Commands for BT..... | | 441 |
| 28.2 | Detailed Description of AT Commands for BT..... | | 442 |
| 28.2.1 | AT+BTPOWER | Open/Close BT..... | 442 |
| 28.2.2 | AT+BTHOST | Get/Set host name..... | 443 |
| 28.2.3 | AT+BTSCAN | Scan BT devices..... | 444 |
| 28.2.4 | AT+BTIOCAP | IOCAP Mode Setting..... | 445 |
| 28.2.5 | AT+BTPAIR | Pair with other BT device..... | 446 |
| 28.2.6 | AT+BTUNPAIR | Unpair with other BT device..... | 447 |
| 28.2.7 | AT+BTPAIRED | Get paired with BT device..... | 448 |
| 28.2.8 | AT+BTSPPSRV | Active/Deactive spp server..... | 448 |
| 28.2.9 | AT+BTSPPPROF | Get remote device spp status..... | 449 |
| 28.2.10 | AT+BTSPPCONN | SPP connect/disconnect..... | 450 |
| 28.2.11 | AT+BTSPSEND | SPP send data..... | 451 |
| 28.2.12 | AT+BTGATTREG | GATT Register..... | 452 |
| 28.2.13 | AT+BTGATTACT | GATT Active..... | 452 |
| 28.2.14 | AT+BTGATTCREDB | GATT Create DB..... | 453 |
| 28.2.15 | AT+BTGATTCRESRV | GATT Create Service..... | 454 |
| 28.2.16 | AT+BTGATTCRECHAR | Create Service characteristic..... | 454 |
| 28.2.17 | AT+BTGATTCRECHARDES | Create Service characteristic description..... | 455 |
| 28.2.18 | AT+BTGATTSRVADD | DB Add To GATT Server..... | 455 |
| 28.2.19 | AT+BTGATTREADCFM | Response to BTGATTREADIND..... | 456 |
| 28.2.20 | AT+BTGATTWRFCFM | Response to BTGATTWRIND..... | 457 |
| 28.2.21 | AT+BTGATTNOTIFY | Send Notification to client..... | 457 |
| 28.2.22 | AT+BTGATTSENDIND | Send Indication to client..... | 458 |
| 28.2.23 | +BTSPPRECV | SPP receive data..... | 459 |
| 28.2.24 | +BTGATTCONN | Client connect status..... | 459 |
| 28.2.25 | +BTGATTREADIND | Receive client read request..... | 459 |
| 28.2.26 | +BTGATTWRIND | Receive client write request..... | 460 |

THIS DOCUMENT IS A REFERENCE GUIDE TO ALL THE AT COMMANDS.

SIMCom
Confidential

1. Introduction

1.1 Scope of the document

This document presents the AT Command Set for SIMCom SIM7500 and SIM7600 series.

1.2 Related documents

You can visit the SIMCom Website using the following link:

<http://www.simcom.com>

1.3 Conventions and abbreviations

In this document, the GSM engines are referred to as following term:

ME (Mobile Equipment);

MS (Mobile Station);

TA (Terminal Adapter);

DCE (Data Communication Equipment) or facsimile DCE (FAX modem, FAX board);

In application, controlling device controls the GSM engine by sending AT Command via its serial interface.

The controlling device at the other end of the serial line is referred to as following term:

TE (Terminal Equipment);

DTE (Data Terminal Equipment) or plainly "the application" which is running on an embedded system;

1.4 AT Command syntax

The "AT" or "at" or "aT" or "At" prefix must be set at the beginning of each Command line. To terminate a Command line enter <CR>.

Commands are usually followed by a response that includes. "<CR><LF><response><CR><LF>" Throughout this document, only the responses are presented, <CR><LF> are omitted intentionally.

The AT Command set implemented by SIM7500&SIM7600 Series is a combination of 3GPP TS 27.005, 3GPP TS 27.007 and ITU-T recommendation V.25ter and the AT commands developed by SIMCom.

NOTE

Only enter AT Command through serial port after SIM7500&SIM7600 Series is powered on and Unsolicited Result Code "RDY" is received from serial port. If auto-bauding is enabled, the Unsolicited Result Codes "RDY" and so on are not indicated when you start up the ME, and the "AT" prefix, or "at" prefix must be set at the beginning of each command line.

All these AT commands can be split into three categories syntactically: "basic", "S parameter", and "extended". These are as follows:

1.4.1 Basic syntax

These AT commands have the format of "AT<x><n>", or "AT&<x><n>", where "<x>" is the Command, and "<n>" is/are the argument(s) for that Command. An example of this is "ATE<n>", which tells the DCE whether received characters should be echoed back to the DTE according to the value of "<n>". "<n>" is optional and a default will be used if missing.

1.4.2 S Parameter syntax

These AT commands have the format of "ATS<n>=<m>", where "<n>" is the index of the S register to set, and "<m>" is the value to assign to it. "<m>" is optional; if it is missing, then a default value is assigned.

1.4.3 Extended Syntax

These commands can operate in several modes, as in the following table:

Table 1: Types of AT commands and responses

Test Command

The mobile equipment returns the list of parameters and value ranges set with the corresponding Write Command or by internal processes.

| | |
|---------------------------------|---|
| AT+<x>=? | |
| Read Command | This command returns the currently set value of the parameter or parameters. |
| AT+<x>? | |
| Write Command | This command sets the user-definable parameter values. |
| AT+<x>=<...> | |
| Execution Command | The execution command reads non-variable parameters affected by internal processes in the GSM engine. |
| AT+<x> | |

1.4.4 Combining AT commands on the same Command line

You can enter several AT commands on the same line. In this case, you do not need to type the "AT" or "at" prefix before every command. Instead, you only need type "AT" or "at" the beginning of the command line. Please note to use a semicolon as the command delimiter after an extended command; in basic syntax or S parameter syntax, the semicolon need not enter, for example:

```
ATE1Q0S0=1S3=13V1X4;+IFC=0,0;+IPR=115200.
```

The Command line buffer can accept a maximum of 559 characters (counted from the first command without "AT" or "at" prefix) or 39 AT commands. If the characters entered exceeded this number then none of the Command will executed and TA will return "ERROR".

1.4.5 Entering successive AT commands on separate lines

When you need to enter a series of AT commands on separate lines, please Note that you need to wait the final response (for example OK, CME error, CMS error) of last AT Command you entered before you enter the next AT Command.

1.5 Supported character sets

The SIM7500&SIM7600 Series AT Command interface defaults to the **IRA** character set. The SIM7500&SIM7600 Series supports the following character sets:

GSM format

UCS2

IRA

The character set can be set and interrogated using the "AT+CSCS" Command (3GPP TS 27.007). The character set is defined in GSM specification 3GPP TS 27.005.

The character set affects transmission and reception of SMS and SMS Cell Broadcast messages, the entry and display of phone book entries text field and SIM Application Toolkit alpha strings.

1.6 Flow control

Flow control is very important for correct communication between the GSM engine and DTE. For in the case such as a data or fax call, the sending device is transferring data faster than the receiving side is ready to accept. When the receiving buffer reaches its capacity, the receiving device should be capable to cause the sending device to pause until it catches up.

There are basically two approaches to achieve data flow control: software flow control and hardware flow control. SIM7500&SIM7600 Series support both two kinds of flow control.

In Multiplex mode, it is recommended to use the hardware flow control.

1.6.1 Software flow control (XON/XOFF flow control)

Software flow control sends different characters to stop (XOFF, decimal 19) and resume (XON, decimal 17) data flow. It is quite useful in some applications that only use three wires on the serial interface.

The default flow control approach of SIM7500&SIM7600 Series is hardware flow control (RTS/CTS flow control), to enable software flow control in the DTE interface and within GSM engine, type the following AT Command:

```
AT+IFC=1,1
```

Ensure that any communications software package (e.g. Hyper terminal) uses software flow control.

NOTE

Software Flow control should not be used for data calls where binary data will be transmitted or received (e.g. TCP/IP) as the DTE interface may interpret binary data as flow control characters.

1.6.2 Hardware flow control (RTS/CTS flow control)

Hardware flow control achieves the data flow control by controlling the RTS/CTS line. When the data transfer should be suspended, the CTS line is set inactive until the transfer from the receiving buffer has completed. When the receiving buffer is ok to receive more data, CTS goes active once again.

To achieve hardware flow control, ensure that the RTS/CTS lines are present on your application platform.

1.7 Definitions

1.7.1 Parameter Saving Mode

For the purposes of the present document, the following syntactical definitions apply:

- **NO_SAVE**: The parameter of the current AT command will be lost if module is rebooted or current AT command doesn't have parameter.
- **AUTO_SAVE**: The parameter of the current AT command will be kept in NVRAM automatically and take in effect immediately, and it won't be lost if module is rebooted.
- **AUTO_SAVE_REBOOT**: The parameter of the current AT command will be kept in NVRAM automatically and take in effect after reboot, and it won't be lost if module is rebooted.

1.7.2 Max Response Time

Max response time is estimated maximum time to get response, the unit is seconds.

2. AT Commands According to V.25TER

2.1 Overview of AT Commands According to V.25TER

| Command | Description |
|---------|---|
| A/ | Re-issues the last command given |
| ATD | Mobile originated call to dial a number |
| ATE | Set command echo mode |
| ATH | Disconnect existing connection |
| ATI | Display product identification information |
| ATL | Set monitor speaker loudness |
| ATM | Set monitor speaker mode |
| +++ | Switch from data mode or ppp online mode to command mode |
| ATO | Switch from command mode to data mode |
| ATQ | Set result code presentation mode |
| ATS0 | Set number of rings before automatically answering the call |
| ATS3 | Set command line termination character |
| ATS4 | Set response formatting character |
| ATS5 | Set command line editing character |
| ATS6 | Pause before blind dialling |
| ATS7 | Set number of seconds to wait for connection completion |
| ATS8 | Set number of seconds to wait for comma dial modifier encountered in dial string of D command |
| ATS10 | Set disconnect delay after indicating the absence of data carrier |
| ATV | TA response format |
| ATX | Set connect result code format and monitor call progress |
| ATZ | Reset default configuration |
| AT&C | Set DCD function mode |
| AT&D | Set DTR function mode |
| AT&E | Set CONNECT Result Code Format About Speed |
| AT+GCAP | Request complete TA capabilities list |
| AT+GMI | Request manufacturer identification |
| AT+GMM | Request TA model identification |
| AT+GMR | Request TA revision identification of software release |

| | |
|--------|--|
| AT+GOI | Request global object identification |
| AT+GSN | Request TA serial number identification (IMEI) |
| AT+ICF | Set TE-TA control character framing |
| AT+IPR | Set TE-TA fixed local rate |

2.2 Detailed Description of AT Commands According to V.25TER

2.2.1 A/ Re-issues the Last Command Given

| A/ Re-issues the Last Command Given | |
|-------------------------------------|--------------------------------|
| Execution Command | Response |
| A/ | Re-issues the previous Command |
| Parameter Saving Mode | NO_SAVE |
| Maximum Response Time | 120000ms |
| Reference | |

Example

```
A/
+GCAP:+CGSM,+FCLASS,+DS
OK
```

2.2.2 ATD Mobile Originated Call to Dial A Number

This command can be used to set up outgoing data calls. It also serves to control supplementary services.

| ATD Mobile Originated Call to Dial A Number | |
|---|--|
| Execution Command | Response |
| ATD<n>[<msgm>] | If error is related to ME functionality +CME ERROR: <err> |
| | If no dial tone and (parameter setting ATX2 or ATX4) NO DIALTONE |
| | If busy and (parameter setting ATX3 or ATX4) BUSY |

| | |
|-----------------------|---|
| | <p>If a connection cannot be established NO CARRIER</p> <p>If the remote station does not answer NO ANSWER</p> <p>If connection successful and non-voice call. CONNECT<text> TA switches to data mode. Note: <text> output only if ATX<value> parameter setting with the <value> >0</p> <p>When TA returns to command mode after call release OK</p> |
| Parameter Saving Mode | NO_SAVE |
| Maximum Response Time | Timeout set with ATS7 (data call) |
| Reference | |

Defined Values

| | |
|------------------------|--|
| <n> | <p>String of dialing digits and optionally V.25ter modifiers dialing digits: 0-9, *, #, +, A, B, C Following V.25ter modifiers are ignored: , (comma), T, P, !, W, @</p> |
| Emergency call: | |
| <n> | Standardized emergency number 112 (no SIM needed) |
| <mgsms> | <p>String of GSM modifiers:</p> <p>I Activates CLIR (Disables presentation of own number to called party) i Deactivates CLIR (Enable presentation of own number to called party) G Activates Closed User Group invocation for this call only g Deactivates Closed User Group invocation for this call only</p> |

Example

```
ATD10086;
OK
VOICE CALL:BEGIN
```

NOTE

- This command may be aborted generally by receiving an ATH Command or a character during execution. The aborting is not possible during some states of connection establishment such as

handshaking.

2.2.3 ATD<mem><n> Originate call from specified memory

This command is used to originate a call using specified memory and index number.

ATD<mem><n> Originate call from specified memory

Execution Command

ATD<mem><n>[:]

Response

a) If originate a voice call successfully:

OK

VOICE CALL:BEGIN

b) If Originate a data call successfully:

CONNECT [<text>]

c) Originate a call unsuccessfully during command execution:

ERROR

d) Originate a call unsuccessfully for failed connection recovery:

NO CARRIER

e) Originate a call unsuccessfully for error related to the MT:

+CME ERROR: <err>

Maximum Response Time

Timeout set with AT57 (data call)

Reference

V.25ter

Defined Values

<mem>

Phonebook storage: (For detailed description of storages see [AT+CPBS](#))

"DC" ME dialed calls list

"MC" ME missed (unanswered received) calls list

"RC" ME received calls list

"SM" SIM phonebook

"ME" UE phonebook

"FD" SIM fixed dialing phonebook

"ON" MSISDN list

"LD" Last number dialed phonebook

"EN" Emergency numbers

<n>

Integer type memory location in the range of locations available in the

| | |
|--------|---|
| | selected memory, i.e. the index returned by AT+CPBR . |
| <;> | The termination character ";" is mandatory to set up voice calls. It must not be used for data and fax calls. |
| <text> | CONNECT result code string; the string formats please refer ATX/ATV/AT&E command. |
| <err> | Service failure result code string; the string formats please refer +CME ERROR result code and AT+CMEE command. |

Example

```

ATD>SM3 //Specify the <mem>.
OK
VOICE CALL: BEGIN

```

2.2.4 ATD><n> Originate call from active memory(1)

This command is used to originate a call to specified number. Telecom does not support this command.

ATD><n> Originate call from active memory

| Execution Command | Response |
|----------------------------|---|
| ATD><n>[;] | a) If originate a voice call successfully: OK VOICE CALL:BEGIN |
| | b) If Originate a data call successfully: CONNECT [<text>] |
| | c) Originate a call unsuccessfully during command execution: ERROR |
| | d) Originate a call unsuccessfully for failed connection recovery: NO CARRIER |
| | e) Originate a call unsuccessfully for error related to the MT: +CME ERROR: <err> |
| Maximum Response Time | Timeout set with AT+T7 (data call) |
| Reference | |
| V.25ter | |

Defined Values

| | |
|-----|---|
| <n> | Integer type memory location in the range of locations available in the |
|-----|---|

| | |
|--------|---|
| | selected memory, i.e. the index returned by AT+CPBR . |
| <;> | The termination character ";" is mandatory to set up voice calls. It must not be used for data and fax calls. |
| <text> | CONNECT result code string; the string formats please refer ATX/ATV/AT&E command. |
| <err> | Service failure result code string; the string formats please refer +CME ERROR result code and AT+CMEE command. |

Example

```
ATD>2;
OK
VOICE CALL: BEGIN
```

2.2.5 ATD><str> Originate call from active memory(2)

This command is used to originate a call to specified number. Telecom does not support this command.

ATD><n> Originate call from active memory

| Execution Command | Response |
|------------------------------|---|
| ATD><str>[:] | <p>a) If originate a voice call successfully: OK VOICE CALL:BEGIN</p> <p>b) If Originate a data call successfully: CONNECT [<text>]</p> <p>c) Originate a call unsuccessfully during command execution: ERROR</p> <p>d) Originate a call unsuccessfully for failed connection recovery: NO CARRIER</p> <p>e) Originate a call unsuccessfully for error related to the MT: +CME ERROR: <err></p> |
| Maximum Response Time | Timeout set with AT+T7 (data call) |
| Reference | |
| V.25ter | |

Defined Values

| | |
|-------|--|
| <str> | String type value, which should equal to an alphanumeric field in at |
|-------|--|

| | |
|--------|--|
| | least one phone book entry in the searched memories. <str> formatted as current TE character set specified by AT+CSCS.<str> must be double quoted. |
| <;> | The termination character ";" is mandatory to set up voice calls. It must not be used for data and fax calls. |
| <text> | CONNECT result code string; the string formats please refer ATX/ATV/AT&E command. |
| <err> | Service failure result code string; the string formats please refer +CME ERROR result code and AT+CMEE command. |

Example

```
ATD>"kobe";
OK
VOICE CALL: BEGIN
```

2.2.6 ATA Call answer

This command is used to make remote station to go off-hook, e.g. answer an incoming call. If there is no an incoming call and entering this command to TA, it will be return "NO CARRIER" to TA.

ATA Call answer

Execution Command

ATA

Response

a)If originate a voice call successfaully:

OK

VOICE CALL:BEGIN

b)For data call, and TA switches to data mode:

CONNECT

c)No connection or no incoming call:

NO CARRIER

Reference

V.25ter

Example

```
ATA
VOICE CALL: BEGIN
OK
```

2.2.7 ATH Disconnect existing call

This command is used to disconnect existing call. Before using **ATH** command to hang up a voice call, it must set **AT+CVHU=0**. Otherwise, ATH command will be ignored and "OK" response is given only.

This command is also used to disconnect PS data call, and in this case it doesn't depend on the value of **AT+CVHU**.

| ATH Disconnect existing call | |
|---------------------------------|---|
| Execution Command ATH | Response a) If AT+CVHU=0: VOICE CALL:END:<time> OK |
| Reference V.25ter | |

Defined Values

| | |
|--------|---|
| <time> | Voice call connection time: Format – HHMMSS (HH: hour, MM: minute, SS: second) |
|--------|---|

Example

```
AT+CVHU=0
OK
ATH
VOICE CALL:END:000017
OK
```

2.2.8 ATSO Automatic answer incoming call

The S-parameter command controls the automatic answering feature of the Module. If set to 000, automatic answering is disabled, otherwise it causes the Module to answer when the incoming call indication (RING) has occurred the number of times indicated by the specified value; and the setting will not be stored upon power-off, i.e. the default value will be restored after restart.

| ATSO Automatic answer incoming call | |
|-------------------------------------|---|
| Read Command ATSO? | Response a) If succes: <n> OK |

| | |
|--|--|
| | b) If failed ERROR |
| Write command ATS0=<n> | Response a)If succes: OK b)If failed ERROR |
| Reference V.25ter | |

Defined Values

| | |
|-----|---|
| <n> | <u>000</u> Automatic answering mode is disable. (default value when power-on) 001–255 Enable automatic answering on the ring number specified. |
|-----|---|

NOTE

- 1.The S-parameter command is effective on voice call and data call.
- 2.If <n> is set too high, the remote party may hang up before the call can be answered automatically.

Example

```
ATS0?
000
OK
ATS0=003
OK
```

2.2.9 +++ Switch from data mode to command mode

This command is only available during a connecting PS data call. The +++ character sequence causes the TA to cancel the data flow over the AT interface and switch to Command Mode. This allows to enter AT commands while maintaining the data connection to the remote device.

+++ Switch from data mode to command mode

| | |
|---------------------------------|-----------------------|
| Execution Command +++ | Response OK |
| Reference V.25ter | |

NOTE

To prevent the +++ escape sequence from being misinterpreted as data, it must be preceded and followed by a pause of at least 1000 milliseconds, and the interval between two '+' character can't exceed 900 milliseconds.

2.2.10 ATO Switch from command mode to data mode

ATO is the corresponding command to the +++ escape sequence. When there is a PS data call connected and the TA is in Command Mode, **ATO** causes the TA to resume the data and takes back to Data Mode.

ATO Switch from command mode to data mode

Execution Command

ATO

Response

a) TA/DCE switches to Data Mode from Command Mode:

CONNECT [<baud rate>]

b) If connection is not successfully resumed:

NO CARRIER

ERROR

Reference

V.25ter

Example

ATO

CONNECT 115200

2.2.11 ATI Display product identification information

This command is used to request the product information, which consists of manufacturer identification, model identification, revision identification, International Mobile station Equipment Identity (IMEI) and overall capabilities of the product.

ATI Display product identification information

Execution Command

ATI

Response

Manufacturer: <manufacturer>

| | |
|----------------------|---|
| | Model: <model> Revision: <revision> IMEI: [<sn>] +GCAP: list of <name>s OK |
| Reference V.25ter | |

Defined Values

| | |
|-----------------------------|--|
| <manufacturer> | The identification of manufacturer. |
| <model> | The identification of model. |
| <revision> | The revision identification of firmware. |
| <sn> | Serial number identification, which consists of a single line containing IMEI (International Mobile station Equipment Identity) number. |
| <name> | List of additional capabilities: +CGSM GSM function is supported +FCLASS FAX function is supported +DS Data compression is supported +ES Synchronous data mode is supported. +CIS707-A CDMA data service command set +CIS-856 EVDO data service command set +MS Mobile Specific command set |

Example

```

ATI
Manufacturer:          SIMCOM
INCORPORATED
Model: SIMCOM_SIM7600C
Revision: SIM7600C_V1.0
IMEI: 351602000330570
+GCAP: +CGSM,+FCLASS,+DS

OK

```

2.2.12 AT+IPR Set local baud rate temporarily

This command sets the baud rate of module's serial interface temporarily, after reboot the baud rate is set to value of IPREX.

AT+IPR Set local baud rate temporarily

| | |
|--|---|
| Test Command AT+IPR=? | Response +IPR: (list of supported<speed>s) OK |
| Read Command AT+IPR? | Response +IPR: <speed> OK |
| Write Command AT+IPR=<speed> | Response OK or ERROR |
| Execution Command AT+IPR=<speed> | Set the value to boot value: OK |

Defined Values

| | |
|----------------------|---|
| <speed> | Baud rate per second: 0, 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, <u>115200</u> , 230400, 460800, 921600, 3000000, 3200000, 3686400 |
|----------------------|---|

2.2.13 AT+ICF Set control character framing

This command sets character framing which contains data bit, stop bit and parity bit.

AT+ICF Set local baud rate temporarily

| | |
|---|--|
| Test Command AT+ICF=? | Response +ICF: (list of supported<format>s), (list of supported<parity>s) OK |
| Read Command AT+ICF? | Response +ICF: <format>, <parity> OK |
| Write Command AT+ICF=<format>[, <parity>] | Response OK or ERROR |
| Execution Command AT+ICF | Set default value: OK |
| Reference V.25ter | |

Defined Values

| | |
|-----------------------|--|
| <format> | <ul style="list-style-type: none"> 1 – data bit 8, stop bit 2 2 – data bit 8, parity bit 1, stop bit 1 3 – data bit 8, stop bit 1 4 – data bit 7, stop bit 2 5 – data bit 7, parity bit 1, stop bit 1 6 – data bit 7, stop bit 1 |
| <parity> | <ul style="list-style-type: none"> 0 – Odd 1 – Even 2 – Space 3 – none |

Example

```

AT+ICF?
+ICF: 3,3
OK
AT+ICF=?
+ICF: (1-6),(0-3)
OK
AT+ICF=3,3
OK
  
```

2.2.14 AT+IFC Set local data flow control

The command sets the flow control mode of the module.

| AT+IFC Set local data flow control | |
|--|--|
| Test Command AT+IFC=? | Response +IFC: (list of supported<DCE>s), (list of supported<DTE>s) OK or ERROR |
| Read Command AT+IFC? | Response +IFC: <DCE>,<DTE> OK or ERROR |
| Write Command AT+IFC=<DCE>[,<DTE>] | Response OK or ERROR |
| Execution Command | Set default value: |

| | |
|----------------------|-----------|
| AT+IFC | OK |
| Reference V.25ter | |

Defined Values

| | |
|--------------------|--|
| <DCE> | <u>0</u> – none (default) 2 – RTS hardware flow control |
| <DTE> | <u>0</u> – none (default) 2 – CTS hardware flow control |

Example

```

AT+IFC?
+ICF: 0,0
OK
AT+IFC=?
+ICF: (0,2),(0,2)
OK
AT+IFC=2,2
OK

```

2.2.15 AT&C Set DCD function mode

This command determines how the state of DCD PIN relates to the detection of received line signal from the distant end.

| AT&C Set DCD function mode | |
|---|---|
| Execution Command AT&C[<value>] | Response OK or ERROR |
| Reference V.25ter | |

Defined Values

| | |
|----------------------|--|
| <value> | 0 DCD line shall always be on. 1 DCD line shall be on only when data carrier signal is present. 2 Setting winks(briefly transitions off,then back on)the DCD line when data calls end. |
|----------------------|--|

Example

```
AT&C1
OK
```

2.2.16 ATE Enable command echo

This command sets whether or not the TA echoes characters.

| ATE Enable command echo | |
|--|---|
| Execution Command ATE[<value>] | Response OK or ERROR |
| Reference V.25ter | |

Defined Values

| | |
|---------|-------------------|
| <value> | 0 – Echo mode off |
| | 1 – Echo mode on |

Example

```
ATE1
OK
```

2.2.17 AT&V Display current configuration

This command returns some of the base configuration parameters settings.

| AT&V Display current configuration | |
|--------------------------------------|--|
| Execution Command AT&V | Response <text> OK or ERROR |
| Reference V.25ter | |

Defined Values

| | |
|--------|---|
| <text> | All relative configuration information. |
|--------|---|

Example

```

AT&V
&C: 0; &D: 2; &F: 0; E: 1; L: 0; M: 0; Q:
0; V: 1; X: 0; Z: 0; S0: 0;
S3: 13; S4: 10; S5: 8; S6: 2; S7: 50; S8:
2; S9: 6; S10: 14; S11: 95;
+FCLASS: 0; +ICF: 3,3; +IFC: 2,2;
+IPR: 115200; +DR: 0; +DS: 0,0,2048,6;
+WS46: 12; +CBST: 0,0,1;
.....
OK

```

2.2.18 AT&D Set DTR function mode

This command determines how the TA responds when DTR PIN is changed from the ON to the OFF condition during data mode.

AT&D Set DTR function mode

| Execution Command | Response |
|--------------------------------|---------------------------------|
| AT&V[<value>] | OK or ERROR |

| | |
|-----------|---------|
| Reference | V.25ter |
|-----------|---------|

Defined Values

| | |
|---------|---|
| <value> | <u>0</u> TA ignores status on DTR. 1 ON->OFF on DTR: Change to Command mode with remaining the connected call 2 ON->OFF on DTR: Disconnect call, change to Command mode. During state DTR = OFF is auto-answer off. |
|---------|---|

Example

```

AT&D1

```

OK

2.2.19 AT&S Set DSR function mode

The command determines how the state of DSR pin works.

AT&D Set DSR function mode

| | |
|---|---|
| Execution Command AT&S[<value>] | Response OK or ERROR |
|---|---|

| |
|----------------------|
| Reference V.25ter |
|----------------------|

Defined Values

| | |
|---------|---|
| <value> | 0 DSR line shall always be on. |
| | 1 DSR line shall be on only when DTE and DCE are connected. |

Example

```
AT&S0
OK
```

2.2.20 ATV Set result code format mode

This parameter setting determines the contents of the header and trailer transmitted with result codes and information responses.

ATV Set result code format mode

| | |
|--|---|
| Write Command ATV[<value>] | Response If <value> =0 0 If <value> =1 OK |
|--|---|

| |
|----------------------|
| Reference V.25ter |
|----------------------|

Defined Values

| | |
|----------------------|--|
| <value> | <p>0 Information response: <text><CR><LF> Short result code format: <numeric code><CR></p> <p>1 Information response: <CR><LF><text><CR><LF> Long result code format: <CR><LF><verbose code><CR><LF></p> |
|----------------------|--|

Example

```
ATV1
OK
```

2.2.21 AT&F Set all current parameters to manufacturer defaults

This command is used to set all current parameters to the manufacturer defined profile.

AT&F Set all current parameters to manufacturer defaults

| | |
|---|---|
| Write Command AT&F[<value>] | Response OK or ERROR |
| Reference V.25ter | |

Defined Values

| | |
|----------------------|--|
| <value> | 0 — Set some temporary TA parameters to manufacturer defaults. The setting after power on or reset is same as value 0. |
|----------------------|--|

Example

```
AT&F
OK
```

2.2.22 ATQ Set Result Code Presentation Mode

Specify whether the TA transmits any result code to the TE or not. Text information transmitted in response is not affected by this setting.

ATQ Set Result Code Presentation Mode

| | |
|--------------------------------------|-----------------------|
| Write Command ATQ<n> | Response If <n>=0: |
|--------------------------------------|-----------------------|

| | |
|----------------------|----------------------------|
| | OK |
| | If <n>=1: No Responses |
| ATQ | Set default value: 0 OK |
| | No Responses |
| Reference V.25ter | |

Defined Values

| | |
|-----|--|
| <n> | 0 – DCE transmits result code 1 – DCE not transmits result code |
|-----|--|

Example

```
ATQ0
OK
```

2.2.23 ATX Set CONNECT Result Code Format

This parameter setting determines whether the TA transmits unsolicited result codes or not. The unsolicited result codes are

<CONNECT><SPEED><COMMUNICATION PROTOCOL>[<TEXT>]

| ATX Set CONNECT Result Code Format | |
|------------------------------------|---|
| Write Command ATX<n> | Response OK or ERROR |
| Execution Command ATX | Set default value: 1 OK or ERROR |
| Reference V.25ter | |

Defined Values

| | |
|---------|----------------------------------|
| <value> | 0 – CONNECT result code returned |
|---------|----------------------------------|

1,2,3,4 – May be transmits extern result codes according to AT&E and AT+V settings. Refer to AT&E.

Example

```
ATX1
OK
```

2.2.24 AT+V Set CONNECT Result Code Format About Protocol

This parameter setting determines whether report the communication protocol. If PS call, it also determines whether report APN, uplink rate, downlink rate.

| AT+V Set CONNECT Result Code Format About Protocol | |
|--|---|
| Write Command AT+V<value> | Response OK or ERROR |
| Execution Command AT+V | Set default value: 0 OK or ERROR |
| Reference V.25ter | |

Defined Values

| | |
|---------|--|
| <value> | 0 – Don't report 1 – Report communication protocol. And report APN, uplink rate, downlink rate if PS call. Refer to AT&E. The maybe communication protocol report include "NONE", "PPPOverUD", "AV32K", "AV64K", "PACKET". And APN in string format while uplink rate and downlink rate in integer format with kb unit. |
|---------|--|

Example

```
AT+V0
OK
```


2.2.25 AT&E Set CONNECT Result Code Format About Speed

This parameter setting determines to report Serial connection rate or Wireless connection speed. It is valid only ATX above 0.

| AT&E Set CONNECT Result Code Format About Speed | |
|---|---|
| Write Command AT&E<value> | Response OK or ERROR |
| Execution Command AT&E | Set default value: 1 OK or ERROR |
| Reference V.25ter | |

Defined Values

| | |
|----------------------|---|
| <value> | 0 – Wireless connection speed in integer format. |
| | 1 – Serial connection rate in integer format. Such as: “115200” |

Example

```
AT&E0  
OK
```

2.2.26 AT&W Save the user setting to ME

This command will save the user settings to ME which set by ATE, ATQ, ATV, ATX, AT&C AT&D, AT&S, ATV, AT+IFC and ATS0.

| AT&W Save the user setting to ME | |
|---|---|
| Write Command AT&W<value> | Response OK or ERROR |
| Execution Command AT&W | Set default value: 0 OK or ERROR |

Reference
V.25ter

Defined Values

<value> 0 – Save

Example

AT&W0
OK

2.2.27 ATZ Restore the user setting from ME

This command will restore the user setting from ME which set by ATE, ATQ, ATV, ATX, AT&C AT&D, AT&S, ATQ, ATV, and ATSO.

ATZ Restore the user setting from ME

| | |
|--|---|
| Write Command ATZ<value> | Response OK or ERROR |
| Execution Command ATZ | Set default value: 0 OK or ERROR |
| Reference V.25ter | |

Defined Values

<value> 0 – Restore

Example

ATZ0
OK

2.2.28 AT+CGMI Request manufacturer identification

This command is used to request the manufacturer identification text, which is intended to permit the user of the Module to identify the manufacturer.

| AT+CGMI Request manufacturer identification | |
|--|--|
| Test Command AT+CGMI=? | Response OK |
| Execution Command AT+CGMI | Response <manufacturer> OK or ERROR |
| Reference V.25ter | |

Defined Values

| | |
|-----------------------------|-------------------------------------|
| <manufacturer> | The identification of manufacturer. |
|-----------------------------|-------------------------------------|

Example

```
AT+CGMI
SIMCOM INCORPORATED
OK
```

2.2.29 AT+CGMM Request model identification

This command is used to requests model identification text, which is intended to permit the user of the Module to identify the specific model.

| AT+CGMM Request model identification | |
|---|---|
| Test Command AT+CGMM=? | Response OK |
| Execution Command AT+CGMM | Response <model> OK or ERROR |
| Reference V.25ter | |

Defined Values

<model> The identification of model.

Example

```
AT+CGMM
SIMCOM_SIM7600C
OK
```

2.2.30 AT+CGMR Request revision identification

This command is used to request product firmware revision identification text, which is intended to permit the user of the Module to identify the version.

| AT+CGMR Request revision identification | |
|---|---|
| Test Command AT+CGMR=? | Response OK |
| Execution Command AT+CGMR | Response +CGMR: <revision> OK or ERROR |
| Reference V.25ter | |

Defined Values

<revision> The revision identification of firmware.

Example

```
AT+CGMR
+CGMR: LE11B01SIM7600C
OK
```

2.2.31 AT+CGSN Request product serial number identification

This command requests product serial number identification text, which is intended to permit the user of the Module to identify the individual ME to which it is connected to.

AT+CGSN Request product serial number identification

| | |
|-------------------------------------|---|
| Test Command AT+CGSN=? | Response OK |
| Execution Command AT+CGSN | Response <sn> OK or +CME ERROR: memory failure |
| Reference V.25ter | |

Defined Values

| | |
|-------------------|---|
| <sn> | Serial number identification, which consists of a single line containing the IMEI (International Mobile station Equipment Identity) number of the MT. If in CDMA/EVDO mode ,it will show ESN(Electronic Serial Number) |
|-------------------|---|

Example

```
AT+CGSN
351602000330570
OK
```

2.2.32 AT+CSCS Select TE character set

Write command informs TA which character set **<chest>** is used by the TE. TA is then able to convert character strings correctly between TE and MT character sets.

Read command shows current setting and test command displays conversion schemes implemented in the TA.

AT+CSCS Select TE character set

| | |
|---|---|
| Test Command AT+CSCS=? | Response +CSCS: (list of supported <chset>s) OK |
| Read Command AT+CSCS? | Response +CSCS: <chset> OK |
| Write Command AT+CSCS=<chset> | Response OK ERROR |

| | |
|-------------------------------------|--|
| Execution Command AT+CSCS | Set subparameters as default value: OK |
| Reference V.25ter | |

Defined Values

| | |
|----------------------|--|
| <chset> | Character set, the definition as following: “IRA” International reference alphabet. “GSM” GSM default alphabet; this setting causes easily software flow control (XON /XOFF) problems. “UCS2” 16-bit universal multiple-octet coded character set; UCS2 character strings are converted to hexadecimal numbers from 0000 to FFFF. |
|----------------------|--|

Example

```
AT+CSCS="IRA"
OK
```

2.2.33 AT+CIMI Request international mobile subscriber identity

Execution command causes the TA to return **<IMSI>**, which is intended to permit the TE to identify the individual SIM card which is attached to MT.

NOTE: If USIM card contains two apps, like China Telecom 4G card, one RUIM/CSIM app, and another USIM app; so there are two IMSI in it; AT+CIMI will return the RUIM/CSIM IMSI; AT+CIMIM will return the USIM IMSI.

| AT+CIMI Request international mobile subscriber identity | |
|---|---|
| Test Command AT+CIMI=? | Response OK |
| Execution Command AT+CIMI | Response <IMSI> OK or +CME ERROR: memory failure |
| Reference V.25ter | |

Defined Values

| | |
|---------------------|--|
| <IMSI> | International Mobile Subscriber Identity (string, without double |
|---------------------|--|

quotes).

Example

```
AT+CIMI
460010222028133
OK
```

2.2.34 AT+CIMIM Request another international mobile subscriber identity

Execution command causes the TA to return **<IMSI>**, which is intended to permit the TE to identify the individual SIM card which is attached to MT.

NOTE: If USIM card contains two apps, like China Telecom 4G card, one RUIIM/CSIM app, and another USIM app; so there are two IMSI in it; AT+CIMIM will return the USIM IMSI; AT+CIMI will return the RUIIM/CSIM IMSI.

AT+CIMIM Request another international mobile subscriber identity

| | |
|--------------------------------------|---|
| Test Command AT+CIMIM=? | Response OK |
| Execution Command AT+CIMIM | Response <IMSI> OK or +CME ERROR: memory failure |
| Reference V.25ter | |

Defined Values

| | |
|---------------------|---|
| <IMSI> | International Mobile Subscriber Identity (string, without double quotes). |
|---------------------|---|

Example

```
AT+CIMIM
460010222028133
OK
```

2.2.35 AT+GCAP Request overall capabilities

Execution command causes the TA reports a list of additional capabilities.

| AT+GCAP Request overall capabilities | |
|---|--|
| Test Command AT+GCAP=? | Response OK |
| Execution Command AT+GCAP | Response +GCAP: (list of <name>s) OK |
| Reference V.25ter | |

Defined Values

| <name> | List of additional capabilities. |
|-----------|-------------------------------------|
| +CGSM | GSM function is supported |
| +FCLASS | FAX function is supported |
| +DS | Data compression is supported |
| +ES | Synchronous data mode is supported. |
| +CIS707-A | CDMA data service command set |
| +CIS-856 | EVDO data service command set |
| +MS | Mobile Specific command set |

Example

```

AT+GCAP
+GCAP:+CGSM,+FCLASS,+DS
OK
  
```


3. AT Commands for Status Control

3.1 Overview of AT Commands for Status Control

| Command | Description |
|-------------|-------------------------------------|
| AT+CFUN | Set phone functionality |
| AT+CPIN | Enter PIN |
| AT+CICCID | Read ICCID from SIM card |
| AT+CSIM | Generic SIM access |
| AT+CRSM | Restricted SIM access |
| AT+SPIC | Times remain to input SIM PIN/PUK |
| AT+CSPN | Get service provider name from SIM |
| AT+CSQ | Query signal quality |
| AT+AUTOCSQ | Set CSQ report |
| AT+CSQDELTA | Set RSSI delta change threshold |
| AT+CATR | Configure URC destination interface |
| AT+CPOF | Power down the module |
| AT+CRESET | Reset the module |
| AT+CACM | Accumulated call meter |
| AT+CAMM | Accumulated call meter maximum |
| AT+CPUC | Price per unit and currency table |
| AT+CCLK | Real time clock management |
| AT+CMEE | Report mobile equipment error |
| AT+CPAS | Phone activity status |
| AT+SIMEI | Set IMEI for the module |
| AT+SMEID | Request Mobile Equipment Identifier |
| AT+CSVM | Voice Mail Subscriber number |

3.2 Detailed Description of AT Commands for Status Control

3.2.1 AT+CFUN Set phone functionality

Description

This command is used to select the level of functionality `<fun>` in the ME. Level "full functionality" is where the highest level of power is drawn. "Minimum functionality" is where minimum power is drawn. Level of functionality between these may also be specified by manufacturers. When supported by manufacturers, ME resetting with `<rst>` parameter may be utilized.

NOTE: `AT+CFUN=6` must be used after setting `AT+CFUN=7`. If module in offline mode, must execute `AT+CFUN=6` or **restart** module to online mode.

| AT+CFUN Set phone functionality | |
|---|--|
| Test Command AT+CFUN=? | Response +CFUN: (list of supported <fun>s),(list of supported <rst>s) OK or ERROR or +CME ERROR: <err> |
| Read Command AT+CFUN? | Response +CFUN: <fun> OK or ERROR or +CME ERROR: <err> |
| Write Command AT+CFUN=<fun>[,<rst>] | Response OK or ERROR or +CME ERROR: <err> |

Defined values

| | |
|--------------------------|--|
| <code><fun></code> | 0 – minimum functionality 1 – full functionality, online mode 4 – disable phone both transmit and receive RF circuits 5 – Factory Test Mode |
|--------------------------|--|

| | |
|-------|--|
| | 6 – Reset |
| | 7 – Offline Mode |
| <rst> | 0 – do not reset the ME before setting it to <fun> power level |
| | 1 – reset the ME before setting it to <fun> power level. This value only takes effect when <fun> equals 1. |

Examples

```

AT+CFUN?
+CFUN: 1

OK
AT+CFUN=0
OK

```

3.2.2 AT+CPIN Enter PIN

Description

This command is used to send the ME a password which is necessary before it can be operated (SIM PIN, SIM PUK, PH-SIM PIN, etc.). If the PIN is to be entered twice, the TA shall automatically repeat the PIN. If no PIN request is pending, no action is taken towards MT and an error message, **+CME ERROR**, is returned to TE.

If the PIN required is SIM PUK or SIM PUK2, the second pin is required. This second pin, **<newpin>**, is used to replace the old pin in the SIM.

| AT+CPIN Enter PIN | |
|----------------------------------|--|
| Test Command AT+CPIN=? | Response OK |
| Read Command AT+CPIN? | Response +CPIN: <code> |
| | OK |
| | or |
| | ERROR |
| | or |
| | +CME ERROR: <err> |

| | |
|--|---|
| Write Command AT+CPIN=<pin>[,<newpin>] | Response OK or ERROR or +CME ERROR: <err> |
|--|---|

Defined values

| | |
|-----------------------|--|
| <pin> | String type values. |
| <newpin> | String type values. |
| <code> | <p>Values reserved by the present document:</p> <ul style="list-style-type: none"> READY – ME is not pending for any password SIM PIN – ME is waiting SIM PIN to be given SIM PUK – ME is waiting SIM PUK to be given PH-SIM PIN – ME is waiting phone- to- SIM card password to be given SIM PIN2 – ME is waiting SIM PIN2 to be given SIM PUK2 – ME is waiting SIM PUK2 to be given PH-NET PIN – ME is waiting network personalization password to be given |

Examples

```
AT+CPIN?
+CPIN: SIM PUK2

OK
```

3.2.3 AT+CICCID Read ICCID from SIM card

Description

This command is used to Read the ICCID from SIM card

AT+CICCID Read ICCID from SIM card

| | |
|------------------------------------|-----------------------|
| Test Command AT+CICCID=? | Response OK |
|------------------------------------|-----------------------|

| | |
|---------------------------------------|---|
| Execution Command AT+CICCID | Response +ICCID: <ICCID> OK or ERROR or +CME ERROR: <err> |
|---------------------------------------|---|

Defined values

| | |
|----------------------|--|
| <ICCID> | Integrate circuit card identity, a standard ICCID is a 20-digit serial number of the SIM card, it presents the publish state, network code, publish area, publish date, publish manufacture and press serial number of the SIM card. |
|----------------------|--|

Examples

| |
|--|
| AT+CICCID +ICCID: 898600700907A6019125 OK |
|--|

3.2.4 AT+CSIM Generic SIM access

Description

This command is used to control the SIM card directly.

Compared to restricted SIM access command AT+CRSM, AT+CSIM allows the ME to take more control over the SIM interface.

For SIM-ME interface please refer 3GPP TS 11.11.

NOTE: The SIM Application Toolkit functionality is not supported by AT+CSIM. Therefore the following SIM commands can not be used: TERMINAL PROFILE, ENVELOPE, FETCH and TEMINAL RESPONSE.

| AT+CSIM Generic SIM access | |
|-----------------------------------|-----------------------|
| Test Command AT+CSIM=? | Response OK |

| | |
|--|--|
| Write Command AT+CSIM=<length>,<command> | Response +CSIM: <length>,<response> OK or ERROR or +CME ERROR: <err> |
|--|--|

Defined values

| | |
|-------------------------|---|
| <length> | Integer type; length of characters that are sent to TE in <command>or<response> |
| <command> | Command passed from MT to SIM card. |
| <response> | Response to the command passed from SIM card to MT. |

Examples

```
AT+CSIM=?  
OK
```

3.2.5 AT+CRSM Restricted SIM access

Description

By using AT+CRSM instead of Generic SIM Access AT+CSIM, TE application has easier but more limited access to the SIM database.

Write command transmits to the MT the SIM <command> and its required parameters. MT handles internally all SIM-MT interface locking and file selection routines. As response to the command, MT sends the actual SIM information parameters and response data. MT error result code **+CME ERROR** may be returned when the command cannot be passed to the SIM, but failure in the execution of the command in the SIM is reported in <sw1> and <sw2> parameters.

AT+CRSM Restricted SIM access

| | |
|----------------------------------|-----------------------|
| Test Command AT+CRSM=? | Response OK |
|----------------------------------|-----------------------|

Write Command

AT+CRSM=<command>[,<fileID>[,<p1>,<p2>,<p3>[,<data>]]]

Response

+CRSM: <sw1>,<sw2>[,<response>]

OK

or

ERROR

or

+CME ERROR: <err>

Defined values

| | |
|-------------------------------|---|
| <p><command></p> | <p>Command passed on by the MT to the SIM:</p> <ul style="list-style-type: none"> 176 – READ BINARY 178 – READ RECORD 192 – GET RESPONSE 214 – UPDATE BINARY 220 – UPDATE RECORD 242 – STATUS 203 – RETRIEVE DATA 219 – SET DATA |
| <p><fileID></p> | <p>Identifier for an elementary data file on SIM, if used by <command>.</p> <p>The following list the fileID hex value, user needs to convert them to decimal.</p> <p>EFs under MF</p> <ul style="list-style-type: none"> 0x2FE2 ICCID 0x2F05 Extended Language Preferences 0x2F00 EF DIR 0x2F06 Access Rule Reference <p>EFs under USIM ADF</p> <ul style="list-style-type: none"> 0x6F05 Language Indication 0x6F07 IMSI 0x6F08 Ciphering and Integrity keys 0x6F09 C and I keys for pkt switched domain 0x6F60 User controlled PLMN selector w/Acc Tech 0x6F30 User controlled PLMN selector 0x6F31 HPLMN search period 0x6F37 ACM maximum value 0x6F38 USIM Service table 0x6F39 Accumulated Call meter 0x6F3E Group Identifier Level 0x6F3F Group Identifier Level 2 0x6F46 Service Provider Name 0x6F41 Price Per Unit and Currency table |

| | |
|---------|---------------------------------------|
| 0x6F45 | Cell Bcast Msg identifier selection |
| 0x6F78 | Access control class |
| 0x6F7B | Forbidden PLMNs |
| 0x6F7E | Location information |
| 0x6FAD | Administrative data |
| 0x6F48 | Cell Bcast msg id for data download |
| 0x6FB7 | Emergency call codes |
| 0x6F50 | Cell bcast msg id range selection |
| 0x6F73 | Packet switched location information |
| 0x6F3B | Fixed dialling numbers |
| 0x6F3C | Short messages |
| 0x6F40 | MSISDN |
| 0x6F42 | SMS parameters |
| 0x6F43 | SMS Status |
| 0x6F49 | Service dialling numbers |
| 0x6F4B | Extension 2 |
| 0x6F4C | Extension 3 |
| 0x6F47 | SMS reports |
| 0x6F80 | Incoming call information |
| 0x6F81 | Outgoing call information |
| 0x6F82 | Incoming call timer |
| 0x6F83 | Outgoing call timer |
| 0x6F4E | Extension 5 |
| 0x6F4F | Capability Config Parameters 2 |
| 0x6FB5 | Enh Multi Level Precedence and Pri |
| 0x6FB6 | Automatic answer for eMLPP service |
| 0x6FC2 | Group identity |
| 0x6FC3 | Key for hidden phonebook entries |
| 0x6F4D | Barred dialling numbers |
| 0x6F55 | Extension 4 |
| 0x6F58 | Comparison Method information |
| 0x6F56 | Enabled services table |
| 0x6F57 | Access Point Name Control List |
| 0x6F2C | De-personalization Control Keys |
| 0x6F32 | Co-operative network list |
| 0x6F5B | Hyperframe number |
| 0x6F5C | Maximum value of Hyperframe number |
| 0x6F61 | OPLMN selector with access tech |
| 0x6F5D | OPLMN selector |
| 0x6F62 | HPLMN selector with access technology |
| 0x6F06 | Access Rule reference |
| 0x6F65 | RPLMN last used access tech |
| 0x6FC4 | Network Parameters |
| 0x6F11 | CPHS: Voice Mail Waiting Indicator |
| 0x6F12, | CPHS: Service String Table |
| 0x6F13 | CPHS: Call Forwarding Flag |

| | |
|--------|--------------------------------------|
| 0x6F14 | CPHS: Operator Name String |
| 0x6F15 | CPHS: Customer Service Profile |
| 0x6F16 | CPHS: CPHS Information |
| 0x6F17 | CPHS: Mailbox Number |
| 0x6FC5 | PLMN Network Name |
| 0x6FC6 | Operator PLMN List |
| 0x6F9F | Dynamic Flags Status |
| 0x6F92 | Dynamic2 Flag Setting |
| 0x6F98 | Customer Service Profile Line2 |
| 0x6F9B | EF PARAMS - Welcome Message |
| 0x4F30 | Phone book reference file |
| 0x4F22 | Phone book synchronization center |
| 0x4F23 | Change counter |
| 0x4F24 | Previous Unique Identifier |
| 0x4F20 | GSM ciphering key Kc |
| 0x4F52 | GPRS ciphering key |
| 0x4F63 | CPBCCH information |
| 0x4F64 | Investigation scan |
| 0x4F40 | MExE Service table |
| 0x4F41 | Operator Root Public Key |
| 0x4F42 | Administrator Root Public Key |
| 0x4F43 | Third party Root public key |
| 0x6FC7 | Mail Box Dialing Number |
| 0x6FC8 | Extension 6 |
| 0x6FC9 | Mailbox Identifier |
| 0x6FCA | Message Waiting Indication Status |
| 0x6FCD | Service Provider Display Information |
| 0x6FD2 | UIM_USIM_SPT_TABLE |
| 0x6FD9 | Equivalent HPLMN |
| 0x6FCB | Call Forwarding Indicator Status |
| 0x6FD6 | GBA Bootstrapping parameters |
| 0x6FDA | GBA NAF List |
| 0x6FD7 | MBMS Service Key |
| 0x6FD8 | MBMS User Key |
| 0x6FCE | MMS Notification |
| 0x6FD0 | MMS Issuer connectivity parameters |
| 0x6FD1 | MMS User Preferences |
| 0x6FD2 | MMS User connectivity parameters |
| 0x6FCF | Extension 8 |
| 0x5031 | Object Directory File |
| 0x5032 | Token Information File |
| 0x5033 | Unused space Information File |
| | EFs under Telecom DF |
| 0x6F3A | Abbreviated Dialing Numbers |
| 0x6F3B | Fixed dialling numbers |
| 0x6F3C | Short messages |

| | |
|--------------|--|
| 0x6F3D | Capability Configuration Parameters |
| 0x6F4F | Extended CCP |
| 0x6F40 | MSISDN |
| 0x6F42 | SMS parameters |
| 0x6F43 | SMS Status |
| 0x6F44 | Last number dialled |
| 0x6F49 | Service Dialling numbers |
| 0x6F4A | Extension 1 |
| 0x6F4B | Extension 2 |
| 0x6F4C | Extension 3 |
| 0x6F4D | Barred Dialing Numbers |
| 0x6F4E | Extension 4 |
| 0x6F47 | SMS reports |
| 0x6F58 | Comparison Method Information |
| 0x6F54 | Setup Menu elements |
| 0x6F06 | Access Rule reference |
| 0x4F20 | Image |
| 0x4F30 | Phone book reference file |
| 0x4F22 | Phone book synchronization center |
| 0x4F23 | Change counter |
| 0x4F24 | Previous Unique Identifier |
| <p1><p2><p3> | Integer type; parameters to be passed on by the Module to the SIM. |
| <data> | Information which shall be written to the SIM (hexadecimal character format, refer AT+CSCS). |
| <sw1><sw2> | Status information from the SIM about the execution of the actual command. It is returned in both cases, on successful or failed execution of the command. |
| <response> | Response data in case of a successful completion of the previously issued command. "STATUS" and "GET RESPONSE" commands return data, which gives information about the currently selected elementary data field. This information includes the type of file and its size. After "READ BINARY" or "READ RECORD" commands the requested data will be returned. <response> is empty after "UPDATE BINARY" or "UPDATE RECORD" commands. |

Examples

AT+CRSM=?

OK

3.2.6 AT+SPIC Times remain to input SIM PIN/PUK

Description

This command is used to inquire times remain to input SIM PIN/PUK.

| AT+SPIC Times remain to input SIM PIN/PUK | |
|---|--|
| Test Command AT+SPIC=? | Response OK |
| Execution Command AT+SPIC | Response +SPIC: <pin1>,<puk1>,<pin2>,<puk2> OK |

Defined values

| | |
|--------|----------------------------------|
| <pin1> | Times remain to input PIN1 code. |
| <puk1> | Times remain to input PUK1 code. |
| <pin2> | Times remain to input PIN2 code. |
| <puk2> | Times remain to input PUK2 code. |

Examples

```
AT+SPIC=?
OK
AT+SPIC
+SPIC: 3,10,0,10
OK
```

3.2.7 AT+CSPN Get service provider name from SIM

Description

This command is used to get service provider name from SIM card.

AT+CSPN Get service provider name from SIM

| | |
|----------------------------------|---|
| Test Command AT+CSPN=? | Response OK or ERROR |
| Read Command AT+CSPN? | Response +CSPN: <spn>,<display mode> OK or ERROR or +CME ERROR: <err> |

Defined values

| | |
|-----------------------------|---|
| <spn> | String type; service provider name on SIM |
| <display mode> | 0 – doesn't display PLMN. Already registered on PLMN. 1 – display PLMN |

Examples

```
AT+CSPN=?
OK
AT+CSPN?
+CSPN: "CMCC",0
OK
```

3.2.8 AT+CSQ Query signal quality

Description

This command is used to return received signal strength indication <rssi> and channel bit error rate <ber> from the ME. Test command returns values supported by the TA as compound values.

AT+CSQ Query signal quality

| | |
|------------------------------------|---|
| Test Command AT+CSQ=? | Response +CSQ: (list of supported <rssis>),(list of supported <ber>s) |
| | OK |
| Execution Command AT+CSQ | Response +CSQ: <rssis>,<ber> |
| | OK or ERROR |

Defined values

| | |
|----------------------|---|
| <rssis> | 0 – -113 dBm or less |
| | 1 – -111 dBm |
| | 2...30 – -109... -53 dBm |
| | 31 – -51 dBm or greater |
| | 99 – not known or not detectable |
| | 100 – -116 dBm or less |
| | 101 – -115 dBm |
| | 102...191 – -114... -26dBm |
| | 191 – -25 dBm or greater |
| | 199 – not known or not detectable |
| | 100...199 – expand to TDSCDMA, indicate RSCP received |
| <ber> | (in percent) |
| | 0 – <0.01% |
| | 1 – 0.01% --- 0.1% |
| | 2 – 0.1% --- 0.5% |
| | 3 – 0.5% --- 1.0% |
| | 4 – 1.0% --- 2.0% |
| | 5 – 2.0% --- 4.0% |
| | 6 – 4.0% --- 8.0% |
| | 7 – >=8.0% |
| | 99 – not known or not detectable |

Examples

```
AT+CSQ
+CSQ: 22,0

OK
```

3.2.9 AT+AUTOCSQ Set CSQ report

Description

This command is used to enable or disable automatic report CSQ information, when automatic report enabled, the module reports CSQ information every five seconds or only after <rsssi>or<ber> is changed, the format of automatic report is "+CSQ: <rsssi>,<ber>".

| AT+AUTOCSQ Set CSQ report | |
|--|---|
| Test Command AT+AUTOCSQ=? | Response +AUTOCSQ: (list of supported<auto>s),(list of supported<mode>s) OK |
| Read Command AT+AUTOCSQ? | Response +AUTOCSQ: <auto>,<mode> OK |
| Write Command AT+AUTOCSQ=<auto>[,<mode>] | Response OK or ERROR |

Defined values

| | |
|--------|--|
| <auto> | 0 – disable automatic report 1 – enable automatic report |
| <mode> | 0 – CSQ automatic report every five seconds 1 – CSQ automatic report only after <rsssi>or<ber>is changed NOTE: If the parameter of <mode> is omitted when executing write command, <mode> will be set to default value. |

Examples

```
AT+AUTOCSQ=?
+AUTOCSQ: (0-1),(0-1)

OK
AT+AUTOCSQ?
```

+AUTOCSQ: 1,1

OK

AT+AUTOCSQ=1,1

OK

+CSQ: 23,0 (when <rssi>or<ber>changing)

3.2.10 AT+CSQDELTA Set RSSI delta change threshold

Description

This command is used to set RSSI delta threshold for signal strength reporting.

AT+CSQDELTA Set RSSI delta change threshold

| | |
|---|--|
| Test Command AT+CSQDELTA=? | Response +CSQDELTA: (list of supported <delta>s) OK |
| Read Command AT+CSQDELTA? | Response +CSQDELTA: <delta> OK or ERROR |
| Write Command AT+CSQDELTA=<delta> | Response OK or ERROR |
| Execution Command AT+CSQDELTA | Response Set default value (<delta>=5) : OK |

Defined values

| | |
|---------|---------------------|
| <delta> | Range: from 0 to 5. |
|---------|---------------------|

Examples

AT+CSQDELTA?

+CSQDELTA: 5

OK

3.2.11 AT+CATR Configure URC destination interface

Description

This command is used to configure the serial port which will be used to output URCs. We recommend configure a destination port for receiving URC in the system initialization phase, in particular, in the case that transmitting large amounts of data, e.g. use TCP/UDP and MT SMS related AT command.

AT+CATR Configure URC destination interface

| | |
|--|--|
| Test Command AT+CATR=? | Response +CATR: (list of supported <port>s) OK |
| Read Command AT+CATR? | Response +CATR: <port> OK |
| Write Command AT+CATR=<port> | Response OK or ERROR |

Defined values

| | |
|---------------------|--|
| <port> | <ul style="list-style-type: none"> <u>0</u> – all ports 1 – use UART port to output URCs 2 – use MODEM port to output URCs 3 – use ATCOM port to output URCs 4 – use cmux virtual port1 to output URCs 5 – use cmux virtual port2 to output URCs 6 – use cmux virtual port3 to output URCs 7 – use cmux virtual port4 to output URCs |
|---------------------|--|

Examples

```
AT+CATR=1
OK
AT+CATR?
+CATR: 1
OK
```

3.2.12 AT+CPOF Power down the module

Description

This command is used to power off the module. Once the AT+CPOF command is executed, The module will store user data and deactivate from network, and then shutdown.

AT+CPOF Power down the module

| | |
|-------------------|-----------|
| Test Command | Response |
| AT+CPOF=? | OK |
| Execution Command | Response |
| AT+CPOF | OK |

Examples

```
AT+CPOF
OK
```

3.2.13 AT+CRESET Reset the module

Description

This command is used to reset the module.

AT+CRESET Reset the module

| | |
|--------------------|-----------|
| Test Command | Response |
| AT+CRESET=? | OK |

| | |
|---------------------------------------|-----------------------|
| Execution Command AT+CRESET | Response OK |
|---------------------------------------|-----------------------|

Examples

```
AT+CRESET=?
OK
AT+CRESET
OK
```

3.2.14 AT+CACM Accumulated call meter

Description

This command is used to reset the Advice of Charge related accumulated call meter value in SIM file EF_{ACM}.

AT+CACM Accumulated call meter

| | |
|--|--|
| Test Command AT+CACM=? | Response OK or ERROR |
| Read Command AT+CACM? | Response +CACM: <acm> OK or ERROR or +CME ERROR: <err> |
| Write Command AT+CACM=<passwd> | Response OK or ERROR or +CME ERROR: <err> |

| | |
|-------------------------------------|---|
| Execution Command AT+CACM | Response OK or ERROR or +CME ERROR: <err> |
|-------------------------------------|---|

Defined values

| | |
|----------|---|
| <passwd> | String type, SIM PIN2. |
| <acm> | String type, accumulated call meter value similarly coded as <ccm> under +CAOC. |

Examples

```
AT+CACM?
+CACM: "000000"

OK
```

3.2.15 AT+CAMM Accumulated call meter maximum

Description

This command is used to set the Advice of Charge related accumulated call meter maximum value in SIM file EF_{ACMmax}.

AT+CAMM Accumulated call meter maximum

| | |
|----------------------------------|---|
| Test Command AT+CAMM=? | Response OK or ERROR |
|----------------------------------|---|

| | |
|---|---|
| <p>Read Command AT+CAMM?</p> | <p>Response +CAMM: <acmmax></p> <p>OK or ERROR or +CME ERROR: <err></p> |
| <p>Write Command AT+CAMM=<acmmax>[,<passwd>]</p> | <p>Response OK or ERROR or +CME ERROR: <err></p> |
| <p>Execution Command AT+CAMM</p> | <p>Response OK or ERROR or +CME ERROR: <err></p> |

Defined values

| | |
|-----------------------|---|
| <acmmax> | String type, accumulated call meter maximum value similarly coded as <ccm> under AT+CAOC, value zero disables ACMmax feature. |
| <passwd> | String type, SIM PIN2. |

Examples

```
AT+CAMM?
+CAMM: "000000"

OK
```

3.2.16 AT+CPUC Price per unit and currency table

Description

This command is used to set the parameters of Advice of Charge related price per unit and currency table in SIM file EF_{PUCT}.

| AT+CPUC Price per unit and currency table | |
|--|---|
| Test Command AT+CPUC=? | Response OK or ERROR |
| Read Command AT+CPUC? | Response +CPUC: [<currency>,<ppu>] OK or ERROR or +CME ERROR: <err> |
| Write Command AT+CPUC=<currency>,<ppu> >[,<passwd>] | Response OK or ERROR or +CME ERROR: <err> |

Defined values

| | |
|-------------------------|--|
| <currency> | String type, three-character currency code (e.g. "GBP", "DEM"), character set as specified by command Select TE Character Set AT+CSCS. |
| <ppu> | String type, price per unit, dot is used as a decimal separator. (e.g. "2.66"). |
| <passwd> | String type, SIM PIN2. |

Examples

```
AT+CPUC?
+CPUC: "GBP", "2.66"

OK
```

3.2.17 AT+CCLK Real time clock management

Description

This command is used to manage Real Time Clock of the module.

| AT+CCLK Real time clock management | |
|--|---|
| Test Command AT+CCLK=? | Response OK |
| Read Command AT+CCLK? | Response +CCLK: <time> |
| Write Command AT+CCLK=<time> | Response OK or ERROR |

Defined values

| | |
|---------------------|---|
| <time> | String type value; format is "yy/MM/dd,hh:mm:ss±zz", where characters indicate year (two last digits), month, day, hour, minutes, seconds and time zone (indicates the difference, expressed in quarters of an hour, between the local time and GMT; three last digits are mandatory, range -47...+48). E.g. 6 th of May 2008, 14:28:10 GMT+8 equals to "08/05/06,14:28:10+32". NOTE: 1. Time zone is nonvolatile, and the factory value is invalid time zone. 2. Command +CCLK? will return time zone when time zone is valid, and if time zone is 00, command +CCLK? will return "+00", but not "-00". |
|---------------------|---|

Examples

```
AT+CCLK="08/11/28,12:30:33+32"
OK
AT+CCLK?
+CCLK: "08/11/28,12:30:35+32"
```

```

OK
AT+CCLK="08/11/26,10:15:00"
OK
AT+CCLK?
+CCLK: "08/11/26,10:15:02+32"
OK

```

3.2.18 AT+CMEE Report mobile equipment error

Description

This command is used to disable or enable the use of result code “**+CME ERROR: <err>**” or “**+CMS ERROR: <err>**” as an indication of an error relating to the functionality of ME; when enabled, the format of <err> can be set to numeric or verbose string.

AT+CMEE Report mobile equipment error

| | |
|---|---|
| Test Command AT+CMEE=? | Response +CMEE: (list of supported <n>s) OK |
| Read Command AT+CMEE? | Response +CMEE: <n> OK |
| Write Command AT+CMEE=<n> | Response OK or ERROR |
| Execution Command AT+CMEE | Response Set default value: OK |

Defined values

| | |
|-----|--|
| <n> | 0 –Disable result code, i.e. only “ ERROR ” will be displayed. 1 –Enable error result code with numeric values. 2 –Enable error result code with string values. |
|-----|--|

Examples

```

AT+CMEE?
+CMEE: 2

OK
AT+CPIN="1234","1234"
+CME ERROR: incorrect password
AT+CMEE=0

OK
AT+CPIN="1234","1234"
ERROR
AT+CMEE=1

OK
AT+CPIN="1234","1234"
+CME ERROR: 16

```

3.2.19 AT+CPAS Phone activity status

Description

This command is used to return the activity status <pas> of the ME. It can be used to interrogate the ME before requesting action from the phone.

NOTE: This command is same as AT+CLCC, but AT+CLCC is more commonly used. So AT+CLCC is recommended to use.

AT+CPAS Phone activity status

| | |
|-------------------------------------|--|
| Test Command AT+CPAS=? | Response +CPAS: (list of supported <pas>s) |
| | OK |
| Execution Command AT+CPAS | Response +CPAS: <pas> |
| | OK |

Defined values

<pas>

- 0 – ready (ME allows commands from TA/TE)
- 3 – ringing (ME is ready for commands from TA/TE, but the ringer is active)
- 4 – call in progress (ME is ready for commands from TA/TE, but a call is in progress)

Examples

RING (with incoming call)

AT+CPAS

+CPAS: 3

OK

AT+CPAS=?

+CPAS: (0,3,4)

OK

3.2.20 AT+SIMEI Set IMEI for the module

Description

This command is used to set the module's IMEI value.

AT+SIMEI Set IMEI for the module

| | |
|---|--|
| Test Command AT+SIMEI=? | Response OK |
| Read Command AT+SIMEI? | Response +SIMEI: <imei> OK or ERROR |
| Write Command AT+SIMEI=<imei> | Response OK or ERROR |

Defined values

| | |
|--------|--------------------------|
| <imei> | The 15-digit IMEI value. |
|--------|--------------------------|

Examples

```
AT+SIMEI=357396012183170
```

```
OK
```

```
AT+SIMEI?
```

```
+SIMEI:357396012183170
```

```
OK
```

```
AT+SIMEI=?
```

```
OK
```

3.2.21 AT+SMEID RequestMobile Equipment Identifier

Description

Only task effect in 7600CE

AT+SMEID RequestMobile Equipment Identifier

Read Command

```
AT+SMEID?
```

Responses

```
+SMEID: <MEID>
```

```
OK
```

```
or
```

```
ERROR
```

Defined values

| | |
|--------|--|
| <MEID> | Mobile Equipment Identifier (string, without double quotes). |
|--------|--|

Examples

```
AT+SMEID?
```

```
+SMEID: A1000021A5906F
```

OK

3.2.22 AT+CSVM Voice Mail Subscriber number

Description

Execution command returns the voice mail number related to the subscriber.

| AT+CSVM Voice Mail Subscriber number | |
|---|--|
| Test Command AT+CSVM=? | Response +CSVM: (0-1), "(0-9,+)", (128-255) OK or ERROR |
| Read Command AT+CSVM? | Response +CSVM: <valid>, "<number>", <type> OK or ERROR |
| Write Command AT+CSVM=<valid>, "<number>", <type> | Response OK or ERROR |

Defined values

| | |
|-----------------------|---|
| <valid> | Whether voice mail number is valid: 0 – Voice mail number is invalid. 1 – Voice mail number is valid. |
| <number> | String type phone number of format specified by <type>. |
| <type> | Type of address octet in integer format. see also AT+CPBR <type> |

Examples

AT+CSVM?

+CSVM: 1 ,"13697252277",129

OK

3.2.23 Indication of Voice Mail

This module supports voice mail function; the subscriber number is configured by AT+CSVM command, the following table shows the URC related Voice Mail.

| Indication of Voice Mail | |
|--|---|
| Box Empty +VOICEMAIL: EMPTY | Description This indication means the voice mail box is empty |
| New Message +VOICEMAIL: NEW MSG | Description This indication means there is a new voice mail message notification received. This is for CPHS. |
| Voice Mail Status Updated +VOICEMAIL: WAITING, <count> | Description This indication means that there are <count> number of voice mail messages that needs to be got. |

Defined values

| | |
|---------|---|
| <count> | Count of voice mail message that waits to be got. |
|---------|---|

Examples

+VOICEMAIL: WAITING, <count>
+VOICEMAIL: WAITING, 5

3.3 Summary of CME ERROR codes

This result code is similar to the regular ERROR result code. The format of <err> can be either numeric or verbose string, by setting AT+CMEE command.

<err> of numeric format <err> of verbose format

| | |
|-----|---|
| 0 | Phone failure |
| 1 | no connection to phone |
| 2 | phone adaptor link reserved |
| 3 | operation not allowed |
| 4 | operation not supported |
| 5 | PH-SIM PIN required |
| 6 | PH-FSIM PIN required |
| 7 | PH-FSIM PUK required |
| 10 | SIM not inserted |
| 11 | SIM PIN required |
| 12 | SIM PUK required |
| 13 | SIM failure |
| 14 | SIM busy |
| 15 | SIM wrong |
| 16 | incorrect password |
| 17 | SIM PIN2 required |
| 18 | SIM PUK2 required |
| 20 | memory full |
| 21 | invalid index |
| 22 | not found |
| 23 | memory failure |
| 24 | text string too long |
| 25 | invalid characters in text string |
| 26 | dial string too long |
| 27 | invalid characters in dial string |
| 30 | no network service |
| 31 | network timeout |
| 32 | network not allowed – emergency calls only |
| 40 | network personalization PIN required |
| 41 | network personalization PUK required |
| 42 | network subset personalization PIN required |
| 43 | network subset personalization PUK required |
| 44 | service provider personalization PIN required |
| 45 | service provider personalization PUK required |
| 46 | corporate personalization PIN required |
| 47 | corporate personalization PUK required |
| 100 | Unknown |
| 103 | Illegal message |
| 106 | Illegal ME |
| 107 | GPRS services not allowed |
| 111 | PLMN not allowed |

| | |
|-----|---|
| 112 | Location area not allowed |
| 113 | Roaming not allowed in this location area |
| 132 | service option not supported |
| 133 | requested service option not subscribed |
| 134 | service option temporarily out of order |
| 148 | unspecified GPRS error |
| 149 | PDP authentication failure |
| 150 | invalid mobile class |
| 257 | network rejected request |
| 258 | retry operation |
| 259 | invalid deflected to number |
| 260 | deflected to own number |
| 261 | unknown subscriber |
| 262 | service not available |
| 263 | unknown class specified |
| 264 | unknown network message |
| 273 | minimum TFTS per PDP address violated |
| 274 | TFT precedence index not unique |
| 275 | invalid parameter combination |

“CME ERROR” codes of FTP

| | |
|-----|-----------------------------------|
| 201 | Unknown error for FTP |
| 202 | FTP task is busy |
| 203 | Failed to resolve server address |
| 204 | FTP timeout |
| 205 | Failed to read file |
| 206 | Failed to write file |
| 207 | It's not allowed in current state |
| 208 | Failed to login |
| 209 | Failed to logout |
| 210 | Failed to transfer data |
| 211 | FTP command rejected by server |
| 212 | Memory error |
| 213 | Invalid parameter |
| 214 | Network error |

Example

`AT+CPIN="1234","1234"`

+CME ERROR: incorrect password

3.4 Summary of CMS ERROR codes

Final result code +CMS ERROR: <err> indicates an error related to mobile equipment or network. The operation is simialer to ERROR result code. None of the following commands in the same command line is executed. Neither ERROR nor OK result code shall be returned. ERROR is returned normally when error is related to syntax or invalid parameters. The format of <err> can be either numeric or verbose. This is set with command AT+CME.

| <err> of numeric format | <err> of verbose format |
|-------------------------|-----------------------------|
| 300 | ME failure |
| 301 | SMS service of ME reserved |
| 302 | Operation not allowed |
| 303 | Operation not supported |
| 304 | Invalid PDU mode parameter |
| 305 | Invalid text mode parameter |
| 310 | SIM not inserted |
| 311 | SIM PIN required |
| 312 | PH-SIM PIN required |
| 313 | SIM failure |
| 314 | SIM busy |
| 315 | SIM wrong |
| 316 | SIM PUK required |
| 317 | SIM PIN2 required |
| 318 | SIM PUK2 required |
| 320 | Memory failure |
| 321 | Invalid memory index |
| 322 | Memory full |
| 330 | SMSC address unknown |
| 331 | No network service |
| 332 | Network timeout |
| 340 | NO +CNMA ACK EXPECTED |
| 341 | Buffer overflow |
| 342 | SMS size more than expected |
| 500 | Unknown error |

Example

AT+CMGS=02112345678

+CMS ERROR: 304

SIMCom
Confidential

4. AT Commands for Network

4.1 Overview of AT Commands for Network

| Command | Description |
|-----------|---|
| AT+CREG | Network Registration |
| AT+COPS | Operator selection |
| AT+CLCK | Facility lock |
| AT+CPWD | Change password |
| AT+CCUG | Closed User Group |
| AT+CUSD | Unstructured supplementary service data |
| AT+CAOC | Advice of Charge |
| AT+CSSN | Supplementary service notifications |
| AT+CPOL | Preferred mode selection |
| AT+COPN | Read operator names |
| AT+CNMP | Preferred mode selection |
| AT+CNBP | Preferred band selection |
| AT+CNAOP | Acquisition order preference |
| AT+CPSI | Inquiring UE system information |
| AT+CNSMOD | Show network system mode |
| AT+CEREG | EPS network registration status |
| AT+CTZU | Automatic time and time zone update |
| AT+CTZR | Time and time zone reporting |

4.2 Detailed Description of AT Commands for Network

4.2.1 AT+CREG Network registration

This command is used to control the presentation of an unsolicited result code +CREG: <stat> when <n>=1 and there is a change in the ME network registration status, or code +CREG: <stat>[,<lac>,<ci>] when <n>=2 and there is a change of the network cell.

Read command returns the status of result code presentation and an integer <stat> which shows whether the network has currently indicated the registration of the ME. Location information elements <lac> and <ci> are returned only when <n>=2 and ME is registered in the network.

| AT+CREG Network registration | |
|---|--|
| Test Command AT+CREG=? | Response +CREG: (list of supported <n>s) OK |
| Read Command AT+CREG? | Response +CREG: <n>,<stat>[,<lac>,<ci>] OK or ERROR If error is related to ME functionality: +CME ERROR: <err> |
| Write Command AT+CREG=<n> | Response OK or ERROR If error is related to ME functionality: +CME ERROR: <err> |
| Execution Command AT+CREG | Response (Set default value “<n>=0”): OK |

Defined Values

| | |
|--------|---|
| <n> | <ul style="list-style-type: none"> 0 disable network registration unsolicited result code 1 enable network registration unsolicited result code +CREG: <stat> 2 enable network registration and location information unsolicited result code +CREG: <stat>[,<lac>,<ci>] |
| <stat> | <ul style="list-style-type: none"> 0 – not registered, ME is not currently searching a new operator to register to 1 registered, home network 2 not registered, but ME is currently searching a new operator to register to 3 registration denied 4 unknown 5 registered, roaming |
| <lac> | Two byte location area code in hexadecimal format(e.g.”00C3” equals 193 in decimal). |
| <ci> | NOTE: The <lac> not supported in CDMA/HDR mode Cell Identify in hexadecimal format. |

GSM : Maximum is two byte
WCDMA : Maximum is four byte
TDS-CDMA : Maximum is four byte

NOTE: The <ci> not supported in CDMA/HDR mode

Example

AT+CREG?

+CREG: 0,1

OK

NOTE

- Location information elements <lac> and <ci> are returned only when <n>=2 and ME is registered in the network

4.2.2 AT+COPS Operator selection

Write command forces an attempt to select and register the GSM/UMTS network operator. <mode> is used to select whether the selection is done automatically by the ME or is forced by this command to operator <oper> (it shall be given in format <format>). If the selected operator is not available, no other operator shall be selected (except <mode>=4). The selected operator name format shall apply to further read commands (AT+COPS?) also. <mode>=2 forces an attempt to deregister from the network. The selected mode affects to all further network registration (e.g. after <mode>=2, ME shall be unregistered until <mode>=0 or 1 is selected).

Read command returns the current mode and the currently selected operator. If no operator is selected, <format> and <oper> are omitted.

Test command returns a list of quadruplets, each representing an operator present in the network. Quadruplet consists of an integer indicating the availability of the operator <stat>, long and short alphanumeric format of the name of the operator, and numeric format representation of the operator. Any of the formats may be unavailable and should then be an empty field. The list of operators shall be in order: home network, networks referenced in SIM, and other networks.

It is recommended (although optional) that after the operator list TA returns lists of supported <mode>s and <format>s. These lists shall be delimited from the operator list by two commas. When executing AT+COPS=? , any input from serial port will stop this command.

AT+COPS Operator selection

Test Command

Response

| | |
|--|--|
| <p>AT+COPS=?</p> | <p>[+COPS: [list of supported (<stat>,long alphanumeric <oper> ,short alphanumeric <oper>,numeric <oper>[,< Act>]]s] [,,(list of supported <mode>s),(list of supported <format>s)]</p> <p>OK or ERROR If error is related to ME functionality: +CME ERROR: <err></p> |
| <p>Read Command AT+COPS?</p> | <p>Response +COPS: <mode>[,<format>,<oper>[,< Act>]]</p> <p>OK or ERROR If error is related to ME functionality: +CME ERROR: <err></p> |
| <p>Write Command AT+COPS=<mode>[,<format> >[,<oper>[,< Act>]]]</p> | <p>Response OK or ERROR If error is related to ME functionality: +CME ERROR: <err></p> |
| <p>Execution Command AT+COPS</p> | <p>Response OK</p> |

Defined Values

| | |
|------------------------------|--|
| <p><mode></p> | <p>0 automatic 1 manual 2 force deregister 3 set only <format> 4 manual/automatic 5 manual,but do not modify the network selection mode(e.g GSM,WCDMA) after module resets.</p> <p>NOTE: if <mode> is set to 1, 4, 5 in write command, the <oper> is needed.</p> |
| <p><format></p> | <p>0 long format alphanumeric <oper> 1 short format alphanumeric <oper> 2 numeric <oper></p> |
| <p><oper></p> | <p>string type, <format> indicates if the format is alphanumeric or numeric.</p> |
| <p><stat></p> | <p>0 unknown 1 available</p> |

| | |
|--------------------|---|
| | 2 current |
| | 3 forbidden |
| <AcT> | Access technology selected |
| | 0 GSM |
| | 1 GSM Compact |
| | 2 UTRAN |
| | 7 EUTRAN |
| | 8 CDMA/HDR |
| | NOTE: the value 8 do not follow the 3gpp spec, we add this value to distinguish cdma/hdr. |

Example

AT+COPS?

```
+ COPS: 0,0,"China Mobile Com",0
```

OK

AT+COPS=?

```
+ COPS: (2,"China Unicom","Unicom","46001",0),(3,"China Mobile Com","DGTMP",
"46000",0),(0,1,2,3,4,5),(0,1,2)
```

OK

NOTE

- When executing AT+COPS=? , any input from serial port will stop this command.

4.2.3 AT+CLCK Facility lock

This command is used to lock, unlock or interrogate a ME or a network facility <fac>. Password is normally needed to do such actions. When querying the status of a network service (<mode>=2) the response line for 'not active' case (<status>=0) should be returned only if service is not active for any <class>.

AT+CLCK Facility lock

Test Command

```
AT+CLCK=?
```

Response

```
+CLCK: (list of supported <fac>s)
```

OK

| | |
|--|---|
| | <p>or</p> <p>ERROR</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR: <err></p> |
| <p>Write Command</p> <p>AT+CLCK=<fac>,<mode>[,<passwd>[,<class>]]</p> | <p>Response (When <mode>=2 and command successful:)</p> <p>[+CLCK:<status>[,<class1>[<CR><LF></p> <p>+CLCK: <status>,<class2></p> <p>[...]]</p> <p>OK</p> <p>or</p> <p>ERROR</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR: <err></p> |

Defined Values

| | |
|-----------------------|---|
| <fac> | <p>"PF" lock Phone to the very First inserted SIM card or USIM card</p> <p>"SC" lock SIM card or USIM card</p> <p>"AO" Barr All Outgoing Calls</p> <p>"OI" Barr Outgoing International Calls</p> <p>"OX" Barr Outgoing International Calls except to Home Country</p> <p>"AI" Barr All Incoming Calls</p> <p>"IR" Barr Incoming Calls when roaming outside the home country</p> <p>"AB" All Barring services (only for <mode>=0)</p> <p>"AG" All outGoing barring services (only for <mode>=0)</p> <p>"AC" All inComing barring services (only for <mode>=0)</p> <p>"FD" SIM fixed dialing memory feature</p> <p>"PN" Network Personalization</p> <p>"PU" network subset Personalization</p> <p>"PP" service Provider Personalization</p> <p>"PC" Corporate Personalization</p> |
| <mode> | <p>0 unlock</p> <p>1 lock</p> <p>2 query status</p> |
| <status> | <p>0 not active</p> <p>1 active</p> |
| <passwd> | <p>Password.</p> <p>string type; shall be the same as password specified for the facility from the ME user interface or with command Change Password +CPWD</p> |
| <classX> | <p>It is a sum of integers each representing a class of information (default 7):</p> <p>1 voice (telephony)</p> <p>2 data (refers to all bearer services)</p> |

| | | |
|-----------|--|----------------------------------|
| | 4 | fax (facsimile services) |
| | 8 | short message service |
| | 16 | data circuit sync |
| | 32 | data circuit async |
| | 64 | dedicated packet access |
| | 128 | dedicated PAD access |
| | 255 | The value 255 covers all classes |
| <nlength> | Integer type value indicating the maximum length of field <number> | |
| <length> | Integer type value indicating the maximum length of field <text>. | |

Example

```
AT+CLCK="SC",2
+CLCK: 0

OK
```

NOTE

- When querying the status of a network service (<mode>=2) the response line for 'not active' case (<status>=0) should be returned only if service is not active for any <class>.

4.2.4 AT+CPWD Change password

Write command sets a new password for the facility lock function defined by command Facility Lock AT+CLCK.

Test command returns a list of pairs which present the available facilities and the maximum length of their password.

AT+CPWD Change password

| | |
|---|---|
| Test Command AT+CPWD=? | Response +CPWD: (list of supported (<fac>,<pwdlength>)s) OK or ERROR If error is related to ME functionality: +CME ERROR: <err> |
| Write Command AT+CPWD=<fac>,<oldpwd>,<newpwd> | Response OK |

<newpwd>

or

ERROR

If error is related to ME functionality:

+CME ERROR: <err>

Defined Values

| | |
|-------------|--|
| <fac> | <p>Refer Facility Lock +CLCK for other values:</p> <p>"SC" SIM or USIM PIN1</p> <p>"P2" SIM or USIM PIN2</p> <p>"AB" All Barring services</p> <p>"AC" All inComing barring services (only for <mode>=0)</p> <p>"AG" All outGoing barring services (only for <mode>=0)</p> <p>"AI" Barr All Incoming Calls</p> <p>"AO" Barr All Outgoing Calls</p> <p>"IR" Barr Incoming Calls when roaming outside the home country</p> <p>"OI" Barr Outgoing International Calls</p> <p>"OX" Barr Outgoing International Calls except to Home Country</p> |
| <oldpwd> | <p>String type, it shall be the same as password specified for the facility from the ME user interface or with command Change Password AT+CPWD.</p> |
| <newpwd> | <p>String type, it is the new password; maximum length of password can be determined with <pwdlength>.</p> |
| <pwdlength> | <p>Integer type, max length of password.</p> |

Example

AT+CPWD=?

+CPWD: ("AB",4),("AC",4),("AG",4),("AI",4),("AO",4),("IR",4),("OI",4),("OX",4),("SC",8),("P2",8)

OK

4.2.5 AT+CCUG Closed user group

This command allows control of the Closed User Group supplementary service. Set command enables the served subscriber to select a CUG index, to suppress the Outgoing Access (OA), and to suppress the preferential CUG.

AT+CCUG Closed user group

| Test Command | Response |
|------------------|-----------|
| AT+CCUG=? | OK |

| | |
|--|---|
| | or ERROR |
| Read Command AT+CCUG? | Response +CCUG: <n>,<index>,<info> |
| | OK or ERROR If error is related to ME functionality: +CME ERROR: <err> |
| Write Command AT+CCUG=<n>[,<index>[,<info>]] | Response OK or ERROR If error is related to ME functionality: +CME ERROR: <err> |
| Execution Command AT+CCUG | Response (Set default value): OK |

Defined Values

| | |
|----------------------|---|
| <n> | <u>0</u> disable CUG temporary mode 1 enable CUG temporary mode |
| <index> | <u>0</u> ..9 CUG index 10 no index (preferred CUG taken from subscriber data) |
| <info> | <u>0</u> no information 1 suppress OA 2 suppress preferential CUG 3 suppress OA and preferential CUG |

Example

AT+CCUG?

+CCUG: 0,0

OK

NOTE

- This command not supported in CDMA/HDR mode

4.2.6 AT+CUSD Unstructured supplementary service data

This command allows control of the Unstructured Supplementary Service Data (USSD). Both network and mobile initiated operations are supported. Parameter <n> is used to disable/enable the presentation of an unsolicited result code (USSD response from the network, or network initiated operation) +CUSD: <m>[,<str>,<dcs>] to the TE. In addition, value <n>=2 is used to cancel an ongoing USSD session.

| AT+CUSD Unstructured supplementary service data | |
|---|---|
| Test Command AT+CUSD=? | Response +CUSD: (list of supported <n>s) OK |
| Read Command AT+CUSD? | Response +CUSD: <n> OK |
| Write Command AT+CUSD=<n>[,<str>[,<dcs>]] | Response OK or ERROR If error is related to ME functionality: +CME ERROR: <err> |
| Execution Command AT+CUSD | Response (Set default value): OK |

Defined Values

| | |
|-------|--|
| <n> | <ul style="list-style-type: none"> 0 disable the result code presentation in the TA 1 enable the result code presentation in the TA 2 cancel session (not applicable to read command response) |
| <str> | String type USSD string. |
| <dcs> | Cell Broadcast Data Coding Scheme in integer format (default 0). |
| <m> | <ul style="list-style-type: none"> 0 no further user action required (network initiated USSD Notify, or no further information needed after mobile initiated operation) 1 further user action required (network initiated USSD Request, or further information needed after mobile initiated operation) 2 USSD terminated by network 4 operation not supported 5 network time out |

Example

```
AT+CUSD?
+CUSD: 1
```

OK

AT+CUSD=0

OK

NOTE

- This command not supported in CDMA/HDR mode

4.2.7 AT+CAOC Advice of Charge

This command refers to Advice of Charge supplementary service that enables subscriber to get information about the cost of calls. With <mode>=0, the execute command returns the current call meter value from the ME.

This command also includes the possibility to enable an unsolicited event reporting of the CCM information. The unsolicited result code +CCCM: <ccm> is sent when the CCM value changes, but not more that every 10 seconds. Deactivation of the unsolicited event reporting is made with the same command.

AT+CAOC Advice of Charge

Test Command

AT+CAOC=?

Response

+CAOC: (list of supported <mode>s)

OK

Read Command

AT+CAOC?

Response

+CUSD: <mode>

OK

or

ERROR

If error is related to ME functionality:

+CME ERROR: <err>

Write Command

AT+CAOC=<mode>

Response

+ CAOC: <ccm>

OK

or

ERROR

If error is related to ME functionality:

+CME ERROR: <err>

Execution Command

AT+CAOC

Response (Set default value):

OK

or

ERROR

Defined Values

| | |
|---------------------|---|
| <mode> | 0 query CCM value 1 deactivate the unsolicited reporting of CCM value 2 activate the unsolicited reporting of CCM value |
| ccm> | String type, three bytes of the current call meter value in hexadecimal format (e.g. "00001E" indicates decimal value 30), value is in home units and bytes are similarly coded as ACMmax value in the SIM. |

Example

AT+CAOC=0

+CAOC: "000000"

OK

NOTE

- This command not supported in CDMA/HDR mode

4.2.8 AT+CSSN Supplementary service notifications

This command refers to supplementary service related network initiated notifications. The set command enables/disables the presentation of notification result codes from TA to TE.

When $\langle n \rangle = 1$ and a supplementary service notification is received after a mobile originated call setup, intermediate result code +CSSI: $\langle \text{code1} \rangle [, \langle \text{index} \rangle]$ is sent to TE before any other MO call setup result codes presented in the present document. When several different $\langle \text{code1} \rangle$ s are received from the network, each of them shall have its own +CSSI result code.

When $\langle m \rangle = 1$ and a supplementary service notification is received during a mobile terminated call setup or during a call, or when a forward check supplementary service notification is received, unsolicited result code +CSSU: $\langle \text{code2} \rangle [, \langle \text{index} \rangle [, \langle \text{number} \rangle [, \langle \text{type} \rangle [, \langle \text{subaddr} \rangle [, \langle \text{satype} \rangle]]]]]]$ is sent to TE. In case of MT call setup, result code is sent after every +CLIP result code (refer command "Calling line identification presentation +CLIP") and when several different $\langle \text{code2} \rangle$ s are received from the network, each of them shall have its own +CSSU result code.

AT+CSSN Supplementary service notifications

| | |
|---|---|
| Test Command AT+CSSN? | Response +CSSN: (list of supported <n>s),(list of supported <m>s) OK |
| Execution Command AT+CSSN=<value> | Response +CSSN: <n>,<m> OK or ERROR |
| Write Command AT+CSSN=<n>[,<m>] | Response OK or ERROR If error is related to ME functionality: +CME ERROR: <err> |

Defined Values

| | |
|-----------|--|
| <n> | Parameter sets/shows the +CSSI result code presentation status in the TA: 0 disable 1 enable |
| <m> | Parameter sets/shows the +CSSU result code presentation status in the TA: 0 disable 1 enable |
| <code1> | 0 unconditional call forwarding is active 1 some of the conditional call forwarding are active 2 call has been forwarded 3 call is waiting 5 outgoing calls are barred |
| <index> | Refer "Closed user group +CCUG". |
| <code2> | 0 this is a forwarded call (MT call setup) 2 call has been put on hold (during a voice call) 3 call has been retrieved (during a voice call) 5 call on hold has been released (this is not a SS notification) (during a voice call) |
| <number> | String type phone number of format specified by <type>. |
| <type> | Type of address octet in integer format; default 145 when dialing string includes international access code character "+", otherwise 129. |
| <subaddr> | String type sub address of format specified by <satype>. |
| <satype> | Type of sub address octet in integer format, default 128. |

Example

```
AT+CSSN=1
```

```
OK
```

```
AT+CSSN?
```

```
+CSSN: 1,1
```

```
OK
```

NOTE

- This command not supported in CDMA/HDR mode

4.2.9 AT+CPOL Preferred operator list

This command is used to edit the SIM preferred list of networks.

AT+CPOL Preferred operator list

Test Command

```
AT+CPOL
```

Response

```
+CPOL: (list of supported <index>s), (list of supported <format>s)
```

```
OK
```

Read Command

```
AT+CPOL?
```

Response

```
[+CPOL:<index1>,<format>,<oper1>[<GSM_AcT1>,<GSM_Compact_AcT1>,<UTRAN_AcT1>,<LTE_AcT1>][<CR><LF>
```

```
+CPOL:
```

```
<index2>,<format>,<oper2>[,<GSM_AcT1>,<GSM_Compact_AcT1>,<UTRAN_AcT1>,<LTE_AcT1>]
```

```
[...]]
```

```
OK
```

```
or
```

```
ERROR
```

Write Command

```
AT+CPOL=<index>[,<format>[,<oper>][,<GSM_AcT1>,<GSM_Compact_AcT1>,<UTRAN_AcT1>,<LTE_AcT1> ]]
```

Response

```
OK
```

```
or
```

```
ERROR
```

If error is related to ME functionality:

NOTE: If using USIM card, the

```
+CME ERROR: <err>
```

last four parameters must set.

Defined Values

| | |
|--------------------|---|
| <index> | Integer type, the order number of operator in the SIM preferred operator list. If only input <index>, command will delete the value indicate by <index>. |
| <format> | 0 long format alphanumeric <oper> 1 short format alphanumeric <oper> 2 numeric <oper> |
| <operX> | String type. |
| <GSM_AcTn> | GSM access technology: 0 access technology not selected 1 access technology selected |
| <GSM_Compact_AcTn> | GSM access technology: 0 access technology not selected 1 access technology selected |
| <UTRA_AcTn> | UTRA access technology: 0 access technology not selected 1 access technology selected |
| <LTE_AcTn> | LTE access technology: 0 access technology not selected 1 access technology selected |

Example

```
AT+CPOL?
+CPOL: 1,2,"46001",0,0,1,0
```

OK

```
AT+CPOL=?
+CPOL: (1-8),(0-2)
```

OK

4.2.10 AT+COPN Read operator names

This command is used to return the list of operator names from the ME. Each operator code <numericX> that has an alphanumeric equivalent <alphaX> in the ME memory shall be returned.

AT+COPN Read operator names

| | |
|----------------------------------|--|
| Test Command AT+COPN=? | Response OK or ERROR |
| Write Command AT+COPN | Response [+COPN:<numeric1>,<alpha1>[<CR><LF> +COPN: <numeric2>,<alpha2> [...]] OK or If error is related to ME functionality: +CME ERROR: <err> |

Defined Values

| | |
|------------|--|
| <numericX> | String type, operator in numeric format (see AT+COPS). |
| <alphaX> | String type, operator in long alphanumeric format (see AT+COPS). |

Example

```

AT+COPN
+COPN: "46000","China Mobile Com"
+COPN: "46001","China Unicom"
.....
OK

```

4.2.11 AT+CNMP Preferred mode selection

This command is used to select or set the state of the mode preference.

AT+CNMP Preferred mode selection

| | |
|----------------------------------|--|
| Test Command AT+CNMP=? | Response +CNMP: (list of supported <mode>s) OK |
| Read Command AT+CNMP? | Response +CNMP: <mode> |

| | |
|-----------------------------|--|
| | OK |
| Write Command | Response |
| AT+CNMP=<mode> | OK |
| | or |
| | (If <mode> not supported by module, this command will return ERROR.) |
| | ERROR |

Defined Values

| | |
|---------------------|-------------------------------------|
| <mode> | <u>2</u> Automatic |
| | 13 GSM Only |
| | 14 WCDMA Only |
| | 38 LTE Only |
| | 59 TDS-CDMA Only |
| | 9 CDMA Only |
| | 10 EVDO Only |
| | 19 GSM+WCDMA Only |
| | 22 CDMA+EVDO Only |
| | 48 Any but LTE |
| | 60 GSM+TDSCDMA Only |
| | 63 GSM+WCDMA+TDSCDMA Only |
| | 67 CDMA+EVDO+GSM+WCDMA+TDSCDMA Only |
| | 39 GSM+WCDMA+LTE Only |
| | 51 GSM+LTE Only |
| | 54 WCDMA+LTE Only |

Example

```
AT+CNMP=13
```

```
OK
```

```
AT+CNMP?
```

```
+CNMP: 13
```

```
OK
```

NOTE

- The set value in Write Command will take effect immediately; The set value will retain after module reset
- The response will be returned immediately for Test Command and Read Command; The maximum response time for Write Command is 10 seconds

4.2.12 AT+CNBP Preferred band selection

This command is used to select or set the state of the band preference.

| AT+CNBP Preferred band selection | |
|---|--|
| Test Command AT+CNBP? | Response +CNBP: <mode>[,<lte_mode>][,<tds_mode>] |
| | OK |
| Read Command AT+CNBP=<mode>[,<lte_mode>][,<tds_mode>] | Response OK Or ERROR |

Defined Values

| | |
|-------------------------|---|
| <mode> | 64 bit number, the value is "1" << "<pos>", then or by bit. Some special mode value declared below: 0x40000000 BAND_PREF_NO_CHANGE |
| <pos> | Value: 0xFFFFFFFF7FFFFFFF Any (any value) 7 GSM_DCS_1800 8 GSM_EGSM_900 9 GSM_PGSM_900 16 GSM_450 17 GSM_480 18 GSM_750 19 GSM_850 20 GSM_RGSM_900 21 GSM_PCS_1900 22 WCDMA_IMT_2000 23 WCDMA_PCS_1900 24 WCDMA_III_1700 25 WCDMA_IV_1700 26 WCDMA_850 27 WCDMA_800 48 WCDMA_VII_2600 49 WCDMA_VIII_900 50 WCDMA_IX_1700 |
| <lte_mode> | 64/256 bit number, the value is "1" << "<lte_pos>", then or by bit. NOTE: FDD(band1 ~ band32, band66 , band252, and band255), |

| | | |
|-------------------------|--|---|
| | DL: 1525 -1559) | |
| 24 | 1930 -1995) | EUTRAN_BAND25(UL: 1850-1915; DL: |
| 25 | -894) | EUTRAN_BAND26(UL: 814-849; DL: 859 |
| 26 | 852 -869) | EUTRAN_BAND27(UL: 807.5-824; DL: |
| 27 | 27 | EUTRAN_BAND28(703-748; DL: 758-803) |
| 28 | 1710-1755; DL:716-728) | EUTRAN_BAND29(UL:1850-1910 or |
| 29 | 2350 - 2360) | EUTRAN_BAND30(UL: 2305-2315 ; DL: |
| 32 | 1900-1920) | EUTRAN_BAND33(UL: 1900-1920; DL: |
| 33 | 2010-2025) | EUTRAN_BAND34(UL: 2010-2025; DL: |
| 34 | 1850-1910) | EUTRAN_BAND35(UL: 1850-1910; DL: |
| 35 | 1930-1990) | EUTRAN_BAND36(UL: 1930-1990; DL: |
| 36 | 1910-1930) | EUTRAN_BAND37(UL: 1910-1930; DL: |
| 37 | 2570-2620) | EUTRAN_BAND38(UL: 2570-2620; DL: |
| 38 | 1880-1920) | EUTRAN_BAND39(UL: 1880-1920; DL: |
| 39 | 2300-2400) | EUTRAN_BAND40(UL: 2300-2400; DL: |
| 40 | 2496-2690) | EUTRAN_BAND41(UL: 2496-2690; DL: |
| 41 | 3400-3600) | EUTRAN_BAND42(UL: 3400-3600; DL: |
| 42 | 3600-3800) | EUTRAN_BAND43(UL: 3600-3800; DL: |
| 65 | 2110-2200) | EUTRAN_BAND66(UL: 1710-1780; DL: |
| 70 | 617-652) | EUTRAN_BAND71(UL: 663-698; DL: |
| 251 | | EUTRAN_BAND252(DL: 5150-5250) |
| 254 | | EUTRAN_BAND255(DL: 5725-5850) |
| <tds_mode> | 64bit number, the value is "1" << "<tds_pos>", then or by bit. | |
| <tds_pos> | Value: | |
| | 0x0000000000000003F | Any (any value) |
| | 0 | TDS Band A (1900-1920 MHz, 2010-2020 MHz) |

| | |
|--|---|
| | OK |
| Write Command AT+CNAOP=<mode>[,<sys_mode1>[,<sys_mode2>[,<sys_mode3>[,<sys_mode4>[,<sys_mode5>[,<sys_mode6>]]]]] | Response OK or ERROR |

Defined Values

| | |
|-------------------------|--|
| <mode> | 7 Acquisition by priority order list <sys_moden>s. |
| <sys_mode> | sys_mode values: 2 CDMA 3 GSM 4 HDR 5 WCDMA 9 LTE 11 TDSCDMA |

Example

AT+CNAOP=7,9,5,3,11,2,4

OK

AT+CNAOP?

+CNAOP: 7,9,5,3,11,2,4

OK

4.2.14 AT+CPSI Inquiring UE system information

This command is used to return the UE system information.

| AT+CPSI Inquiring UE system information | |
|--|---|
| Test Command AT+CPSI=? | Response +CPSI: (scope of <time>) |
| Read Command AT+CPSI? | Response If camping on a cdma/evdo cell: +CPSI: CDMA,<Operation Mode>[,<MCC>-<MNC>,<CDMA ch num>,<CDMA pilot PN>,<CDMA RX Chain 0 AGC>,<CDMA RX |

Chain 1 AGC>,<CDMA Chain 0 LNA>,<CDMA Chain 1 LNA>,<CDMA TX AGC>,<SID>,<NID>,<CDMA EC/IO>,<BID>]
 +CPSI: EVDO,<Operation Mode>[,<MCC>-<MNC>,<EVDO ch num>,<EVDO RX Chain 0 AGC>,<EVDO RX Chain 1 AGC>,<EVDO TX AGC>,<EVDO Serving PN>,<EVDO Rel0 SCI>,<EVDO RelA SCI>,<EVDO EC/IO>]

OK

If camping on a gsm cell:

+CPSI:<System Mode>,<Operation Mode>,<MCC>-<MNC>,<LAC>,<Cell ID>,<Absolute RF Ch Num>,<RxLev>,<Track LO Adjust>,<C1-C2>

OK

If camping on a wcdma cell:

+CPSI: <System Mode>,<Operation Mode>,<MCC>-<MNC>,<LAC>,<Cell ID>,<Frequency Band>,<PSC>,<Freq>,<SSC>,<EC/IO>,<RSCP>,<Qual>,<RxLev>,<TXPWR>

OK

If camping on a tds-cdma cell:

+CPSI: <System Mode>,<Operation Mode>,<MCC>-<MNC>,<LAC>,<Cell ID>,<Frequency Band>,<Uarfcn>,<Cpid>

OK

If camping on a lte cell:

+CPSI: <System Mode>,<Operation Mode>[,<MCC>-<MNC>,<TAC>,<SCellID>,<PCellID>,<Frequency Band>,<earfcn>,<dlbw>,<ulbw>,<RSRQ>,<RSRP>,<RSSI>,<RSSNR>]

OK

If camping on a cdma/evdo cell:

+CPSI: CDMA,<Operation Mode>[,<MCC>-<MNC>,<CDMA ch num>,<CDMA pilot PN>,<CDMA RX Chain 0 AGC>,<CDMA RX Chain 1 AGC>,<CDMA Chain 0 LNA>,<CDMA Chain 1 LNA>,<CDMA TX AGC>,<SID>,<NID>,<CDMA EC/IO>,<BID>]
 +CPSI: EVDO,<Operation Mode>[,<MCC>-<MNC>,<EVDO ch num>,<EVDO RX Chain 0 AGC>,<EVDO RX Chain 1 AGC>,<EVDO TX AGC>,<EVDO Serving PN>,<EVDO Rel0 SCI>,<EVDO RelA SCI>,<EVDO EC/IO>]

OK

If camping on a cdma/ehrpd cell:

+CPSI: CDMA,<Operation Mode>[,<MCC>-<MNC>,<CDMA ch num>,<CDMA pilot PN>,<CDMA RX Chain 0 AGC>,<CDMA RX Chain 1 AGC>,<CDMA Chain 0 LNA>,<CDMA Chain 1 LNA>,<CDMA TX AGC>,<SID>,<NID>,<CDMA EC/IO>,<BID>]

+CPSI: eHRPD,<Operation Mode>[,<MCC>-<MNC>,<EVDO ch num>,<EVDO RX Chain 0 AGC>,<EVDO RX Chain 1 AGC>,<EVDO TX AGC>,<EVDO Serving PN>,<EVDO Rel0 SCI>,<EVDO RelA SCI>,<EVDO EC/IO>]

OK

If camping on 1xlte cell:

+CPSI: CDMA,<Operation Mode>[,<MCC>-<MNC>,<CDMA ch num>,<CDMA pilot PN>,<CDMA RX Chain 0 AGC>,<CDMA RX Chain 1 AGC>,<CDMA Chain 0 LNA>,<CDMA Chain 1 LNA>,<CDMA TX AGC>,<SID>,<NID>,<CDMA EC/IO>,<BID>]

+CPSI: LTE,<Operation Mode>[,<MCC>-<MNC>,<TAC>,<SCellID>,<PCellID>,<Frequency Band>,<earfcn>,<dlbw>,<ulbw>,<RSRQ>,<RSRP>,<RSSI>,<RSSNR>]

OK

If no service:

+CPSI: NO SERVICE, Online

OK

or

ERROR

Write Command
AT+CPSI=<time>

Response
OK
or
ERROR

Defined Values

| | |
|-------------------------------|--|
| <time> | The range is 0-255, unit is second, after set <time> will report the system information every the seconds. |
| <System mode> | System mode, values: "NO SERVICE", "GSM", "WCDMA", "LTE", "TDS"... If module in LIMITED SERVICE state and +CNLSA command is set to 1, the system mode will display as "GSM-LIMITED", "WCDMA-LIMITED"... |
| <Operation mode> | UE operation mode, values: "Unknown", "Online", "Offline", "Factory Test Mode", "Reset", "Low Power Mode". |
| <MCC> | Mobile Country Code (first part of the PLMN code) |

| | |
|-------------------------|--|
| <MNC> | Mobile Network Code (second part of the PLMN code) |
| <LAC> | Location Area Code (hexadecimal digits) |
| <Cell ID> | Service-cell Identify. |
| <Absolute RF Ch Number> | AFRCN for service-cell. |
| <Track LO Adjust> | Track LO Adjust |
| <C1> | Coefficient for base station selection |
| <C2> | Coefficient for Cell re-selection |
| <Frequency Band> | Frequency Band of active set |
| <PSC> | Primary synchronization code of active set. |
| <Freq> | Downlink frequency of active set. |
| <SSC> | Secondary synchronization code of active set |
| <EC/IO> | Ec/Io value Received Signal Code Power |
| <RSCP> | Received Signal Code Power |
| <Qual> | Quality value for base station selection |
| <RxLev> | RX level value for base station selection |
| <TXPWR> | UE TX power in dBm. If no TX, the value is 500. |
| <Cpi> | Cell Parameter ID |
| <TAC> | Tracing Area Code |
| <PCellID> | Physical Cell ID |
| <earfcn> | E-UTRA absolute radio frequency channel number for searching LTE cells |
| <dlbw> | Transmission bandwidth configuration of the serving cell on the downlink |
| <ulbw> | Transmission bandwidth configuration of the serving cell on the uplink |
| <RSRP> | Current reference signal received power in -1/10 dBm. Available for LTE |
| <RSRQ> | Current reference signal receive quality as measured by L1. |
| <RSSNR> | Average reference signal signal-to-noise ratio of the serving cell |
| <BID> | Base ID |

Example

AT+CPSI?

+CPSI: GSM,Online,460-00,0x182d,12401,27 EGSM 900,-64,2110,42-42

OK

AT+CPSI?

+CPSI: WCDMA,Online,460-01,0xA809,11122855,WCDMA IMT 2000,279,10663,0,1.5,62,33,52,500

OK

AT+CPSI=?
+CPSI: (0-255)

OK

4.2.15 AT+CNSMOD Show network system mode

This command is used to return the current network system mode.

| AT+CNSMOD Show network system mode | |
|---|---|
| Test Command AT+CNSMOD=? | Response +CNSMOD: (list of supported <n>s) OK |
| Read Command AT+CNSMOD=? | Response +CNSMOD: <n>,<stat> OK or ERROR If error is related to ME functionality: +CME ERROR: <err> |
| Write Command AT+CNSMOD=<n> | Response OK or ERROR If error is related to ME functionality: +CME ERROR: <err> |

Defined Values

| | |
|--------|---|
| <n> | 0 disable auto report the network system mode information 1 auto report the network system mode information, command: +CNSMOD:<stat> |
| <stat> | 0 no service 1 GSM 2 GPRS 3 EGPRS (EDGE) 4 WCDMA 5 HSDPA only(WCDMA) 6 HSUPA only(WCDMA) 7 HSPA (HSDPA and HSUPA, WCDMA) |

| | |
|--------|---|
| | 8 LTE |
| | 9 TDS-CDMA |
| | 10 TDS-HSDPA only |
| | 11 TDS- HSUPA only |
| | 12 TDS- HSPA (HSDPA and HSUPA) |
| | 13 CDMA |
| | 14 EVDO |
| | 15 HYBRID (CDMA and EVDO) |
| | 16 1XLTE(CDMA and LTE) |
| | 23 eHRPD |
| | 24 HYBRID(CDMA and eHRPD) |
| <type> | Type of address octet in integer format.see also AT+CPBR <type> |

Example

```
AT+CNSMOD?
+CNSMOD: 0,2
OK
```

4.2.16 AT+CEREG EPS network registration status

The set command controls the presentation of an unsolicited result code +CEREG: <stat> when <n>=1 and there is a change in the MT's EPS network registration status in E-UTRAN, or unsolicited result code +CEREG: <stat>[,<tac>,<ci>[,<AcT>]] when <n>=2 and there is a change of the network cell in E-UTRAN; in this latest case <AcT>, <tac> and <ci> are sent only if available.

NOTE 1:If the EPS MT in GERAN/UTRAN/E-UTRAN also supports circuit mode services and/or GPRS services, the +CREG command and +CREG: result codes and/or the +CGREG command and +CGREG: result codes apply to the registration status and location information for those services.

The read command returns the status of result code presentation and an integer <stat> which shows whether the network has currently indicated the registration of the MT. Location information elements <tac>, <ci> and <AcT>, if available, are returned only when <n>=2 and MT is registered in the network.

AT+CEREG EPS network registration status

| | |
|-----------------------------------|---|
| Test Command AT+CEREG=? | Response +CEREG: (list of supported <n> s) OK or ERROR |
| Read Command AT+CEREG? | Response +CEREG: <n>,<stat>[,<tac>,<ci>[,<AcT>]] |

| | |
|---|--|
| | <p>OK</p> <p>or</p> <p>ERROR</p> |
| <p>Write Command</p> <p>AT+CEREG[=<n>]</p> | <p>Response</p> <p>OK</p> <p>or</p> <p>ERROR</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR: <err></p> |
| <p>Execution Command</p> <p>AT+CEREG</p> | <p>Response (Set default value(<n>=0)</p> <p>OK</p> <p>or</p> <p>ERROR</p> |

Defined Values

| | |
|---------------------|--|
| <n> | <p>0 disable network registration unsolicited result code</p> <p>1 enable network registration unsolicited result code +CEREG: <stat></p> <p>2 enable network registration and location information unsolicited result code +CEREG: <stat>[,<tac>,<ci>[,<AcT>]]</p> |
| <stat> | <p>0 not registered, MT is not currently searching an operator to register to</p> <p>1 registered, home network</p> <p>2 not registered, but MT is currently trying to attach or searching an operator to register to</p> <p>3 registration denied</p> <p>4 unknown (e.g. out of E-UTRAN coverage)</p> <p>5 registered, roaming</p> <p>6 registered for "SMS only", home network (not applicable)</p> <p>7 registered for "SMS only", roaming (not applicable)</p> <p>8 attached for emergency bearer services only (See NOTE 2)</p> |
| <tac> | <p>string type; two byte tracking area code in hexadecimal format (e.g. "00C3" equals 195 in decimal)</p> |
| <ci> | <p>string type; four byte E-UTRAN cell identify in hexadecimal format</p> |
| <AcT> | <p>A numeric parameter that indicates the access technology of serving cell</p> <p>0 GSM (not applicable)</p> <p>1 GSM Compact (not applicable)</p> <p>2 UTRAN (not applicable)</p> <p>3 GSM w/EGPRS (see NOTE 3) (not applicable)</p> <p>4 UTRAN w/HSDPA (see NOTE 4) (not applicable)</p> <p>5 UTRAN w/HSUPA (see NOTE 4) (not applicable)</p> <p>6 UTRAN w/HSDPA and HSUPA (see NOTE 4) (not applicable)</p> |

Example

AT+CEREG?

+CEREG: 0,4

OK

NOTE

- If the EPS MT in GERAN/UTRAN/E-UTRAN also supports circuit mode services and/or GPRS services, the +CREG command and +CEREG: result codes and/or the +CGREG command and +CGREG: result codes apply to the registration status and location information for those services.

4.2.17 AT+CTZU Automatic time and time zone update

This command is used to enable and disable automatic time and time zone update via NITZ.

AT+CTZU Automatic time and time zone update

| | |
|--|--|
| Test Command AT+CTZU=? | Response +CTZU: (list of supported <on/off>s) OK |
| Execution Command AT+CTZU? | Response +CTZU: <on/off > OK or If error is related to ME functionality: +CME ERROR: <err> |
| Write Command AT+CTZU=<on/off> | Response OK or ERROR |

Defined Values

<on/off> Integer type value indicating:

| | |
|----------|---|
| | <p>0 Disable automatic time zone update via NITZ (default). 1 Enable automatic time zone update via NITZ.</p> <p>NOTE: 1. The value of < on/off > is nonvolatile, and factory value is 0. 2. For automatic time and time zone update is enabled (+CTZU=1): If time zone is only received from network and it isn't equal to local time zone (AT+CCLK), time zone is updated automatically, and real time clock is updated based on local time and the difference between time zone from network and local time zone (Local time zone must be valid). If Universal Time and time zone are received from network, both time zone and real time clock is updated automatically, and real time clock is based on Universal Time and time zone from network.</p> |
| <number> | String type phone number of format specified by <type>. |
| <type> | Type of address octet in integer format.see also AT+CPBR <type> |

Example

AT+CTZU?

+ CTZU: 0

OK

AT+CTZU=1

OK

4.2.18 AT+CTZR Time and time zone reporting

This command is used to enable and disable the time zone change event reporting. If the reporting is enabled the MT returns the unsolicited result code +CTZV: <tz>[,<time>][, <dst>] whenever the time zone is changed.

AT+CTZR Time and time zone reporting

| | |
|--|--|
| Test Command AT+CTZR=? | Response +CTZR: (list of supported <on/off>s) OK |
| Read Command AT+CTZR | Response +CTZR: <on/off> OK |
| Write Command AT+CTZR=<on/off> | Response OK |

| | |
|-------------------------------------|---|
| | or ERROR |
| Execution Command AT+CTZR | Response (Set default value) OK |

Defined Values

| | |
|---|--|
| <on/off> | Integer type value indicating: 0 Disable time zone change event reporting (default). 1 Enable time zone change event reporting. |
| +CTZV: <tz>[,<time>][,<dst>] | <p>Unsolicited result code when time zone received from network isn't equal to local time zone, and if the informations from network don't include date and time, time zone will be only reported, and if network daylight saving time is present, it is also reported. For example:</p> <p>+CTZV: 32 (Only report time zone) +CTZV: 32,1 (Report time zone and network daylight saving time) +CTZV: 32,08/12/09,17:00:00 (Report time and time zone) +CTZV: 32,08/12/09,17:00:00,1 (Report time, time zone and daylight saving time)</p> <p>For more detailed informations about time and time zone, please refer 3GPP TS 24.008.</p> <p><tz> Local time zone received from network. <time> Universal time received from network, and the format is "yy/MM/dd,hh:mm:ss", where characters indicate year (two last digits), month, day, hour, minutes and seconds. <dst> Network daylight saving time, and if it is received from network, it indicates the value that has been used to adjust the local time zone. The values as following:</p> <ul style="list-style-type: none"> 0 – No adjustment for Daylight Saving Time. 1 – +1 hour adjustment for Daylight Saving Time. 2 – +2 hours adjustment for Daylight Saving Time. <p>NOTE: Herein, <time> is Universal Time or NITZ time, but not local time.</p> |

Example

AT+CTZR?

+CTZR: 0

OK

AT+CTZR=1

OK

NOTE

- The time zone reporting is not affected by the Automatic Time and Time Zone command AT+CTZU.

SIMCom
Confidential

5. AT Commands for Call Control

5.1 Overview of AT Commands for Call Control

| Command | Description |
|---------|--|
| AT+CVHU | Voice hang up control |
| AT+CHUP | Hang up call |
| AT+CBST | Select bearer service type |
| AT+CRLP | Radio link protocol |
| AT+CR | Service reporting control |
| AT+CRC | Cellular result codes |
| AT+CLCC | List current calls |
| AT+CEER | Extended error report |
| AT+CCWA | Call waiting |
| AT+CHLD | Call related supplementary services |
| AT+CCFC | Call forwarding number and conditions |
| AT+CLIP | Calling line identification presentation |
| AT+CLIR | Calling line identification restriction |
| AT+COLP | Connected line identification presentation |
| AT+VTS | DTMF and tone generation |
| AT+VTD | Tone duration |
| AT+CSTA | Select type of address |
| AT+CMOD | Call mode |

5.2 Detailed Description of AT Commands for Call Control

5.2.1 AT+CVHU Voice hang up control

Write command selects whether ATH or “drop DTR” shall cause a voice connection to be disconnected or not. By voice connection is also meant alternating mode calls that are currently in voice mode.

AT+CVHU Voice hang up control

| | |
|--|---|
| Test Command AT+CVHU=? | Response +CVHU: (list of supported <mode>s) OK |
| Read Command AT+CVHU? | Response +CVHU: <mode> OK |
| Write Command AT+CVHU=<mode> | Response a)If successfully: OK b)If failed: ERROR |
| Execution Command AT+CVHU | Response OK |
| Maximum Response Time | 120000ms |

Defined Values

| | |
|---------------------|---|
| <mode> | 0 – “Drop DTR” ignored but OK response given. ATH disconnects. 1 – “Drop DTR” and ATH ignored but OK response given. |
|---------------------|---|

Examples

AT+CVHU=0

OK

AT+CVHU?

+CVHU: 0

OK

5.2.2 AT+CHUP Hang up call

This command is used to cancel voice calls. If there is no call, it will do nothing but OK response is given. After running AT+CHUP, multiple “VOICE CALL END: ” may be reported which relies on how many calls exist before calling this command.

AT+CHUP Hang up call

| | |
|----------------------------------|-----------------------|
| Test Command AT+CHUP=? | Response OK |
|----------------------------------|-----------------------|

| | |
|-------------------------------------|---|
| Execution Command AT+CHUP | Response VOICE CALL: END: <time> [... VOICE CALL: END: <time>] OK |
| | <i>No call:</i> OK |
| Maximum Response Time | 120000ms |

Defined Values

| | |
|---------------------|---|
| <time> | Voice call connection time. Format – HHMMSS (HH: hour, MM: minute, SS: second) |
|---------------------|---|

Examples

```
AT+CHUP
VOICE CALL:END: 000017
OK
```

5.2.3 AT+CBST Select bearer service type

Write command selects the bearer service <name> with data rate <speed>, and the connection element <ce> to be used when data calls are originated. Values may also be used during mobile terminated data call setup, especially in case of single numbering scheme calls.

| AT+CBST Select bearer service type | |
|--|---|
| Test Command AT+CBST=? | Response +CBST: (list of supported <speed>s), (list of supported <name>s), (list of supported <ce>s) OK |
| Read Command AT+CBST? | Response +CBST: <speed>,<name>,<ce> OK |
| Write Command AT+CBST=<speed>[,<name>[<ce>]] | Response a)If successfully: OK b)If failed: ERROR |
| Execution Command AT+CBST | Response OK |

Maximum Response Time 120000ms

Defined Values

| | |
|---|---|
| <speed> | <p><u>0</u> – autobauding(automatic selection of the speed; this setting is possible in case of 3.1 kHz modem and non-transparent service)</p> <p>7 – 9600 bps (V.32)</p> <p>12 – 9600 bps (V.34)</p> <p>14 – 14400 bps(V.34)</p> <p>16 – 28800 bps(V.34)</p> <p>17 – 33600 bps(V.34)</p> <p>39 – 9600 bps(V.120)</p> <p>43 – 14400 bps(V.120)</p> <p>48 – 28800 bps(V.120)</p> <p>51 – 56000 bps(V.120)</p> <p>71 – 9600 bps(V.110)</p> <p>75 – 14400 bps(V.110)</p> <p>80 – 28800 bps(V.110 or X.31 flag stuffing)</p> <p>81 – 38400 bps(V.110 or X.31 flag stuffing)</p> <p>83 – 56000 bps(V.110 or X.31 flag stuffing)</p> <p>84 – 64000 bps(X.31 flag stuffing)</p> <p>116 – 64000 bps(bit transparent)</p> <p>134 – 64000 bps(multimedia)</p> |
| <name> | <p><u>0</u> – Asynchronous modem</p> <p>1 – Synchronous modem</p> <p>4 – data circuit asynchronous (RDI)</p> |
| <ce> | <p>0 – transparent</p> <p>1 – non-transparent</p> |
| NOTE: If <speed> is set to 116 or 134, it is necessary that <name> is equal to 1 and <ce> is equal to 0. | |

Examples

```
AT+CBST=0,0,1
```

```
OK
```

```
AT+CBST?
```

```
+CBST: 0,0,1
```

```
OK
```

5.2.4 AT+CRLP Radio link protocol

Radio Link Protocol(RLP) parameters used when non-transparent data calls are originated may be altered with write command.

Read command returns current settings for each supported RLP version <verX>. Only RLP parameters applicable to the corresponding <verX> are returned.

Test command returns values supported by the TA as a compound value. If ME/TA supports several RLP versions <verX>, the RLP parameter value ranges for each <verX> are returned in a separate line.

| AT+CRLP Radio link protocol | |
|--|---|
| Test Command AT+CRLP=? | Response +CRLP: (list of supported <iws>s), (list of supported <mws>s), (list of supported <T1>s), (list of supported <N2>s) [,<ver1> [(list of supported <T4>s)]]<CR><LF> +CRLP: (list of supported <iws>s), (list of supported <mws>s), (list of supported <T1>s), (list of supported <N2>s) [,<ver2> [(list of supported <T4>s)]] [...] OK |
| Read Command AT+CRLP? | Response +CRLP: <iws>, <mws>, <T1>, <N2> [,<ver1> [, <T4>]]<CR><LF> +CRLP:<iws>,<mws>,<T1>,<N2>[,<ver2>[,<T4>]] [...] OK |
| Write Command AT+CRLP=<iws> [,<mws>[,<T1>[,<N2> [,<ver>[,<T4>]]]]] | Response a)If successfully: OK b)If failed: ERROR |
| Execution Command AT+CRLP | Response OK |
| Maximum Response Time | 120000ms |

Defined Values

| | |
|--------------|---|
| <ver>,<verX> | RLP version number in integer format, and it can be 0, 1 or 2; when version indication is not present it shall equal 1. |
| <iws> | IWF to MS window size. |
| <mws> | MS to IWF window size. |
| <T1> | Acknowledgement timer. |
| <N2> | Retransmission attempts. |
| <T4> | Re-sequencing period in integer format. |

NOTE: <T1> and <T4> are in units of 10 ms.

Examples

AT+CRLP=0

+CRLP:61,61,48,6,0
+CRLP:61,61,48,6,1
+CRLP:240,240,52,6,2
OKs

5.2.5 AT+CR Service reporting control

Write command controls whether or not intermediate result code “+CR: <serv>” is returned from the TA to the TE. If enabled, the intermediate result code is transmitted at the point during connect negotiation at which the TA has determined which speed and quality of service will be used, before any error control or data compression reports are transmitted, and before the intermediate result code CONNECT is transmitted.

| AT+CR Service reporting control | |
|--|---|
| Test Command AT+CR=? | Response +CR: (list of supported <mode>s) OK |
| Read Command AT+CR? | Response +CR: <mode> OK |
| Write Command AT+CR=<mode> | Response a)If successfully: OK b)If failed: ERROR |
| Execution Command AT+CR | Response OK |
| Maximum Response Time | 120000ms |

Defined Values

| | |
|---------------------|--|
| <mode> | 0 – disables reporting 1 – enables reporting |
| <serv> | ASYNC asynchronous transparent SYNC synchronous transparent REL ASYNC asynchronous non-transparent REL sync synchronous non-transparent GPRS [<L2P>] GPRS The optional <L2P> proposes a layer 2 protocol to use between the MT and the TE.s |

Examples

AT+CR=1

OK

AT+CR?

+CR: 1

OK

5.2.6 AT+CRC Cellular result codes

Write command controls whether or not the extended format of incoming call indication or GPRS network request for PDP context activation is used. When enabled, an incoming call is indicated to the TE with unsolicited result code “+CRING: <type>” instead of the normal RING.

Test command returns values supported by the TA as a compound value.

| AT+CRC Cellular result codes | |
|---|---|
| Test Command AT+CRC=? | Response +CRC: (list of supported <mode>s) OK |
| Read Command AT+CRC? | Response +CRC: <mode> OK |
| Write Command AT+CRC=<mode> | Response a)If successfully: OK b)If failed: ERROR |
| Execution Command AT+CRC | Response OK |
| Maximum Response Time | 120000ms |

Defined Values

| | | |
|---------------------|---|------------------------------|
| <mode> | 0 – disable extended format 1 – enable extended format | |
| <type> | ASYNC | asynchronous transparent |
| | SYNC | synchronous transparent |
| | REL ASYNC | asynchronous non-transparent |
| | REL SYNC | synchronous non-transparent |
| | FAX | facsimile |
| | VOICE | normal voice |

VOICE/XXX voice followed by data(XXX is ASYNC, SYNC, REL ASYNC or REL SYNC)
 ALT VOICE/XXX alternating voice/data, voice first
 ALT XXX/VOICE alternating voice/data, data first
 ALT FAX/VOICE alternating voice/fax, fax first
 GPRS GPRS network request for PDP context activation

Examples

AT+CRC=1

OK

AT+CRC?

+CRC: 1

OK

5.2.7 AT+CLCC List current calls

This command issued to return list of current calls of ME. If command succeeds but no calls are available, no information response is sent to TE.

| AT+CLCC List current calls | |
|---|---|
| Test Command AT+CLCC=? | Response +CLCC: (list of supported <n>s) OK |
| Read Command AT+CLCC? | Response +CLCC: <n> OK |
| Write Command AT+CLCC=<n> | Response a)If successfully: OK b)If failed: ERROR |
| Execution Command AT+CLCC | Response +CLCC:<id1>,<dir>,<stat>,<mode>,<mpty>[,<number>,<type>[,<alpha>]] [<CR><LF> +CLCC:<id2>,<dir>,<stat>,<mode>,<mpty>[,<number>,<type>[,<alpha>]] [...] OK |
| Maximum Response Time | 120000ms |

Defined Values

| | |
|----------|--|
| <n> | <p>0 – Don't report a list of current calls of ME automatically when the current call status changes.</p> <p>1 – Report a list of current calls of ME automatically when the current call status changes.</p> |
| <idX> | <p>Integer type, call identification number, this number can be used in +CHLD command operations.</p> |
| <dir> | <p>0 – mobile originated (MO) call</p> <p>1 – mobile terminated (MT) call</p> |
| <stat> | <p>State of the call:</p> <p>0 – active</p> <p>1 – held</p> <p>2 – dialing (MO call)</p> <p>3 – alerting (MO call)</p> <p>4 – incoming (MT call)</p> <p>5 – waiting (MT call)</p> <p>6 – disconnect</p> |
| <mode> | <p>bearer/teleservice:</p> <p>0 – voice</p> <p>1 – data</p> <p>2 – fax</p> <p>9 – unknown</p> |
| <mpty> | <p>0 – call is not one of multiparty (conference) call parties</p> <p>1 – call is one of multiparty (conference) call parties</p> |
| <number> | <p>String type phone number in format specified by <type>.</p> |
| <type> | <p>Type of address octet in integer format;</p> <p>128 – Restricted number type includes unknown type and format</p> <p>145 – International number type</p> <p>161 – national number. The network support for this type is optional</p> <p>177 – network specific number, ISDN format</p> <p>129 – Otherwise</p> |
| <alpha> | <p>String type alphanumeric representation of <number> corresponding to the entry found in phonebook; used character set should be the one selected with command Select TE Character Set AT+CSCS.</p> |

Examples

```
ATD10011;
OK
```

AT+CLCC

```
+CLCC: 1,0,0,0,0,"10011",129,"sm"
OK
```

RING (with incoming call)

AT+CLCC

```
+CLCC: 1,1,4,0,0,"02152063113",128,"gongsi"
OK
```

5.2.8 AT+CEER Extended error report

Execution command causes the TA to return the information text <report>, which should offer the user of the TA an extended report of the reason for:

- 1 The failure in the last unsuccessful call setup(originating or answering) or in-call modification.
- 2 The last call release.
- 3 The last unsuccessful GPRS attach or unsuccessful PDP context activation.

The last GPRS detach or PDP context deactivation.

AT+CEER Extended error report

| | |
|-------------------------------------|--|
| Test Command AT+CEER=? | Response OK |
| Execution Command AT+CEER | Response +CEER:<report> OK |
| Maximum Response Time | 120000ms |

Defined Values

| | |
|----------|---|
| <report> | Wrong information which is possibly occurred. |
|----------|---|

Examples

AT+CEER

```
+CEER: Invalid/incomplete number
OK
```

5.2.9 AT+CCWA Call waiting

This command allows control of the Call Waiting supplementary service. Activation, deactivation and status query are supported. When querying the status of a network service (<mode>=2) the response line for 'not active' case (<status>=0) should be returned only if service is not active for any <class>. Parameter <n> is used to disable/enable the presentation of an unsolicited result code +CCWA: <number>,<type>,<class> to the TE when call waiting service is enabled. Command should be abortable when network is interrogated.

| AT+CCWA Call waiting | |
|--|--|
| Test Command AT+CCWA=? | Response +CCWA: (list of supported <n>s) OK |
| Read Command AT+CCWA? | Response +CCWA: <n> OK |
| Write Command AT+CCWA=<n>[,<mode>[,<class>]] | Response a)If successfully: When <mode>=2 and command successful: +CCWA:<status>,<class>[<CR><LF> +CCWA: <status>, <class>[...]] OK b)If failed: ERROR |
| Execution Command AT+CCWA | Response OK |
| Maximum Response Time | 120000ms |

Defined Values

| | |
|----------------------|--|
| <n> | Sets/shows the result code presentation status in the TA 0 – disable 1 – enable |
| <mode> | When <mode> parameter is not given, network is not interrogated: 0 – disable 1 – enable 2 – query status |
| <class> | It is a sum of integers each representing a class of information (default 7) 1 – voice (telephony) 2 – data (refers to all bearer services) 4 – fax (facsimile services) 7 – voice,data and fax(1+2+4) 8 – short message service 16 – data circuit sync 32 – data circuit async 64 – dedicated packet access 128 – dedicated PAD access |

| | |
|----------|---|
| | 255 – The value 255 covers all classes |
| <status> | 0 – not active 1 – active |
| <number> | String type phone number of calling address in format specified by <type>. |
| <type> | Type of address octet in integer format; 128 – Restricted number type includes unknown type and format 145 – International number type 129 – Otherwise |

Examples

```
AT+CCWA=?
```

```
+CCWA:(0-1)
```

```
OK
```

```
AT+CCWA?
```

```
+CCWA: 0
```

```
OK
```

5.2.10 AT+CHLD Call related supplementary services

This command allows the control the following call related services:

1. A call can be temporarily disconnected from the ME but the connection is retained by the network.
2. Multiparty conversation (conference calls).
3. The served subscriber who has two calls (one held and the other either active or alerting) can connect the other parties and release the served subscriber's own connection.

Calls can be put on hold, recovered, released, added to conversation, and transferred. This is based on the GSM/UMTS supplementary services.

AT+CHLD Call related supplementary services

| | |
|--|---|
| Test Command AT+CHLD=? | Response OK |
| Write Command AT+CHLD=<n> | Response OK or ERROR |
| Execution Command AT+CHLD Default to <n>=2. | Response OK or ERROR |

| | |
|-----------------------|--------------------------------------|
| | or +CME ERROR: <err> |
| Parameter Saving Mode | NO_SAVE |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-----|--|
| <n> | <ul style="list-style-type: none"> 0 – Terminate all held calls; or set User Determined User Busy for a waiting call 1 – Terminate all active calls and accept the other call (waiting call or held call) 1X – Terminate a specific call X 2 – Place all active calls on hold and accept the other call (waiting call or held call) as the active call 2X – Place all active calls except call X on hold 3 – Add the held call to the active calls 4 – Connect two calls and cut off the connection between users and them simultaneously |
|-----|--|

Example

```
AT+CHLD=?
+CHLD: (0,1,1x,2,2x,3,4)
OK
```

5.2.11 AT+CCFC Call forwarding number and conditions

This command allows control of the call forwarding supplementary service. Registration, erasure, activation, deactivation, and status query are supported.

AT+CCFC Call forwarding number and conditions

| | |
|--|---|
| Test Command AT+CCFC=? | Response +CCFC: (list of supported <reason>s) OK |
| Write Command AT+CCFC=<reason>,<mode>[,<number>[,<type>[,<class>[,<subaddr>[,<satype>[,<time>]]]]]] | Response When <mode>=2 and command successful: +CCFC: <status>,<class1>[,<number>,<type>[,<subaddr>,<satype>[,<time>]]][<CR><LF>+CCFC: <status>,<class2>[,<number>,<type>[,<subaddr>,<satype>[,<time>]]][...] OK |

| | |
|-----------------------|--|
| | When <mode>!=2 and command successful: OK or ERROR or +CME ERROR:<err> |
| Parameter Saving Mode | NO_SAVE |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-----------|---|
| <reason> | 0 – unconditional 1 – mobile busy 2 – no reply 3 – not reachable 4 – all call forwarding 5 – all conditional call forwarding |
| <mode> | 0 – disable 1 – enable 2 – query status 3 – registration 4 – erasure |
| <number> | String type phone number of forwarding address in format specified by <type>. |
| <type> | Type of address octet in integer format: 145 – dialing string <number> includes international access code character '+' 129 – otherwise |
| <subaddr> | String type sub address of format specified by <satype>. Subaddr length is 0-19. |
| <satype> | Type of sub address octet in integer format, default 128. |
| <classX> | It is a sum of integers each representing a class of information (default 7): 1 – voice (telephony) 2 – data (refers to all bearer services) 4 – fax (facsimile services) 16 – data circuit sync 32 – data circuit async 64 – dedicated packet access 128 – dedicated PAD access 255 – The value 255 covers all classes |
| <time> | 1..30 – when "no reply" is enabled or queried, this gives the time in seconds to wait before call is forwarded, default value 20. |

| | |
|----------|----------------|
| <status> | 0 – not active |
| | 1 – active |

Example

```
AT+CCFC=?
+CCFC: (0,1,2,3,4,5)
OK
AT+CCFC=0,2
+CCFC: 0,255
OK
```

5.2.12 AT+CLIP Calling line identification presentation

This command refers to the GSM/UMTS supplementary service CLIP (Calling Line Identification Presentation) that enables a called subscriber to get the calling line identity (CLI) of the calling party when receiving a mobile terminated call.

Write command enables or disables the presentation of the CLI at the TE. It has no effect on the execution of the supplementary service CLIP in the network.

When the presentation of the CLI at the TE is enabled (and calling subscriber allows), +CLIP: <number>, <type>,,[, [<alpha>][, <CLI validity>]] response is returned after every RING (or +CRING: <type>; refer sub clause "Cellular result codes +CRC") result code sent from TA to TE. It is manufacturer specific if this response is used when normal voice call is answered.

AT+CLIP Calling line identification presentation

| Test Command | Response |
|---|---|
| AT+CLIP=? | +CLIP: (list of supported <n>s) OK |
| Read Command AT+CLIP? | Response +CLIP: <n>, <m> OK or ERROR or +CME ERROR: <err> |
| Write Command AT+CLIP=<n> | Response OK or ERROR |
| Execution Command AT+CLIP | Response Set default value(<n>=0): OK |

| | |
|-----------------------|---------|
| Parameter Saving Mode | NO_SAVE |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|----------------|---|
| <n> | Parameter sets/shows the result code presentation status in the TA: 0 – disable 1 – enable |
| <m> | 0 – CLIP not provisioned 1 – CLIP provisioned 2 – unknown (e.g. no network, etc.) |
| <number> | String type phone number of calling address in format specified by <type> |
| <type> | Type of address octet in integer format; 128 – Restricted number type includes unknown type and format 145 – International number type 161 – national number.The network support for this type is optional 177 – network specific number,ISDN format 129 – Otherwise |
| <alpha> | String type alphanumeric representation of <number> corresponding to the entry found in phone book. |
| <CLI validity> | 0 – CLI valid 1 – CLI has been withheld by the originator 2 – CLI is not available due to interworking problems or limitations of originating network |

Example

```
AT+CLIP=1
OK
RING (with incoming call)
+CLIP: "02152063113",128,,,"gongsi",0
```

5.2.13 AT+CLIR Calling line identification restriction

This command refers to CLIR service that allows a calling subscriber to enable or disable the presentation of the CLI to the called party when originating a call.

Write command overrides the CLIR subscription (default is restricted or allowed) when temporary mode is provisioned as a default adjustment for all following outgoing calls. This adjustment can be revoked by using the opposite command.. If this command is used by a subscriber without provision of CLIR in permanent mode the network will act.

Read command gives the default adjustment for all outgoing calls (given in <n>), and also triggers an interrogation of the provision status of the CLIR service (given in <m>).

Test command returns values supported as a compound value.

| AT+CLIR Calling line identification restriction | |
|---|---|
| Test Command AT+CLIR=? | Response +CLIR: (list of supported <n>s) OK |
| Read Command AT+CLIR? | Response +CLIR <n>,<m> OK or ERROR or +CME ERROR: <err> |
| Write Command AT+CLIR=<n> | Response OK or ERROR or +CME ERROR: <err> |
| Parameter Saving Mode | NO_SAVE |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-----|--|
| <n> | 0 – presentation indicator is used according to the subscription of the CLIR service 1 – CLIR invocation 2 – CLIR suppression |
| <m> | 0 – CLIR not provisioned 1 – CLIR provisioned in permanent mode 2 – unknown (e.g. no network, etc.) 3 – CLIR temporary mode presentation restricted 4 – CLIR temporary mode presentation allowed |

Example

```
AT+CLIR=?
+CLIR:(0-2)
OK
```

5.2.14 AT+COLP Connected line identification presentation

This command refers to the GSM/UMTS supplementary service COLP(Connected Line Identification Presentation) that enables a calling subscriber to get the connected line identity (COL) of the called party after setting up a mobile originated call. The command enables or disables the presentation of the COL at the TE. It has no effect on the execution of the supplementary service COLR in the network.

When enabled (and called subscriber allows), +COLP:<number>, <type> [,<subaddr>, <satype> [,<alpha>]] intermediate result code is returned from TA to TE before any +CR responses. It is manufacturer specific if this response is used when normal voice call is established.

When the AT+COLP=1 is set, any data input immediately after the launching of "ATDXXX;" will stop the execution of the ATD command, which may cancel the establishing of the call.

| AT+COLP Connected line identification presentation | |
|--|--|
| Test Command AT+COLP=? | Response +COLP: (list of supported <n>s) OK |
| Read Command AT+COLP? | Response +COLP: <n>,<m> OK or ERROR or +CME ERROR: <err> |
| Write Command AT+COLP =<n> | Response OK or ERROR or +CME ERROR: <err> |
| Execution Command AT+COLP | Response Set default value(<n>=0, <m>=0): OK |
| Parameter Saving Mode | NO_SAVE |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-----|--|
| <n> | Parameter sets/shows the result code presentation status in the TA: 0 – disable 1 – enable |
| <m> | 0 – COLP not provisioned 1 – COLP provisioned 2 – unknown (e.g. no network, etc.) |

Example

```

AT+COLP?
+COLP: 1,0
OK
ATD10086;
VOICE CALL: BEGIN

+COLP: "10086",129,,,

OK

```

5.2.15 AT+VTS DTMF and tone generation

This command allows the transmission of DTMF tones and arbitrary tones which cause the Mobile Switching Center (MSC) to transmit tones to a remote subscriber. The command can only be used in voice mode of operation (active voice call).

NOTE: The END event of voice call will terminate the transmission of tones, and as an operator option, the tone may be ceased after a pre-determined time whether or not tone duration has been reached.

AT+VTS DTMF and tone generation

| | |
|---|--|
| Test Command AT+VTS=? | Response +VTS: (list of supported<dtmf>s) OK |
| Write Command AT+VTS=<dtmf> [,<duration>] | Response OK or ERROR |
| AT+VTS=<dtmf-string> | |
| Parameter Saving Mode | NO_SAVE |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|----------------------------|---|
| <dtmf> | A single ASCII character in the set 0-9, *, #, A, B, C, D. |
| <duration> | Tone duration in 1/10 seconds, from 0 to 255. This is interpreted as a DTMF tone of different duration from that mandated by the AT+VTD command, otherwise, the duration which be set the AT+VTD command will be used for the tone (<duration> is omitted). |
| <dtmf-string> | A sequence of ASCII character in the set 0-9, *, #, A, B, C, D, and |

maximal length of the string is 29. The string must be enclosed in double quotes (“”), and separated by commas between the ASCII characters (e.g. “1,3,5,7,9,*”). Each of the tones with a duration which is set by the AT+VTD command.

NOTE

- The value of <mode> shall be set to zero after a successfully completed alternating mode call. It shall be set to zero also after a failed answering. The power-on, factory and user resets shall also set the value to zero. This reduces the possibility that alternating mode calls are originated or answered accidentally.

Example

```
AT+VTS=1
OK
AT+VTS=1,20
OK
AT+VTS="1,3,5"
OK
AT+VTS=?
+VTS: (0-9,*,#,A,B,C,D)
OK
```

5.2.16 AT+VTD Tone duration

This refers to an integer <n> that defines the length of tones emitted as a result of the AT+VTS command. A value different than zero causes a tone of duration <n>/10 seconds.

| AT+VTD Tone duration | |
|--|--|
| Test Command AT+VTD=? | Response +VTD: (list of supported <n>s) OK |
| Read Command AT+VTD? | Response +VTD: <n> OK |
| Write Command AT+VTD=<n> | Response OK |
| Parameter Saving Mode | NO_SAVE |
| Maximum Response Time | - |

Reference

Defined Values

| | |
|------------------|--|
| <n> | Tone duration in integer format, from 0 to 255, and 0 is factory value. 0 Tone duration of every single tone is dependent on the network. 1...255 one duration of every single tone in 1/10 seconds. |
|------------------|--|

Example

```

AT+VTD=?
+VTD: (0-255)
OK
AT+VTD?
+VTD: 0
OK
AT+VTD=5
OK

```

5.2.17 AT+CSTA Select type of address

Write command is used to select the type of number for further dialing commands ([ATD](#)) according to GSM/UMTS specifications.

Read command returns the current type of number.

Test command returns values supported by the Module as a compound value.

| AT+CSTA Select type of address | |
|--|---|
| Test Command AT+CSTA=? | Response +CSTA:(list of supported <type>s) OK |
| Read Command AT+CSTA? | Response +CSTA:<type> OK |
| Write Command AT+CSTA=<type> | Response OK or ERROR |
| Execution Command AT+CSTA | Response OK |
| Parameter Saving Mode | NO_SAVE |
| Maximum Response Time | - |

Reference

Defined Values

| | |
|---------------------|--|
| <type> | Type of address octet in integer format: 145 – when dialling string includes international access code character “+” 161 – national number. The network support for this type is optional 177 – network specific number, ISDN format 129 – otherwise |
|---------------------|--|

NOTE

- Because the type of address is automatically detected on the dial string of dialling command, command AT+CSTA has really no effect.

Example

```
AT+CSTA?
+CSTA: 129
OK
AT+CSTA=145
OK
```

5.2.18 AT+CMOD Call mode

Write command is used to select the type of number for further dialling commands ([ATD](#)) according to GSM/UMTS specifications.

Read command returns the current type of number.

Test command returns values supported by the Module as a compound value.

AT+CMOD Call mode

| | |
|--|--|
| Test Command AT+CMOD=? | Response +CMOD: (list of supported <mode>s) OK |
| Read Command AT+CMOD? | Response +CMOD: <mode> OK |
| Write Command AT+CMOD=<mode> | Response OK or |

| | |
|-------------------------------------|--|
| | ERROR |
| Execution Command AT+CMOD | Response Set default value: OK |
| Parameter Saving Mode | NO_SAVE |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|--------|---------------------------------|
| <mode> | 0 – single mode(only supported) |
|--------|---------------------------------|

NOTE

- **NOTE:** The value of <mode> shall be set to zero after a successfully completed alternating mode call. It shall be set to zero also after a failed answering. The power-on, factory and user resets shall also set the value to zero. This reduces the possibility that alternating mode calls are originated or answered accidentally.

Example

```
AT+CMOD?
+CMOD: 0
OK
AT+CMOD=0
OK
```

6. AT Commands for Phonebook

6.1 Overview of AT Commands for Phonebook

| Command | Description |
|---------|---------------------------------|
| AT+CPBS | Select Phonebook memory storage |
| AT+CPBR | Read Phonebook entries |
| AT+CPBF | Find Phonebook entries |
| AT+CPBW | Write Phonebook entry |
| AT+CNUM | Subscriber number |

6.2 Detailed Description of AT Commands for Phonebook

6.2.1 AT+CPBS Select Phonebook memory storage

| AT+CPBS Select Phonebook memory entries | |
|---|---|
| Test Command AT+CPBS=? | Response +CPBS: (list of supported <storage>s) OK |
| Read Command AT+CPBS? | Response +CPBS: <storage>[,<used>,<total>] OK |
| Write Command AT+CPBS=<storage> | Response OK or ERROR If error is related to ME functionality: +CME ERROR: <err> |
| Execution Command AT+CPBS | Response (Set default value "SM") OK |

Defined Values

| | |
|-----------|--|
| <storage> | <p>Values reserved by the present document:</p> <p>"DC" ME dialed calls list Capacity: max. 100 entries AT+CPBW command is not applicable to this storage.</p> <p>"MC" ME missed (unanswered received) calls list Capacity: max. 100 entries AT+CPBW command is not applicable to this storage.</p> <p>"RC" ME received calls list Capacity: max. 100 entries AT+CPBW command is not applicable to this storage.</p> <p>"SM" SIM phonebook Capacity: depending on SIM card</p> <p>"ME" Mobile Equipment phonebook Capacity: max. 500 entries</p> <p>"FD" SIM fixdialling-phonebook Capacity: depending on SIM card</p> <p>"ON" MSISDN list Capacity: depending on SIM card</p> <p>"LD" Last number dialed phonebook Capacity: depending on SIM card AT+CPBW command is not applicable to this storage</p> <p>"EN" Emergency numbers Capacity: depending on SIM card AT+CPBW command is not applicable to this storage.</p> |
| <used> | Integer type value indicating the number of used locations in selected memory. |
| <total> | Integer type value indicating the total number of locations in selected memory. |

Example

```

AT+CPBS=?
+CPBS:
("SM","DC","FD","LD","MC","ME","RC","EN",
,"ON")

OK
AT+CPBS="SM"
OK

AT+CPBS?
+CPBS: "SM",1,200

```

OK

NOTE

- Select the active phonebook storage, i.e. the phonebook storage that all subsequent phonebook commands will be operating on

6.2.2 AT+CPBR Read Phonebook entries

| AT+CPBR Read Phonebook entries | |
|---|---|
| Test Command AT+CPBR=? | Response +CPBR: (<minIndex>-<maxIndex>), [<nlength>], [<tlength>] OK or If error is related to ME functionality: +CME ERROR: <err> |
| Write Command AT+CPBR=<index1>[,<index2>] | Response [+CPBR: <index1>,<number>,<type>,<text>[<CR><LF>+CPBR: <index2>,<number>,<type>,<text>[...]]] OK or ERROR If error is related to ME functionality: +CME ERROR: <err> |

Defined Values

| | |
|------------|---|
| <index1> | Integer type value in the range of location numbers of phonebook memory. |
| <index2> | Integer type value in the range of location numbers of phonebook memory. |
| <index> | Integer type. the current position number of the Phonebook index. |
| <minIndex> | Integer type the minimum <index> number. |
| <maxIndex> | Integer type the maximum <index> number. |
| <number> | String type, phone number of format <type>, the maximum length is <nlength>. |
| <type> | Type of phone number octet in integer format, default 145 when dialing string includes international access code character "+", |

| | |
|------------------------|---|
| | otherwise 129. |
| <text> | String type field of maximum length <tlength>; often this value is set as name. |
| <nlength> | Integer type value indicating the maximum length of field <number> |
| <tlength> | Integer type value indicating the maximum length of field <text>. |

Example

AT+CPBS?

+CPBS: "SM",2,200

OK

AT+CPBS=1,10

+CPBR: 1,"1234567890",129,"James"

+CPBR: 2,"0987654321",129,"Kevin"

OK

NOTE

- If the storage is selected as "SM" then the command will return the record in SIM phonebook, the same to others.

6.2.3 AT+CPBF Find Phonebook entries

AT+CPBF Find Phonebook entries

Test Command

AT+CPBF=?

Response

+CPBF: [<nlength>],[<tlength>]

OK

Write Command

AT+CPBF=[<findtext>]

Response

[+CPBF: <index1>,<number>,<type>,<text>[<CR><LF>

+CPBF: <indexN>,<number>,<type>,<text>[...]]]

OK

or

ERROR

If error is related to ME functionality:

+CME ERROR: <err>

Defined Values

| | |
|------------|--|
| <findtext> | String type, this value is used to find the record. Character set should be the one selected with command AT+CSCS. |
| <index> | Integer type. the current position number of the Phonebook index. |
| <number> | String type, phone number of format <type>, the maximum length is <nlength>. |
| <type> | Type of phone number octet in integer format, default 145 when dialing string includes international access code character "+", otherwise 129. |
| <text> | String type field of maximum length <tlength>; often this value is set as name. |
| <nlength> | Integer type value indicating the maximum length of field <number> |
| <tlength> | Integer type value indicating the maximum length of field <text>. |

Example

```
AT+CPBF="James"
+CPBF: 1,"1234567890",129,"James"
```

OK

NOTE

- If <findtext> is null, it will lists all the entries.

6.2.4 AT+CPBW Write Phonebook entry

AT+CPBW Write Phonebook entry

| | |
|----------------------------------|---|
| Test Command AT+CPBW=? | Response +CPBW:(list of supported <index>s),[<nlength>], (list of supported <type>s),[<tlength>] OK or ERROR If error is related to ME functionality: +CME ERROR: <err> |
| Write Command | Response |

AT+CPBW=[<index>][,<number>,<type>,<text>]]

OK

or

ERROR

If error is related to ME functionality:

+CME ERROR: <err>

Defined Values

| | |
|------------------------|---|
| <index> | Integer type values in the range of location numbers of phonebook memory.If <index> is not given, the first free entry will be used. If <index> is given as the only parameter, the phonebook entry specified by <index> is deleted.If record number <index> already exists, it will be overwritten. |
| <number> | String type, phone number of format <type>, the maximum length is <nlength>. It must be a non-empty string. |
| <type> | Type of address octet in integer format, The range of value is from 129 to 255. If <number> contains a leading "+" <type> = 145 (international) is used.Supported value are: 145 – when dialling string includes international access code character "+" 161 – national number.The network support for this type is optional 177 – network specific number,ISDN format 129 – otherwise NOTE: Other value refer TS 24.008 [8] subclause 10.5.4.7. |
| <text> | String type field of maximum length <tlength>; character set as specified by command Select TE Character Set AT+CSCS. |
| <nlength> | Integer type value indicating the maximum length of field <number>. |
| <tlength> | Integer type value indicating the maximum length of field <text>. |

Example

AT+CPBW=3,"88888888",129,"John"

OK

AT+CPBW="6666666",129,"mary"

OK

AT+CPBW=1

OK

NOTE

- NOTE: If the parameters of <type> and <text> are omitted and the first character of <number> is

'+', it will specify <type> as 145(129 if the first character isn't '+') and <text> as NULL.

6.2.5 AT+CNUM Subscriber number

| AT+CNUM Subscriber number | |
|-------------------------------------|--|
| Test Command AT+CNUM=? | Response OK |
| Execution Command AT+CNUM | Response [+CNUM: <alpha>,<number>,<type>[<CR><LF> +CNUM: <alpha>,<number>,<type> [...]] OK or If error is related to ME functionality: +CME ERROR: <err> |

Defined Values

| | |
|----------|--|
| <alpha> | Optional alphanumeric string associated with <number>, used character set should be the one selected with command Select TE Character Set AT+CSCS. |
| <number> | String type phone number of format specified by <type>. |
| <type> | Type of address octet in integer format.see also AT+CPBR <type> |

Example

```
AT+CNUM
+CNUM: "", "13697252277", 129

OK
```

NOTE

- If subscriber has different MSISDN for different services, each MSISDN is returned in a separate line

7. AT Commands for SIM Application Toolkit

7.1 Overview of AT Commands for SIM Application Toolkit

| Command | Description |
|-----------|---------------------------------------|
| AT+STIN | SAT Indication |
| AT+STGI | Get SAT information |
| AT+STGR | SAT respond |
| AT+STK | STK switch |
| AT+STKFMT | Set STK pdu format |
| AT+STENV | Original STK PDU Envelope Command |
| AT+STSM | Get STK Setup Menu List with PDU Mode |

7.2 Detailed Description of AT Commands for SIM Application Toolkit

7.2.1 AT+STIN SAT Indication

| AT+STIN SAT Indication | |
|----------------------------------|---|
| Test Command AT+STIN=? | Response OK |
| Read Command AT+STIN? | +STIN: <cmd_id> OK |

Unsolicited Result Codes

| | |
|-----------------------|--------------------------------|
| <cmd_id> | Proactive Command notification |
| | 21 Display text |
| | 22 Get inkey |
| | 23 Get input |

| | |
|------------------|--|
| | 24 Select item |
| +STIN: 25 | Notification that SIM Application has returned to main menu. If user doesn't do any action in 2 minutes, application will return to main menu automatically. |

Defined Values

| | |
|-----------------------|---|
| <cmd_id> | 21 Display text 22 Get inkey 23 Get input 24 Select item 25 Set up menu 81 Session end (pdu mode only) 0 None command |
| <time> | Service time |

Example

AT+STIN?

+STIN: 24

OK

NOTE

- Every time the SIM Application issues a Proactive Command, via the ME, the TA will receive an indication. This indicates the type of Proactive Command issued.

7.2.2 AT+STGI Get SAT information

AT+STGI Get SAT information

| | |
|--|---|
| Test Command AT+STGI=? | Response OK |
| Write Command AT+STGI=<cmd_id> | Response (<i>PDU format</i>) +STGI: <cmd_id>,<tag>,<pdu_len>,<pdu_value> OK |
| AT+STGI=<cmd_id> | Response (<i>NOT PDU format, listed below</i>) If <cmd_id>=10: OK If <cmd_id>=21: |


```

+STGI: 21,<prio>,<clear_mode>,<text_len>,<text>
OK
If <cmd_id>=22:
+STGI: 22,< rsp_format>,< help>,<text_len>,<text>
OK
If <cmd_id>=23:
+STGI:
23,<rsp_format>,<max_len>,<min_len>,<help>,<show>,<text_len
>,<text>
OK
If <cmd_id>=24:
+STGI:
24,<help>,<softkey>,<present>,<title_len>,<title>,<item_num>
+STGI: 24,<item_id>,<item_len>,<item_data>
[...]
OK
If <cmd_id>=25:
+STGI: 25,<help>,<softkey>,<title_len>,<title>,<item_num>
+STGI: 25,<item_id>,<item_len>,<item_data>
[...]
OK

```

Defined Values

| | |
|---------------------------|---|
| <cmd_id> | Proactive Command notification 21 Display text 22 Get inkey 23 Get input 24 Select item 25 Set up menu |
| <prio> | Priority of display text 0 Normal priority 1 High priority |
| <clear_mode> | 0 Clear after a delay 1 Clear by user |
| <text_len> | Length of text |
| <rsp_format> | 0 SMS default alphabet 1 YES or NO 2 numerical only 3 UCS2 |
| <help> | 0 Help unavailable 1 Help available |
| <max_len> | Maximum length of input |
| <min_len> | Minimum length of input |
| <show> | 0 Hide input text |

| | |
|-------------|--|
| | 1 Display input text |
| <softkey> | 0 No softkey preferred 1 Softkey preferred |
| <present> | Menu presentation format available for select item 0 Presentation not specified 1 Data value presentation 2 Navigation presentation |
| <title_len> | Length of title |
| <item_num> | Number of items in the menu |
| <item_id> | Identifier of item |
| <item_len> | Length of item |
| <title> | Title in ucs2 format |
| <item_data> | Content of the item in ucs2 format |
| <text> | Text in ucs2 format. |
| <tag> | Not used now. |
| <pdu_len> | Integer type, pdu string length |
| <pdu_val> | String type, the pdu string. |

Example

AT+STGI=25 (NOT PDU format)

```
+STGI:
25,0,0,10,"795E5DDE884C59295730",15
+STGI: 25,1,8,"8F7B677E95EE5019"
+STGI: 25,2,8,"77ED4FE17FA453D1"
+STGI: 25,3,8,"4F1860E05FEB8BAF"
+STGI: 25,4,8,"4E1A52A17CBE9009"
+STGI: 25,5,8,"8D448D3963A88350"
+STGI: 25,6,8,"81EA52A9670D52A1"
+STGI: 25,7,8,"8F7B677E5F6994C3"
+STGI: 25,8,8,"8BED97F367425FD7"
+STGI: 25,9,10,"97F34E506392884C699C"
+STGI: 25,10,8,"65B095FB59296C14"
+STGI: 25,11,8,"94C358F056FE7247"
+STGI: 25,12,8,"804A59294EA453CB"
+STGI: 25,13,8,"5F005FC34F1195F2"
+STGI: 25,14,8,"751F6D3B5E388BC6"
+STGI:
25,21,12,"00530049004D53614FE1606F"
```

OK

AT+STGI=24 (PDU format)

```
+STGI:
```

```
24,0,48,"D02E81030124008202818285098070
ED70B963A883508F0A018053057F574E078C
618F0C02809177917777ED6D88606F"
OK
```

7.2.3 AT+STGR SAT respond

| AT+STGR SAT respond | |
|---|---|
| Test Command AT+STGR=? | Response OK |
| Write Command AT+STGR=<cmd_id>[,<data>] | Response (<i>NOT PDU format</i>) OK |
| AT+STGR=<pdu_len>,<pdu_value> | Response (<i>PDU format</i>) OK |

Defined Values

| | |
|-----------------------|---|
| <cmd_id> | Proactive Command notification 21 Display text 22 Get inkey 23 Get input 24 Select item 25 Set up menu 81 Session end 83 Session end by user 84 Go backward |
| <data> | If <cmd_id>=22: Input a character If <cmd_id>=23: Input a string. If <rsp_format> is YES or NO, input of a character in case of ANSI character set requests one byte, e.g. "Y". If <rsp_format> is numerical only, input the characters in decimal number, e.g. "123" If <rsp_faomat> is UCS2, requests a 4 byte string, e.g. "0031" <rsp_faomat> refer to the response by AT+STGI=23 If <cmd_id>=24: Input the identifier of the item selected by user If <cmd_id>=25: Input the identifier of the item selected by user If <cmd_id>=83: |

| | |
|-------------|--|
| | <p><data> ignore</p> <p>Note: It could return main menu during Proactive Command id is not 22 or 23</p> <p>If <cmd_id>= 84:</p> <p><data> ignore</p> |
| <pdu_len> | Integer type, pdu string length |
| <pdu_value> | String type, the pdu string. |

Example

AT+STGR=25,1 (NOT PDU format)

OK

+STIN: 24

AT+STGR=30,"8103012400020282818301009

00101" (PDU format)

OK

NOTE

- After selected an item, different SIM/USIM cards will report different +STIN: command.

7.2.4 AT+STK STK switch

| AT+STK STK switch | |
|--|---|
| Test Command AT+STK=? | Response +STK: (list of supported <value>s) OK |
| Read Command AT+STK? | Response +STK: <value> OK |
| Write Command AT+STK=<value> | Response OK or ERROR |
| Execution Command AT+STK | Response OK |

Defined Values

| | | |
|---------|---|-------------|
| <value> | 0 | Disable STK |
| | 1 | Enable STK |

Example

```
AT+STK=1
OK
```

NOTE

- Module should reboot to take effective

7.2.5 AT+STKFMT Set STK pdu format

AT+STKFMT Set STK pdu format

| | |
|---|--|
| Read Command AT+STKFMT? | Response +STKFMT: <value> OK |
| Write Command AT+STKFMT=<value> | Response OK or ERROR |

Defined Values

| | | |
|---------|---|---|
| <value> | 0 | Disable STK pdu format, decoded command mode. |
| | 1 | Enable STK pdu format |

Example

```
AT+STKFMT=1
OK
```

NOTE

- Module should reboot to take effective

7.2.6 AT+STENV Original STK PDU Envelope Command

AT+STENV Original STK PDU Envelope Command

| | |
|--|---|
| Test Command AT+STENV=? | Response OK |
| Write Command AT+STENV=<len>,<pdu> | Response OK or ERROR |

Defined Values

| | |
|-------|---------------------------------|
| <len> | Integer type, pdu string length |
| <pdu> | String type, pdu value |

Example

```
AT+STENV=18,"D30782020181900101"  
OK
```

NOTE

- Module should reboot to take effective

7.2.7 AT+STSM Get STK Setup Menu List with PDU Mod

AT+STSM Get STK Setup Menu List with PDU Mod

| | |
|----------------------------------|--|
| Test Command AT+STSM=? | Response OK |
| Read Command AT+STSM? | Response +STSM: <cmd_id>,<tag>,<pdu_len>, <pdu_value> OK or ERROR |

Defined Values

| | |
|-------------|---------------------------------------|
| <cmd_id> | Integer type, please refer to AT+STIN |
| <tag> | Not used now. |
| <pdu_len> | Integer type, pdu string length |
| <pdu_value> | String type, the pdu string. |

Example

AT+STSM?

+STSM:

```
25,0,120,"D0768103012500820281828507806
5B052BF529B8F0A018070ED70B963A883508
F06028070AB94C38F0A03806D41884C77ED4
FE18F0A048081EA52A9670D52A18F0A05806
24B673A97F34E508F0606808D854FE18F0A0
7805A314E50753162118F0A0880767E53D875
1F6D3B8F0A09806D596C5F98919053"
```

OK

NOTE

- Setup main menu info got first before envelope command sent.

8. AT Commands for GPRS

8.1 Overview of AT Commands for GPRS

| Command | Description |
|-------------|---|
| AT+CGREG | GPRS network registration status |
| AT+CGATT | Packet domain attach or detach |
| AT+CGACT | PDP context activate or deactivate |
| AT+CGDCONT | Define PDP context |
| AT+CGDSCONT | Define Secondary PDP Context |
| AT+CGTFT | Traffic Flow Template |
| AT+CGQREQ | Quality of service profile (requested) |
| AT+CGEQREQ | 3G quality of service profile (requested) |
| AT+CGQMIN | Quality of service profile (minimum acceptable) |
| AT+CGEQMIN | 3G quality of service profile (minimum acceptable) |
| AT+CGDATA | Enter data state |
| AT+CGPADDR | Show PDP address |
| AT+CGCLASS | GPRS mobile station class |
| AT+CGEREP | GPRS event reporting |
| AT+CGAUTH | Set type of authentication for PDP-IP connections of GPRS |

8.2 Detailed Description of AT Commands for GPRS

8.2.1 AT+CGREG GPRS network registration status

This command controls the presentation of an unsolicited result code “+CGREG: <stat>” when <n>=1 and there is a change in the MT’s GPRS network registration status.

The read command returns the status of result code presentation and an integer <stat> which shows whether the network has currently indicated the registration of the MT.

AT+CGREG GPRS network registration status

| | |
|--|--|
| Test Command AT+CGREG=? | Response +CGREG: (list of supported <n>s) OK |
| Read Command AT+CGREG? | Response +CGREG: <n>,<stat>[,<lac>,<ci>] OK |
| Write Command AT+CGREG=<n> | Response OK |
| Execution Command Set default value: AT+CGREG | Response OK |

Defined Values

| | |
|--------|---|
| <n> | <ul style="list-style-type: none"> 0 – disable network registration unsolicited result code 1 – enable network registration unsolicited result code +CGREG: <stat> 2 – there is a change in the ME network registration status or a change of the network cell: +CGREG: <stat>[,<lac>,<ci>] |
| <stat> | <ul style="list-style-type: none"> 0 – not registered, ME is not currently searching an operator to register to 1 – registered, home network 2 – not registered, but ME is currently trying to attach or searching an operator to register to 3 – registration denied 4 – unknown 5 – registered, roaming |
| <lac> | Two bytes location area code in hexadecimal format (e.g."00C3" equals 193 in decimal). |
| <ci> | Cell ID in hexadecimal format. GSM : Maximum is two byte WCDMA : Maximum is four byte TDS-CDMA : Maximum is four byte |

NOTE

The <lac> not supported in CDMA/HDR mode
The <ci> not supported in CDMA/HDR mode

Example

```
AT+CGREG=?
+CGREG: (0-1)

OK
AT+CGREG?
+CGREG: 0,0

OK
```

8.2.2 AT+CGATT Packet domain attach or detach

The write command is used to attach the MT to, or detach the MT from, the Packet Domain service. The read command returns the current Packet Domain service state.

AT+CGATT Packet domain attach or detach

| | |
|--|---|
| Test Command AT+CGATT=? | Response +CGATT: (list of supported <state>s) OK |
| Read Command AT+CGATT? | Response +CGATT: <state> OK |
| Write Command AT+CGATT=<state> | Response OK or ERROR or +CME ERROR: <err> |

Defined Values

| | |
|----------------------|--|
| <state> | Indicates the state of Packet Domain attachment: 0 – detached 1 – attached |
|----------------------|--|

Example

```
AT+CGATT?
+CGATT: 0
```

```
OK
AT+CGATT=1
OK
```

8.2.3 AT+CGACT GPRS network registration status

The write command is used to activate or deactivate the specified PDP context (s).

| AT+CGACT GPRS network registration status | |
|--|--|
| Test Command AT+CGACT=? | Response +CGACT: (list of supported <state>s) OK |
| Read Command AT+CGACT? | Response +CGACT: [<cid>, <state> [<CR><LF> +CGACT: <cid>, <state> [...]] OK |
| Write Command AT+CGACT=<state>[,<cid>] | Response OK or ERROR or +CME ERROR: <err> |

Defined Values

| | |
|---------|---|
| <state> | Indicates the state of PDP context activation: 0 – deactivated 1 – activated |
| <cid> | A numeric parameter which specifies a particular PDP context definition (see AT+CGDCONT command). 1...16 |

Example

```
AT+CGACT=?
+CGACT: (0,1)

OK
```

AT+CGACT?

+CGACT: 1,1

OK

AT+CGACT=0,1

OK

8.2.4 AT+CGDCONT Define PDP context

The set command specifies PDP context parameter values for a PDP context identified by the (local) context identification parameter <cid>. The number of PDP contexts that may be in a defined state at the same time is given by the range returned by the test command. A special form of the write command (**AT+CGDCONT=<cid>**) causes the values for context <cid> to become undefined.

| AT+CGDCONT Define PDP context | |
|---|--|
| Test Command AT+CGDCONT=? | Response +CGDCONT: (range of supported<cid>s),<PDP_type>,,,(list of supported <d_comp>s),(list of supported <h_comp>s) (list of <ipv4_ctrl>s),(list of <emergency_flag>s) OK or ERROR |
| Read Command AT+CGDCONT? | Response +CGDCONT: [<cid>, <PDP_type>,<APN>,<PDP_addr>,<d_comp>,<h_comp><ipv4_ctrl>,<emergency_flag>[<CR><LF>+CGDCONT: <cid>, <PDP_type>, <APN>,<PDP_addr>, <d_comp>,<h_comp>< ipv4_ctrl>,<emergency_flag>[...]]] OK or ERROR |
| Write Command AT+CGDCONT=<cid>[,<PDP_type>[,<APN>[,<PDP_addr>[,<d_comp>[,<h_comp>[,<ipv4_ctrl>[,<emergency_flag>]]]]]]] | Response OK or ERROR |
| Execution Command Set default value: AT+CGDCONT | Response OK or |

ERROR

Defined Values

| | |
|------------|---|
| <cid> | (PDP Context Identifier) a numeric parameter which specifies a particular PDP context definition. The parameter is local to the TE-MT interface and is used in other PDP context-related commands. The range of permitted values (minimum value = 1) is returned by the test form of the command. 1...16,100...179 |
| <PDP_type> | (Packet Data Protocol type) a string parameter which specifies the type of packet data protocol. IP Internet Protocol PPP Point to Point Protocol IPV6 Internet Protocol Version 6 IPV4V6 Dual PDN Stack |
| <APN> | (Access Point Name) a string parameter which is a logical name that is used to select the GGSN or the external packet data network. |
| <PDP_addr> | A string parameter that identifies the MT in the address space applicable to the PDP. Read command will continue to return the null string even if an address has been allocated during the PDP startup procedure. The allocated address may be read using command AT+CGPADDR . |
| <d_comp> | A numeric parameter that controls PDP data compression, this value may depend on platform: 0 – off (default if value is omitted) 1 – on 2 – V.42bis |
| <h_comp> | A numeric parameter that controls PDP header compression, this value may depend on platform: 0 – off (default if value is omitted) 1 – on 2 – RFC1144 3 – RFC2507 4 – RFC3095 |

Example

```

AT+CGDCONT=?
+CGDCONT:
(1-24,100-179),"IP",,,(0-2),(0-4),(0-1),(0-1)
+CGDCONT:
(1-24,100-179),"PPP",,,(0-2),(0-4),(0-1),(0-1)
+CGDCONT:
(1-24,100-179),"IPV6",,,(0-2),(0-4),(0-1),(0-1)
+CGDCONT:

```

(1-24,100-179),"IPV4V6",,,(0-2),(0-4),(0-1),(0-1)

OK

AT+CGDCONT?

+CGDCONT: 1,"IP",,"","0.0.0.0",0,0

OK

8.2.5 AT+CGDSCONT Define Secondary PDP Context

The set command specifies PDP context parameter values for a Secondary PDP context identified by the (local) context identification parameter, <cid>. The number of PDP contexts that may be in a defined state at the same time is given by the range returned by the test command. A special form of the set command, AT+CGDSCONT=<cid> causes the values for context number <cid> to become undefined.

AT+CGDSCONT Define Secondary PDP Context

Test Command
AT+CGDSCONT=?

Response

+CGDSCONT: (range of supported <cid>s),(list of <p_cid>s for active primary contexts), <PDP_type>,,,(list of supported <d_comp>s),(list of supported <h_comp>s)

OK

or

ERROR

Read Command
AT+CGDSCONT?

Response

+CGDSCONT: [<cid>,<p_cid>,<d_comp>,<h_comp>
[<CR><LF>+CGDSCONT: <cid>,<p_cid>,<d_comp>,<h_comp>
[...]]]

OK

or

ERROR

Write Command
**AT+CGDSCONT=<cid>[,<p_
cid>[,<d_comp>[,<h_comp>
]]]**

Response

OK

or

ERROR

Defined Values

<cid>

a numeric parameter which specifies a particular PDP context definition. The parameter is local to the TE-MT interface and is used in other PDP

| | |
|------------|--|
| | context-related commands. The range of permitted values (minimum value = 1) is returned by the test form of the command. |
| <p_cid> | a numeric parameter which specifies a particular PDP context definition which has been specified by use of the +CGDCONT command. The parameter is local to the TE-MT interface. The list of permitted values is returned by the test form of the command. |
| <PDP_type> | (Packet Data Protocol type) a string parameter which specifies the type of packet data protocol. IP Internet Protocol PPP Point to Point Protocol IPV6 Internet Protocol Version 6 IPV4V6 Dual PDN Stack |
| <d_comp> | a numeric parameter that controls PDP data compression (applicable for SNDCPonly) (refer 3GPP TS 44.065 [61]) 0 off 1 on (manufacturer preferred compression) 2 V.42bis Other values are reserved. |
| <h_comp> | a numeric parameter that controls PDP header compression (refer 3GPP TS 44.065 [61] and 3GPP TS 25.323 [62]) 0 off 1 on (manufacturer preferred compression) 2 RFC1144 (applicable for SNDCP only) 3 RFC2507 4 RFC3095 (applicable for PDCP only) Other values are reserved. |

NOTE

The <cid>s for network-initiated PDP contexts will have values outside the ranges indicated for the <cid> in the test form of the commands +CGDCONT and +CGDSCONT.

Example

AT+CGDSCONT=?

+CGDSCONT: (1-24,100-179),(), "IP", (0-2), (0-4)

+CGDSCONT: (1-24,100-179),(), "PPP", (0-2), (0-4)

+CGDSCONT:

(1-24,100-179),(), "IPV6", (0-2), (0-4)

+CGDSCONT:

(1-24,100-179),(), "IPV4V6", (0-2), (0-4)

```
OK
AT+CGDSCONT?
+CGDSCONT: 2,1,0,0

OK
AT+CGDSCONT=2,1
OK
```

8.2.6 AT+CGTFT Traffic Flow Template

This command allows the TE to specify a Packet Filter - PF for a Traffic Flow Template - TFT that is used in the GGSN in UMTS/GPRS and Packet GW in EPS for routing of packets onto different QoS flows towards the TE. The concept is further described in the 3GPP TS 23.060 [47]. A TFT consists of from one and up to 16 Packet Filters, each identified by a unique <packet filter identifier>. A Packet Filter also has an <evaluation precedence index> that is unique within all TFTs associated with all PDP contexts that are associated with the same PDP address.

AT+CGTFT Traffic Flow Template

| Test Command | Response |
|-------------------|---|
| AT+CGTFT=? | <p>+CGTFT: <PDP_type>,(list of supported <packet filter identifier>s),(list of supported <evaluation precedence index>s),(list of supported <source address and subnet mask>s),(list of supported <protocol number (ipv4) / next header (ipv6)>s),(list of supported <destination port range>s),(list of supported <source port range>s),(list of supported <ipsec security parameter index (spi)>s),(list of supported <type of service (tos) (ipv4) and mask / traffic class (ipv6) and mask>s),(list of supported <flow label (ipv6)>s),(list of supported <direction>s)</p> <p>[<CR><LF>+CGTFT: <PDP_type>,(list of supported <packet filter identifier>s),(list of supported <evaluation precedence index>s),(list of supported <source address and subnet mask>s),(list of supported <protocol number (ipv4) / next header (ipv6)>s),(list of supported <destination port range>s),(list of supported <source port range>s),(list of supported <ipsec security parameter index (spi)>s),(list of supported <type of service (tos) (ipv4) and mask / traffic class (ipv6) and mask>s),(list of supported <flow label (ipv6)>s),(list of supported <direction>s)</p> <p>[...]</p> <p>OK</p> |

| | |
|--|---|
| <cid> | a numeric parameter which specifies a particular PDP context definition (see the AT+CGDCONT and AT+CGDSCONT commands). |
| <PDP_type> | (Packet Data Protocol type) a string parameter which specifies the type of packet data protocol. IP Internet Protocol PPP Point to Point Protocol IPV6 Internet Protocol Version 6 IPV4V6 Dual PDN Stack |
| <packet filter identifier> | a numeric parameter, value range from 1 to 16. |
| <evaluation precedence index> | a numeric parameter. The value range is from 0 to 255. |
| <source address and subnet mask> | string type The string is given as dot-separated numeric (0-255) parameters on the form: "a1.a2.a3.a4.m1.m2.m3.m4" for IPv4 or "a1.a2.a3.a4.a5.a6.a7.a8.a9.a10.a11.a12.a13.a14.a15.a16.m1.m2.m3.m4.m5.m6.m7.m8.m9.m10.m11.m12.m13.m14.m15.m16", for IPv6. |
| <protocol number (ipv4) / next header (ipv6)> | a numeric parameter, value range from 0 to 255. |
| <destination port range> | string type. The string is given as dot-separated numeric (0-65535) parameters on the form "f.t". |
| <source port range> | string type. The string is given as dot-separated numeric (0-65535) parameters on the form "f.t". |
| <ipsec security parameter index (spi)> | numeric value in hexadecimal format. The value range is from 00000000 to FFFFFFFF. |
| <type of service (tos) (ipv4) and mask / traffic class (ipv6) and mask> | string type. The string is given as dot-separated numeric (0-255) parameters on the form "t.m". |
| <flow label (ipv6)> | numeric value in hexadecimal format. The value range is from 00000 to FFFFF. Valid for IPv6 only. |
| <direction> | a numeric parameter which specifies the transmission direction in which the packet filter shall be applied. 0 Pre-Release 7 TFT filter (see 3GPP TS 24.008 [8], table 10.5.162) 1 Uplink 2 Downlink 3 Birectional (Up & Downlink) |

Example

AT+CGTFT=?

+CGTFT:

"IP",(1-16),(0-255),,(0-255),(0-65535.0-65535),(0-65535.0-65535),(0-FFFFFFF),(0-255.0-255),(0-FFF FFF)

+CGTFT:

"PPP",(1-16),(0-255),,(0-255),(0-65535.0-65535),(0-65535.0-65535),(0-FFFFFFF),(0-255.0-255),(0-FFFFF)

+CGTFT:

"IPV6",(1-16),(0-255),,(0-255),(0-65535.0-65535),(0-65535.0-65535),(0-FFFFFFFF),(0-255.0-255),(0-FFFFF)

+CGTFT:

"IPV4V6",(1-16),(0-255),,(0-255),(0-65535.0-65535),(0-65535.0-65535),(0-FFFFFFFF),(0-255.0-255),(0-FFFFF)

OK

AT+CGTFT?

+CGTFT: 2,1,0,"74.125.71.99.255.255.255.255",0,0,0,0,0,0,0

OK

AT+CGTFT=2,1,0,"74.125.71.99.255.255.255.255"

OK

8.2.7 AT+CGQREQ Quality of service profile (requested)

This command allows the TE to specify a Quality of Service Profile that is used when the MT sends an Activate PDP Context Request message to the network. A special form of the set command (AT+CGQREQ=<cid>) causes the requested profile for context number <cid> to become undefined.

AT+CGQREQ Quality of service profile (requested)

Test Command

AT+CGQREQ=?

Response

+CGQREQ: <PDP_type>, (list of supported <precedence>s), (list of supported <delay>s), (list of supported <reliability>s) , (list of supported <peak>s), (list of supported <mean>s) [<CR><LF>
+CGQREQ: <PDP_type>, (list of supported <precedence>s), (list of supported <delay>s), (list of supported <reliability>s) , (list of supported <peak>s), (list of supported <mean>s)
[...]]

OK

or

ERROR

Read Command

AT+CGQREQ?

Response

+CGQREQ: [<cid>, <precedence >, <delay>, <reliability>, <peak>, <mean>]<CR><LF>
+CGQREQ: <cid>, <precedence >, <delay>, <reliability.>, <peak>, <mean>[...]]

OK

or

| | |
|---|---|
| | ERROR |
| Write Command AT+CGQREQ=<cid>[,<precedence>[,<delay>[,<reliability>[,<peak> [,<mean>]]]]] | Response OK or ERROR |
| Execution Command AT+CGQREQ | Response OK or ERROR |

Defined Values

| | |
|----------------------------|---|
| <cid> | A numeric parameter which specifies a particular PDP context definition (see AT+CGDCONT command). The range is from 1 to 42,100 to 179. |
| <PDP_type> | (Packet Data Protocol type) a string parameter which specifies the type of packet data protocol. IP Internet Protocol PPP Point to Point Protocol IPV6 Internet Protocol Version 6 IPV4V6 Dual PDN Stack |
| <precedence> | A numeric parameter which specifies the precedence class: 0 – network subscribed value 1 – high priority 2 – normal priority 3 – low priority |
| <delay> | A numeric parameter which specifies the delay class: 0 – network subscribed value 1 – delay class 1 2 – delay class 2 3 – delay class 3 4 – delay class 4 |
| <reliability> | A numeric parameter which specifies the reliability class: 0 – network subscribed value 1 – Non real-time traffic,error-sensitive application that cannot cope with data loss 2 – Non real-time traffic,error-sensitive application that can cope with infrequent data loss 3 – Non real-time traffic,error-sensitive application that can cope with data loss, GMM/-SM,and SMS 4 – Real-time traffic,error-sensitive application that can cope with data loss 5 – Real-time traffic error non-sensitive application that can cope with data loss |
| <peak> | A numeric parameter which specifies the peak throughput class: |

| | |
|---------------------|--|
| | 0 – network subscribed value |
| | 1 – Up to 1000 (8 kbit/s) |
| | 2 – Up to 2000 (16 kbit/s) |
| | 3 – Up to 4000 (32 kbit/s) |
| | 4 – Up to 8000 (64 kbit/s) |
| | 5 – Up to 16000 (128 kbit/s) |
| | 6 – Up to 32000 (256 kbit/s) |
| | 7 – Up to 64000 (512 kbit/s) |
| | 8 – Up to 128000 (1024 kbit/s) |
| | 9 – Up to 256000 (2048 kbit/s) |
| <mean> | A numeric parameter which specifies the mean throughput class: |
| | 0 – network subscribed value |
| | 1 – 100 (~0.22 bit/s) |
| | 2 – 200 (~0.44 bit/s) |
| | 3 – 500 (~1.11 bit/s) |
| | 4 – 1000 (~2.2 bit/s) |
| | 5 – 2000 (~4.4 bit/s) |
| | 6 – 5000 (~11.1 bit/s) |
| | 7 – 10000 (~22 bit/s) |
| | 8 – 20000 (~44 bit/s) |
| | 9 – 50000 (~111 bit/s) |
| | 10 – 100000 (~0.22 kbit/s) |
| | 11 – 200000 (~0.44 kbit/s) |
| | 12 – 500000 (~1.11 kbit/s) |
| | 13 – 1000000 (~2.2 kbit/s) |
| | 14 – 2000000 (~4.4 kbit/s) |
| | 15 – 5000000 (~11.1 kbit/s) |
| | 16 – 10000000 (~22 kbit/s) |
| | 17 – 20000000 (~44 kbit/s) |
| | 18 – 50000000 (~111 kbit/s) |
| | 31 – optimization |

Example

AT+CGQREQ=?

+CGQREQ: "IP",(0-3),(0-4),(0-5),(0-9),(0-18,31)

+CGQREQ: "PPP",(0-3),(0-4),(0-5),(0-9),(0-18,31)

+CGQREQ: "IPV6",(0-3),(0-4),(0-5),(0-9),(0-18,31)

+CGQREQ: "IPV4V6",(0-3),(0-4),(0-5),(0-9),(0-18,31)

OK

AT+CGREG?

+CGQREQ:

OK

8.2.8 AT+CGEQREQ 3G quality of service profile (requested)

The test command returns values supported as a compound value.

The read command returns the current settings for each defined context for which a QOS was explicitly specified.

The write command allows the TE to specify a Quality of Service Profile for the context identified by the context identification parameter **<cid>** which is used when the MT sends an Activate PDP Context Request message to the network.

A special form of the write command, **AT+CGEQREQ=<cid>** causes the requested profile for context number **<cid>** to become undefined.

| AT+CGEQREQ 3G quality of service profile (requested) | |
|--|---|
| Test Command AT+CGEQREQ=? | Response +CGEQREQ: <PDP_type>,(list of supported <Traffic class>s),(list of supported <Maximum bitrate UL>s),(list of supported <Maximum bitrate DL>s),(list of supported <Guaranteed bitrate UL>s),(list of supported <Guaranteed bitrate DL>s),(list of supported <Delivery order>s),(list of supported <Maximum SDU size>s),(list of supported <SDU error ratio>s),(list of supported <Residual bit error Ratio>s),(list of supported <Delivery of erroneous SDUs>s),(list of Supported <Transfer delay>s),(list of supported <Traffic handling priority>s) OK or ERROR |
| Read Command AT+CGEQREQ? | Response +CGEQREQ: [<cid>,<Traffic class>,<Maximum bitrate UL>,<Maximum bitrate DL>,<Guaranteed bitrate UL>,<Guaranteed bitrate DL>,<Delivery order>,<Maximum SDU size>,<SDU error ratio>,<Residual bit error ratio>,<Delivery of erroneous SDUs>,<Transfer Delay>,<Traffic handling priority>][<CR><LF> +CGEQREQ: <cid>,<Traffic class>,<Maximum bitrate UL>,<Maximum bitrate DL>,<Guaranteed bitrate UL>,<Guaranteed bitrate DL>,<Delivery order>,<Maximum SDU size>,<SDU error ratio>,<Residual bit error ratio>,<Delivery of erroneous SDUs>,<Transfer |

| | | |
|---|------------------------|---|
| <Guaranteed UL> | bitrate | <p>This parameter indicates the guaranteed number of kbit/s delivered to UMTS(up-link traffic)at a SAP(provided that there is data to deliver).As an example a bitrate of 32kbit/s would be specified as 32(e.g.AT+CGEQREQ=...,32,...).</p> <p>The range is from 0 to 8460. The default value is 0. If the parameter is set to '0' the subscribed value will be requested.</p> |
| <Guaranteed DL> | bitrate | <p>This parameter indicates the guaranteed number of kbit/s delivered to UMTS(down-link traffic)at a SAP(provided that there is data to deliver).As an example a bitrate of 32kbit/s would be specified as 32(e.g.AT+CGEQREQ=...,32,...).</p> <p>The range is from 0 to 8460. The default value is 0. If the parameter is set to '0' the subscribed value will be requested.</p> |
| <Delivery order> | | <p>This parameter indicates whether the UMTS bearer shall provide in-sequence SDU delivery or not.</p> <p>0 – no 1 – yes 2 – subscribed value</p> |
| <Maximum SDU size> | | <p>This parameter indicates the maximum allowed SDU size in octets. The range is from 0 to 1520. The default value is 0. If the parameter is set to '0' the subscribed value will be requested.</p> |
| <SDU error ratio> | | <p>This parameter indicates the target value for the fraction of SDUs lost or detected as erroneous.SDU error ratio is defined only for conforming traffic.As an example a target SDU error ratio of $5 \cdot 10^{-3}$ would be specified as "5E3"(e.g.AT+CGEQREQ=...,"5E3",...).</p> <p>"0E0" – subscribed value</p> <p>"1E2"</p> <p>"7E3"</p> <p>"1E3"</p> <p>"1E4"</p> <p>"1E5"</p> <p>"1E6"</p> <p>"1E1"</p> |
| <Residual bit error ratio> | bit error ratio | <p>This parameter indicates the target value for the undetected bit error ratio in the delivered SDUs. If no error detection is requested,Residual bit error ratio indicates the bit error ratio in the delivered SDUs.As an example a target residual bit error ratio of $5 \cdot 10^{-3}$ would be specified as "5E3"(e.g. AT+CGEQREQ=...,"5E3",...).</p> |

| | |
|---|--|
| | <p>"0E0" – subscribed value</p> <p>"5E2"</p> <p>"1E2"</p> <p>"5E3"</p> <p>"4E3"</p> <p>"1E3"</p> <p>"1E4"</p> <p>"1E5"</p> <p>"1E6"</p> <p>"6E8"</p> |
| <Delivery of erroneous SDUs> | <p>This parameter indicates whether SDUs detected as erroneous shall be delivered or not.</p> <p>0 – no</p> <p>1 – yes</p> <p>2 – no detect</p> <p>3 – subscribed value</p> |
| <Transfer delay> | <p>This parameter indicates the targeted time between request to transfer an SDU at one SAP to its delivery at the other SAP, in milliseconds.</p> <p>The range is from 0 to 4000. The default value is 0. If the parameter is set to '0' the subscribed value will be requested.</p> |
| <Traffic handling priority> | <p>This parameter specifies the relative importance for handling of all SDUs belonging to the UMTS Bearer compared to the SDUs of the other bearers.</p> <p>The range is from 0 to 3. The default value is 0. If the parameter is set to '0' the subscribed value will be requested.</p> |
| <PDP_type> | <p>(Packet Data Protocol type) a string parameter which specifies the type of packet data protocol.</p> <p>IP Internet Protocol</p> <p>PPP Point to Point Protocol</p> <p>IPV6 Internet Protocol Version 6</p> <p>IPV4V6 Dual PDN Stack</p> |

Example

AT+CGEQREQ=?

+CGEQREQ: "IP",(0-4),(0-384),(0-7168),(0-384),(0-7168),(0-2),(0-1520),("0E0","1E

```

1","1E2","7E3","1E3","1E4","1E5","1E6"),("0E0","5E2","1E2","5E3","4E3","1E3","1E
4","1E5","1E6","6E8"),(0-3),(0-4000),(0-3) ,(0,1),(0,1)
+CGEQREQ: "PPP",(0-4),(0-384),(0-7168),(0-384),(0-7168),(0-2),(0-1520),("0E0","1
E1","1E2","7E3","1E3","1E4","1E5","1E6"),("0E0","5E2","1E2","5E3","4E3","1E3","1
E4","1E5","1E6","6E8"),(0-3),(0-4000),(0-3) ,(0,1),(0,1)
+CGEQREQ: "IPV6",(0-4),(0-384),(0-7168),(0-384),(0-7168),(0-2),(0-1520),("0E0","
1E1","1E2","7E3","1E3","1E4","1E5","1E6"),("0E0","5E2","1E2","5E3","4E3","1E3","
1E4","1E5","1E6","6E8"),(0-3),(0-4000),(0-3) ,(0,1),(0,1)
+CGEQREQ:"IPV4V6",(0-4),(0-5760),(0-14000),(0-5760),(0-14000),(0-2),(0-1520),("0E0","1E1","1E
2","7E3","1E3","1E4","1E5","1E6"),("0E0","5E2","1E2","5E3","4E3","1E3","1E4","1E5","1E6","6
E8"),(0-3),(0-4000),(0-3),(0,1),(0,1)

```

OK

AT+CGEQREQ?

+CGEQREQ:

OK

8.2.9 AT+CGQMIN Quality of service profile (minimum acceptable)

This command allows the TE to specify a minimum acceptable profile which is checked by the MT against the negotiated profile returned in the Activate PDP Context Accept message. A special form of the set command. **AT+CGQMIN=<cid>** causes the minimum acceptable profile for context number <cid> to become undefined.

AT+CGQMIN Quality of service profile (minimum acceptable)

| Test Command | Response |
|-----------------------------------|---|
| AT+CGQMIN=? | <p>+CGQMIN: <PDP_type>, (list of supported <precedence>s), (list of supported <delay>s), (list of supported <reliability>s) , (list of supported <peak>s), (list of supported <mean>s) [<CR><LF>]</p> <p>+CGQMIN: <PDP_type>, (list of supported <precedence>s), (list of supported <delay>s), (list of supported <reliability>s) , (list of supported <peak>s), (list of supported <mean>s)[...]</p> <p>OK</p> <p>or</p> <p>ERROR</p> |
| Read Command AT+CGQMIN? | <p>Response</p> <p>+CGQMIN: [<cid>,<precedence>,<delay>,<reliability>,<peak>,<mean>]<CR><LF></p> <p>+CGQMIN: <cid>,<precedence>,<delay>,<reliability>,<peak>,<mean></p> |

| | |
|---|-------------------------------|
| | [...]] |
| | OK or ERROR |
| Write Command AT+CGQMIN=<cid>[,<prece dence>[,<delay>[,<reliability >[,<peak> [,<mean>]]]]] | Response OK or ERROR |
| Execution Command AT+CGQMIN | Response OK or ERROR |

Defined Values

| | |
|----------------------------|--|
| <cid> | A numeric parameter which specifies a particular PDP context definition (see AT+CGDCONT command). The range is from 1 to 24,100 to 179. |
| <PDP_type> | (Packet Data Protocol type) a string parameter which specifies the type of packet data protocol. IP Internet Protocol PPP Point to Point Protocol IPV6 Internet Protocol Version 6 IPV4V6 Dual PDN Stack |
| <precedence> | A numeric parameter which specifies the precedence class: 0 – network subscribed value 1 – high priority 2 – normal priority 3 – low priority |
| <delay> | A numeric parameter which specifies the delay class: 0 – network subscribed value 1 – delay class 1 2 – delay class 2 3 – delay class 3 4 – delay class 4 |
| <reliability> | A numeric parameter which specifies the reliability class: 0 – network subscribed value 1 – Non real-time traffic,error-sensitive application that cannot cope with data loss 2 – Non real-time traffic,error-sensitive application that can cope with infrequent data loss 3 – Non real-time traffic,error-sensitive application that can cope with data loss, GMM/-SM,and SMS 4 – Real-time traffic,error-sensitive application that can cope with data |

| | |
|---------------------|---|
| | <p>loss</p> <p>5 – Real-time traffic error non-sensitive application that can cope with data loss</p> |
| <peak> | <p>A numeric parameter which specifies the peak throughput class:</p> <p>0 – network subscribed value</p> <p>1 – Up to 1000 (8 kbit/s)</p> <p>2 – Up to 2000 (16 kbit/s)</p> <p>3 – Up to 4000 (32 kbit/s)</p> <p>4 – Up to 8000 (64 kbit/s)</p> <p>5 – Up to 16000 (128 kbit/s)</p> <p>6 – Up to 32000 (256 kbit/s)</p> <p>7 – Up to 64000 (512 kbit/s)</p> <p>8 – Up to 128000 (1024 kbit/s)</p> <p>9 – Up to 256000 (2048 kbit/s)</p> |
| <mean> | <p>A numeric parameter which specifies the mean throughput class:</p> <p>0 – network subscribed value</p> <p>1 – 100 (~0.22 bit/s)</p> <p>2 – 200 (~0.44 bit/s)</p> <p>3 – 500 (~1.11 bit/s)</p> <p>4 – 1000 (~2.2 bit/s)</p> <p>5 – 2000 (~4.4 bit/s)</p> <p>6 – 5000 (~11.1 bit/s)</p> <p>7 – 10000 (~22 bit/s)</p> <p>8 – 20000 (~44 bit/s)</p> <p>9 – 50000 (~111 bit/s)</p> <p>10 – 100000 (~0.22 kbit/s)</p> <p>11 – 200000 (~0.44 kbit/s)</p> <p>12 – 500000 (~1.11 kbit/s)</p> <p>13 – 1000000 (~2.2 kbit/s)</p> <p>14 – 2000000 (~4.4 kbit/s)</p> <p>15 – 5000000 (~11.1 kbit/s)</p> <p>16 – 10000000 (~22 kbit/s)</p> <p>17 – 20000000 (~44 kbit/s)</p> <p>18 – 50000000 (~111 kbit/s)</p> <p>31 – optimization</p> |

Example

AT+CGQMIN=?

```
+CGQMIN: "IP",(0-3),(0-4),(0-5),(0-9),(0-18,31)
+CGQMIN: "PPP",(0-3),(0-4),(0-5),(0-9),(0-18,31)
+CGQMIN: "IPV6",(0-3),(0-4),(0-5),(0-9),(0-18,31)
+CGQMIN:
"IPV4V6",(0-3),(0-4),(0-5),(0-9),(0-18,31)
```

```
OK
AT+CGQMIN?
+CGQMIN:

OK
```

8.2.10 AT+CGEQMIN 3G quality of service profile (minimum acceptable)

The test command returns values supported as a compound value.

The read command returns the current settings for each defined context for which a QOS was explicitly specified.

AT+CGEQMIN 3G quality of service profile (minimum acceptable)

| Test Command | Response |
|------------------------------------|--|
| AT+CGEQMIN=? | <p>+CGEQMIN: <PDP_type>,(list of supported <Traffic class>s),(list of supported <Maximum bitrate UL>s),(list of supported <Maximum bitrate DL>s),(list of supported <Guaranteed bitrate UL>s),(list of supported <Guaranteed bitrate DL>s),(list of supported <Delivery order>s),(list of supported <Maximum SDU size>s),(list of supported <SDU error ratio>s),(list of supported <Residual bit error Ratio>s),(list of supported <Delivery of erroneous SDUs>s),(list of Supported <Transfer delay>s),(list of supported <Traffic handling priority>s)</p> <p>OK or ERROR</p> |
| Read Command AT+CGEQMIN? | <p>Response</p> <p>+CGEQMIN: [<cid>,<Traffic class>,<Maximum bitrate UL>,<Maximum bitrate DL>,<Guaranteed bitrate UL>,<Guaranteed bitrate DL>,<Delivery order>,<Maximum SDU size>,<SDU error ratio>,<Residual bit error ratio>,<Delivery of erroneous SDUs>,<Transfer Delay>,<Traffic handling priority>][<CR><LF></p> <p>+CGEQMIN: <cid>,<Traffic class>,<Maximum bitrate UL>,<Maximum bitrate DL>,<Guaranteed bitrate UL>,<Guaranteed bitrate DL>,<Delivery order>,<Maximum SDU size>,<SDU error ratio>,<Residual bit error ratio>,<Delivery of erroneous SDUs>,<Transfer</p> |

| | | |
|---|------------------------|--|
| <Guaranteed UL> | bitrate | <p>This parameter indicates the guaranteed number of kbit/s delivered to UMTS(up-link traffic)at a SAP(provided that there is data to deliver).As an example a bitrate of 32kbit/s would be specified as 32(e.g.AT+CGEQMIN=...,32,...).</p> <p>The range is from 0 to 8460. The default value is 0. If the parameter is set to '0' the subscribed value will be requested.</p> |
| <Guaranteed DL> | bitrate | <p>This parameter indicates the guaranteed number of kbit/s delivered to UMTS(down-link traffic)at a SAP(provided that there is data to deliver).As an example a bitrate of 32kbit/s would be specified as 32(e.g.AT+CGEQMIN=...,32,...).</p> <p>The range is from 0 to 8460. The default value is 0. If the parameter is set to '0' the subscribed value will be requested.</p> |
| <Delivery order> | | <p>This parameter indicates whether the UMTS bearer shall provide in-sequence SDU delivery or not.</p> <p>0 – no 1 – yes 2 – subscribed value</p> |
| <Maximum SDU size> | | <p>This parameter indicates the maximum allowed SDU size in octets. The range is from 0 to 1520. The default value is 0. If the parameter is set to '0' the subscribed value will be requested.</p> |
| <SDU error ratio> | | <p>This parameter indicates the target value for the fraction of SDUs lost or detected as erroneous.SDU error ratio is defined only for conforming traffic.As an example a target SDU error ratio of $5 \cdot 10^{-3}$ would be specified as "5E3"(e.g.AT+CGEQMIN=..., "5E3",...).</p> <p>"0E0" – subscribed value</p> <p>"1E2"</p> <p>"7E3"</p> <p>"1E3"</p> <p>"1E4"</p> <p>"1E5"</p> <p>"1E6"</p> <p>"1E1"</p> |
| <Residual bit error ratio> | bit error ratio | <p>This parameter indicates the target value for the undetected bit error ratio in the delivered SDUs. If no error detection is requested,Residual bit error ratio indicates the bit error ratio in the delivered SDUs.As an example a target residual bit error ratio of $5 \cdot 10^{-3}$ would be specified as "5E3"(e.g. AT+CGEQMIN=..., "5E3",..).</p> |

| | |
|--|--|
| | <p>"0E0" – subscribed value</p> <p>"5E2"</p> <p>"1E2"</p> <p>"5E3"</p> <p>"4E3"</p> <p>"1E3"</p> <p>"1E4"</p> <p>"1E5"</p> <p>"1E6"</p> <p>"6E8"</p> |
| <Delivery erroneous SDUs> | <p>of This parameter indicates whether SDUs detected as erroneous shall be delivered or not.</p> <p>0 – no</p> <p>1 – yes</p> <p>2 – no detect</p> <p>3 – subscribed value</p> |
| <Transfer delay> | <p>This parameter indicates the targeted time between request to transfer an SDU at one SAP to its delivery at the other SAP, in milliseconds.</p> <p>The range is from 0 to 4000. The default value is 0. If the parameter is set to '0' the subscribed value will be requested.</p> |
| <Traffic handling priority> | <p>handling This parameter specifies the relative importance for handling of all SDUs belonging to the UMTS Bearer compared to the SDUs of the other bearers.</p> <p>The range is from 0 to 3. The default value is 0. If the parameter is set to '0' the subscribed value will be requested.</p> |
| <PDP_type> | <p>(Packet Data Protocol type) a string parameter which specifies the type of packet data protocol.</p> <p>IP Internet Protocol</p> <p>PPP Point to Point Protocol</p> <p>IPV6 Internet Protocol Version 6</p> <p>IPV4V6 Dual PDN Stack</p> |

Example

AT+CGEQMIN=?

+CGEQMIN:

"IP",(0-4),(0-11520),(0-42200),(0-11520),(0-42200),(0-2),(0-1520),("0E0","1E1","1E2","7E3","1E3","


```

1E4","1E5","1E6"),("0E0","5E2","1E2","5E3","4E3","1E3","1E4","1E5","1E6","6E8"),(0-3),(0,100-
4000),(0-3),(0-1),(0-1)
+CGEQMIN:
"PPP",(0-4),(0-11520),(0-42200),(0-11520),(0-42200),(0-2),(0-1520),("0E0","1E1","1E2","7E3","1E3
","1E4","1E5","1E6"),("0E0","5E2","1E2","5E3","4E3","1E3","1E4","1E5","1E6","6E8"),(0-3),(0,1
00-4000),(0-3),(0-1),(0-1)
+CGEQMIN:
"IPV6",(0-4),(0-11520),(0-42200),(0-11520),(0-42200),(0-2),(0-1520),("0E0","1E1","1E2","7E3","1E3
","1E4","1E5","1E6"),("0E0","5E2","1E2","5E3","4E3","1E3","1E4","1E5","1E6","6E8"),(0-3),(0,1
00-4000),(0-3),(0-1),(0-1)
+CGEQMIN:
"IPV4V6",(0-4),(0-11520),(0-42200),(0-11520),(0-42200),(0-2),(0-1520),("0E0","1E1","1E2","7E3","1
E3","1E4","1E5","1E6"),("0E0","5E2","1E2","5E3","4E3","1E3","1E4","1E5","1E6","6E8"),(0-3),(0
,100-4000),(0-3),(0-1),(0-1)

OK
AT+CGEQMIN?
+CGEQMIN:

OK

```

8.2.11 AT+CGDATA Enter data state

The command causes the MT to perform whatever actions are necessary to establish communication between the TE and the network using one or more Packet Domain PDP types. This may include performing a PS attach and one or more PDP context activations.

| AT+CGDATA Enter data state | |
|--|--|
| Test Command AT+CGDATA=? | Response +CGDATA: (list of supported <L2P>s) OK or ERROR |
| Write Command AT+CGDATA=[<L2P>,<cid>]] | Response NO CARRIER or OK or ERROR or +CME ERROR: <err> |

Defined Values

| | |
|---------------------|--|
| <L2P> | A string parameter that indicates the layer 2 protocol to be used between the TE and MT. PPP Point-to-point protocol for a PDP such as IP |
| <text> | CONNECT result code string; the string formats please refer ATX/ATV/AT&E command. |
| <cid> | A numeric parameter which specifies a particular PDP context definition (see AT+CGDCONT command). 1...16 |

Example

```

AT+CGDATA=?
+CGDATA: ("PPP")

OK
AT+CGDATA="PPP",1
CONNECT 115200

```

8.2.12 AT+CGPADDR Show PDP address

The write command returns a list of PDP addresses for the specified context identifiers.

AT+CGPADDR Show PDP address

| | |
|---|---|
| <p>Test Command</p> <p>AT+CGPADDR=?</p> | <p>Response</p> <p>[+CGPADDR: (list of defined <cid>s)]</p> <p>OK</p> <p>or</p> <p>ERROR</p> |
| <p>Write Command</p> <p>AT+CGPADDR=<cid>[,<cid> [...]]</p> | <p>Response</p> <p>OK</p> <p>or</p> <p>ERROR</p> <p>or</p> <p>+CME ERROR: <err></p> |
| <p>Execution Command</p> <p>AT+CGPADDR</p> | <p>Response</p> <p>[+CGPADDR: <cid>,<PDP_addr>]</p> |

+CGPADDR: <cid>,<PDP_addr>[...]]

OK

or

ERROR

or

+CME ERROR: <err>

Defined Values

| | |
|-------------------------|--|
| <cid> | A numeric parameter which specifies a particular PDP context definition (see AT+CGDCONT command). If no <cid> is specified, the addresses for all defined contexts are returned. 1...24,100...179 |
| <PDP_addr> | A string that identifies the MT in the address space applicable to the PDP. The address may be static or dynamic. For a static address, it will be the one set by the AT+CGDCONT command when the context was defined. For a dynamic address it will be the one assigned during the last PDP context activation that used the context definition referred to by <cid>. <PDP_addr> is omitted if none is available. |

Example

AT+CGPADDR=?

+CGPADDR: (1)

OK

AT+CGPADDR=1

+CGPADDR: 1,"0.0.0.0"

OK

8.2.13 AT+CGCLASS GPRS network registration status

This command is used to set the MT to operate according to the specified GPRS mobile class.

AT+CGCLASS GPRS network registration status

Test Command

AT+CGCLASS=?

Response

+CGCLASS:(list of supported <class>s)

OK

| | |
|--|---|
| | or ERROR |
| Read Command AT+CGCLASS? | Response +CGCLASS: <class> |
| | OK or ERROR |
| Write Command AT+CGCLASS=<class> | Response OK or ERROR or +CME ERROR: <err> |
| Execution Command Set default value: AT+CGCLASS | Response OK or ERROR |

Defined Values

| | |
|----------------------|--|
| <class> | A string parameter which indicates the GPRS mobile class (in descending order of functionality) A – class A (highest) |
|----------------------|--|

Example

```

AT+CGCLASS=?
+CGCLASS: ("A")

OK
AT+CGCLASS?
+CGCLASS: "A"

OK

```

8.2.14 AT+CGEREP GPRS event reporting

The write command enables or disables sending of unsolicited result codes, "+CGEV" from MT to TE in the case of certain events occurring in the Packet Domain MT or the network. <mode> controls the processing of unsolicited result codes specified within this command. <bfr> controls the effect on buffered codes when <mode> 1 or 2 is entered. If a setting is not supported by the MT, ERROR or +CME ERROR: is returned.

Read command returns the current <mode> and buffer settings.

Test command returns the modes and buffer settings supported by the MT as compound values.

| AT+CGEREP GPRS event reporting | |
|--|--|
| Test Command AT+CGEREP=? | Response +CGEREP: (list of supported <mode>s), (list of supported <bfr>s) OK or ERROR |
| Read Command AT+CGEREP? | Response +CGEREP: <mode>,<bfr> OK or ERROR |
| Write Command AT+CGEREP=<mode>[,<bfr>] | Response OK or ERROR or +CME ERROR: <err> |
| Execution Command AT+CGEREP | Response OK or ERROR |

Defined Values

| | |
|---------------------|---|
| <n> | 0 – disable network registration unsolicited result code 1 – enable network registration unsolicited result code +CGREG: <stat> 2 – there is a change in the ME network registration status or a change of the network cell: +CGREG: <stat>[,<lac>,<ci>] |
| <stat> | 0 – not registered, ME is not currently searching an operator to register to 1 – registered, home network 2 – not registered, but ME is currently trying to attach or searching an operator to register to 3 – registration denied 4 – unknown 5 – registered, roaming |
| <lac> | Two bytes location area code in hexadecimal format (e.g."00C3" equals 193 in decimal). |

| | |
|------|--|
| <ci> | Cell ID in hexadecimal format. GSM : Maximum is two byte WCDMA : Maximum is four byte TDS-CDMA : Maximum is four byte |
|------|--|

NOTE

The <lac> not supported in CDMA/HDR mode
 The <ci> not supported in CDMA/HDR mode

Example

```
AT+CGREG=?
+CGREG: (0-2)
```

OK

```
AT+CGREG?
+CGREG: 0,1
```

OK

8.2.15 AT+CGAUTH Set type of authentication for PDP-IP connections of GPRS

This command is used to set type of authentication for PDP-IP connections of GPRS.

AT+CGAUTH Set type of authentication for PDP-IP connections of GPRS

| | |
|------------------------------------|---|
| Test Command AT+CGAUTH=? | Response +CGAUTH: ,,127,127(for CDMA1x-EvDo only) +CGAUTH: (range of supported<cid>s),(list of supported <auth_type>s),, OK or ERROR or +CME ERROR: <err> |
| Read Command AT+CGAUTH? | Response +CGAUTH: <cid>,<auth_type>[,<user>]<CR><LF> +CGAUTH: <cid>,<auth_type>[,<user>]<CR><LF> |

| | |
|---|--|
| | <p>...</p> <p>OK</p> <p>OK</p> <p>or</p> <p>ERROR</p> <p>or</p> <p>+CME ERROR: <err></p> |
| Write Command AT+CGAUTH=<cid>[,<auth_type>[,<passwd>[,<user>]]] | <p>Response</p> <p>OK</p> <p>or</p> <p>ERROR</p> <p>or</p> <p>+CME ERROR: <err></p> |
| Execution Command AT+CGAUTH | <p>Response</p> <p>OK</p> <p>or</p> <p>ERROR</p> <p>or</p> <p>+CME ERROR: <err></p> |

Defined Values

| | |
|--------------------------|--|
| <cid> | <p>Parameter specifies a particular PDP context definition. This is also used in other PDP context-related commands.</p> <p>1...42,100...179</p> |
| <auth_type> | <p>Indicate the type of authentication to be used for the specified context. If CHAP is selected another parameter <passwd> needs to be specified. If PAP is selected two additional parameters <passwd> and <user> need to be specified.</p> <p>0 – none 1 – PAP 2 – CHAP 3 – PAP or CHAP</p> |
| <passwd> | <p>Parameter specifies the password used for authentication.</p> |
| <user> | <p>Parameter specifies the user name used for authentication.</p> |

Example

```

AT+CGAUTH=?
+CGAUTH: ,,127,127(for CDMA1x-EvDo only)
+CGAUTH: (1-24,100-179),(0-3),127,127

OK

```

```
AT+CGAUTH=1,1,"123","SIMCOM"
```

```
OK
```

SIMCom
Confidential

9. AT Commands for SMS

9.1 Overview of AT Commands for SMS Control

| Command | Description |
|-----------|--|
| AT+CSMS | Select message service |
| AT+CPMS | Preferred message storage |
| AT+CMGF | Select bearer service type |
| AT+CSCA | SMS service centre address |
| AT+CSCB | Select cell broadcast message indication |
| AT+CSMP | Set text mode parameters |
| AT+CSDH | Show text mode parameters |
| AT+CNMA | New message acknowledgement to ME/TA |
| AT+CNMI | New message indications to TE |
| AT+CGSMS | Select service for MO SMS messages |
| AT+CMGL | List SMS messages from preferred store |
| AT+CMGR | Read message |
| AT+CMGS | Send message |
| AT+CMSS | Send message from storage |
| AT+CMGW | Write message to memory |
| AT+CMGD | Delete message |
| AT+CMGMT | Change message status |
| AT+CMVP | Set message valid period |
| AT+CMGRD | Read and delete message |
| AT+CMGSEX | Send message |
| AT+CMSSEX | Send multi messages from storage |
| AT+CMGP | Set cdma/evdo text mode parameters |

9.2 Detailed Description of AT Commands for SMS Control

9.2.1 AT+CSMS Select message service

This command is used to select messaging service <service>.

Note: This command not support in CDMA/EVDO mode

| AT+CSMS Select message service | |
|---|--|
| Test Command AT+CSMS=? | Response a)If start HTTP service successfully: +CSMS: (list of supported <service>s) OK b)If failed: ERROR |
| Read Command AT+CSMS? | Response +CSMS: <service>,<mt>,<mo>,<bm> OK |
| Write Command AT+CSMS=<service> | Response a) +CSMS: <mt>,<mo>,<bm> OK b)If failed: +CMS ERROR: <err> |

Defined Values

| | |
|-----------|---|
| <service> | 0 – SMS at command is compatible with GSM phase 2. 1 – SMS at command is compatible with GSM phase 2+. |
| <mt> | Mobile terminated messages: 0 – type not supported. 1 – type supported. |
| <mo> | Mobile originated messages: 0 – type not supported. 1 – type supported 1 – SMS at command is compatible with GSM phase 2+. |
| <bm> | Broadcast type messages: 0 – type not supported. 1 – type supported. |

Example

```
AT+CSMS=0
+CSMS:1,1,1
OK
```

9.2.2 AT+CPMS Preferred message storage

This command is used to select memory storages <mem1>, <mem2> and <mem3> to be used for reading, writing, etc.

| AT+CPMS Preferred message storage | |
|--|---|
| Test Command AT+CPMS=? | Response a)If start HTTP service successfully: +CPMS: (list of supported <mem1>s), (list of supported <mem2>s), (list of supported <mem3>s) OK b)If failed: ERROR |
| Read Command AT+CPMS? | Response +CPMS:<mem1>,<used1>,<total1>,<mem2>,<used2>,<total2>,<mem3>,<used3>,<total3> OK |
| Write Command AT+CPMS=<mem1>[,<mem2>[,<mem3>]] | Response a) +CPMS: <used1>,<total1>,<used2>,<total2>,<used3>,<total3> OK b)If failed: +CMS ERROR: <err> |

Defined Values

| | |
|--------|---|
| <mem1> | String type, memory from which messages are read and deleted (commands List Messages AT+CMGL, Read Message AT+CMGR and Delete Message AT+CMGD). "ME" and "MT" FLASH message storage "SM" SIM message storage "SR" Status report storage (not used in CDMA/EVDO mode) |
|--------|---|

| | |
|----------|--|
| <mem2> | <p>String type, memory to which writing and sending operations are made (commands Send Message from Storage AT+CMSS and Write Message to Memory AT+CMGW).</p> <p>"ME" and "MT" FLASH message storage</p> <p>"SM" SIM message storage</p> |
| <mem3> | <p>String type, memory to which received SMS is preferred to be stored (unless forwarded directly to TE; refer command New Message Indications AT+CNMI).</p> <p>"ME" FLASH message storage</p> <p>"SM" SIM message storage GSM phase 2+.</p> |
| <usedX> | Integer type, number of messages currently in <memX>. |
| <totalX> | Integer type, total number of message locations in <memX>. |

Example

```
AT+CSMS=0
+CSMS:1,1,1
OK
```

9.2.3 AT+CMGF Select SMS message format

This command is used to specify the input and output format of the short messages.

| AT+CMGF Select SMS message format | |
|--|---|
| Test Command AT+CMGF=? | Response a)If start HTTP service successfully: +CMGF: (list of supported <mode>s) OK b)If failed: ERROR |
| Read Command AT+CMGF? | Response +CMGF: <mode> OK |
| Write Command AT+CMGF=<mode> | Response a) OK b)If failed: ERROR |
| Execution Command | Response |

AT+CMGF

- a)
OK
- b)If failed:
ERROR

Defined Values

| | |
|---------------------|---------------|
| <mode> | 0 – PDU mode |
| | 1 – Text mode |

Example

AT+CMGF=1
OK

9.2.4 AT+CSCA SMS service centre address

This command is used to update the SMSC address, through which mobile originated SMS are transmitted.
Note: This command not support in CDMA/EVDO mode

AT+CSCA SMS service centre address

| | |
|---|---|
| Test Command AT+CSCA=? | Response a)If start HTTP service successfully: +CMGF: (list of supported <mode>s) OK b)If failed: ERROR |
| Read Command AT+CSCA? | Response +CMGF: <mode> OK |
| Write Command AT+CSCA=<sca>[,<tosca>] | Response a) OK b)If failed: ERROR |

Defined Values

| | |
|---------------------|--------------|
| <mode> | 0 – PDU mode |
|---------------------|--------------|

1 - Text mode

Example

```
AT+CMGF=1
OK
```

9.2.5 AT+CSCB Select cell broadcast message indication

The test command returns the supported <mode>s as a compound value.

The read command displays the accepted message types.

Depending on the <mode> parameter, the write command adds or deletes the message types accepted.

Note: This command not support in CDMA/EVDO mode

| AT+CSCB Select cell broadcast message indication | |
|--|---|
| Test Command AT+CSCB=? | Response a)If start HTTP service successfully: +CSCB: (list of supported <mode>s) OK b)If failed: ERROR |
| Read Command AT+CSCB? | Response +CSCB: <mode>,<mids>,<dcss> OK b)If failed: ERROR |
| Write Command AT+CSCB=<mode>[,<mids>[,<dcss>]] | Response a) OK b)If failed: ERROR c)If failed: +CMS ERROR: <err> |

Defined Values

| | |
|--------|--|
| <mode> | 0 - message types specified in <mids> and <dcss> are accepted. 1 - message types specified in <mids> and <dcss> are not |
|--------|--|

| | |
|--------|--|
| | accepted. |
| <mids> | String type; all different possible combinations of CBM message identifiers. |
| <dcss> | String type; all different possible combinations of CBM data coding schemes(default is empty string) |

Example

AT+CSCB=?

+CSCB: (0-1)

OK

9.2.6 AT+CSMP Set text mode parameters

This command is used to select values for additional parameters needed when SM is sent to the network or placed in storage when text format message mode is selected.

Note: This command not support in CDMA/EVDO mode

AT+CSMP Set text mode parameters

| | |
|--|---|
| Test Command AT+CSMP=? | Response OK |
| Read Command AT+CSMP? | Response +CSMP: <fo>,<vp>,<pid>,<dc> OK |
| Write Command AT+CSMP=[<fo>[,<vp>[,<pid>[,<dc>]]]] | Response a) OK b)If failed: ERROR |

Defined Values

| | |
|------|---|
| <fo> | Depending on the Command or result code: first octet of GSM 03.40 SMS-DELIVER, SMS-SUBMIT (default 17), SMS-STATUS-REPORT, or SMS-COMMAND (default 2) in integer format. SMS status report is supported under text mode if <fo> is set to 49. |
| <vp> | Depending on SMS-SUBMIT <fo> setting: GSM 03.40,TP-Validity-Period either in integer format (default 167), in time-string format, or if is supported, in enhanced format (hexadecimal coded string with quotes), (<vp> is in range 0... 255). |

| | |
|--------------------|---|
| <pid> | GSM 03.40 TP-Protocol-Identifier in integer format (default 0). |
| <dc> | GSM 03.38 SMS Data Coding Scheme (default 0), or Cell Broadcast Data Coding Scheme in integer format depending on the command or result code. |

Example

```
AT+CSMP=17,23,64,244
OK
```

9.2.7 AT+CSDH Show text mode parameters

This command is used to select values for additional parameters needed when SM is sent to the network or placed in storage when text format message mode is selected.

Note: This command not support in CDMA/EVDO mode

| AT+CSDH Show text mode parameters | |
|--|--|
| Test Command AT+CSDH=? | Response a) +CSDH: (list of supported <show>s) OK b)If failed: ERROR |
| Read Command AT+CSDH? | Response +CSDH: <show> OK |
| Write Command AT+CSDH=<show> | Response a) OK b)If failed: ERROR |
| Execution Command AT+CSDH | Response a) Set default value (<show>=0): OK b)If failed: ERROR |

Defined Values

| | |
|-------------------|---|
| <fo> | Depending on the Command or result code: first octet of GSM 03.40 SMS-DELIVER, SMS-SUBMIT (default 17), |
|-------------------|---|

| | |
|-------|--|
| | SMS-STATUS-REPORT, or SMS-COMMAND (default 2) in integer format. SMS status report is supported under text mode if <fo> is set to 49. |
| <vp> | Depending on SMS-SUBMIT <fo> setting: GSM 03.40,TP-Validity-Period either in integer format (default 167), in time-string format, or if is supported, in enhanced format (hexadecimal coded string with quotes), (<vp> is in range 0...255). |
| <pid> | GSM 03.40 TP-Protocol-Identifier in integer format (default 0). |
| <dcs> | GSM 03.38 SMS Data Coding Scheme (default 0), or Cell Broadcast Data Coding Scheme in integer format depending on the command or result code. |

Example

```
AT+CSDH=1
OK
```

9.2.8 AT+CNMA New message acknowledgement to ME/TA

This command is used to confirm successful receipt of a new message (SMS-DELIVER or SMS-STATUSREPORT) routed directly to the TE. If ME does not receive acknowledgement within required time (network timeout), it will send RP-ERROR to the network.

AT+CNMA New message acknowledgement to ME/TA

| | |
|---|--|
| Test Command AT+CNMA=? | Response if text mode(AT+CMGF=1): OK if PDU mode (AT+CMGF=0): +CNMA: (list of supported <n>s) OK |
| Write Command AT+CNMA=<n> | Response a) OK b)If failed: ERROR c)If failed: +CMS ERROR: <err> |
| Write Command AT+CNMA | Response a) OK b)If failed: |

ERROR

c)If failed:

+CMS ERROR: <err>

Defined Values

<n>

Parameter required only for PDU mode.

0 – Command operates similarly as execution command in text mode.

1 – Send positive (RP-ACK) acknowledgement to the network. Accepted only in PDU mode.

2 – Send negative (RP-ERROR) acknowledgement to the network. Accepted only in PDU mode.

Example

AT+CNMI=1,2,0,0,0

OK

+CMT:" 1380022xxxx" ,"", " 02/04/03,11 :06 :38+32" <CR><LF>

Testing

(receive new short message)

AT+CNMA(send ACK to the network)

OK

AT+CNMA

+CMS ERROR : 340

(the second time return error, it needs ACK only once)

NOTE

- NOTE: The execute / write command shall only be used when AT+CSMS parameter <service> equals 1 (= phase 2+) and appropriate URC has been issued by the module, i.e.:
- <+CMT> for <mt>=2 incoming message classes 0, 1, 3 and none;
- <+CMT> for <mt>=3 incoming message classes 0 and 3;
- <+CDS> for <ds>=1.
- This command not support in CDMA/EVDO mode

9.2.9 AT+CNMI New message indications to TE

This command is used to select the procedure how receiving of new messages from the network is indicated to the TE when TE is active, e.g. DTR signal is ON. If TE is inactive (e.g. DTR signal is OFF). If set `<mt> = 3` or `<ds> = 1`, make sure `<mode> = 1`, If set `<mt>=2`, make sure `<mode>=1` or `2`, otherwise it will return error.

| AT+CNMI New message indications to TE | |
|--|---|
| Test Command AT+CNMI=? | Response +CNMI: (list of supported <mode>s),(list of supported <mt>s),(list of supported <bm>s),(list of supported <ds>s),(list of supported <bfr>s) OK |
| Read Command AT+CNMI? | Response +CNMI: <mode>,<mt>,<bm>,<ds>,<bfr> OK |
| Write Command AT+CNMI=<mode>[,<mt>[,<bm>[,<ds> [,<bfr>]]]] | Response a) OK b)If failed: ERROR c)If failed: +CMS ERROR: <err> |
| Execution Command AT+CNMI | Set default value:b) OK |

Defined Values

| | |
|---------------------|---|
| <mode> | <p>0 – Buffer unsolicited result codes in the TA. If TA result code buffer is full, indications can be buffered in some other place or the oldest indications may be discarded and replaced with the new received indications.</p> <p>1 – Discard indication and reject new received message unsolicited result codes when TA-TE link is reserved (e.g. in on-line data mode). Otherwise forward them directly to the TE.</p> <p>2 – Buffer unsolicited result codes in the TA when TA-TE link is reserved (e.g. in on-line data mode) and flush them to the TE after reservation. Otherwise forward them directly to the TE.</p> |
| <mt> | The rules for storing received SMS depend on its data coding scheme, preferred memory storage (AT+CPMS) setting and this |

| | |
|-------------------|---|
| | <p>value:</p> <p>0 – No SMS-DELIVER indications are routed to the TE.</p> <p>1 – If SMS-DELIVER is stored into ME/TA, indication of the memory location is routed to the TE using unsolicited result code: +CMTI: <mem3>,<index>.</p> <p>2 – SMS-DELIVERs (except class 2 messages and messages in the message waiting indication group (store message)) are routed directly to the TE using unsolicited result code: +CMT:[<alpha>],<length><CR><LF><pdu> (PDU mode enabled); or +CMT:<oa>,<alpha>,<scts>[,<toa>,<fo>,<pid>,<dc>,<sca>,<tosca>,<length>] <CR> <LF><data> (text mode enabled, about parameters in italics, refer command Show Text Mode Parameters AT+CSDH).</p> <p>3 – Class 3 SMS-DELIVERs are routed directly to TE using unsolicited result codes defined in <mt>=2. Messages of other data coding schemes result in indication as defined in <mt>=1.</p> |
| <p><bm></p> | <p>(not used in CDMA/EVDO mode)</p> <p>The rules for storing received CBMs depend on its data coding scheme, the setting of Select CBM Types (AT+CSCB) and this value:</p> <p>0 – No CBM indications are routed to the TE.</p> <p>2 – New CBMs are routed directly to the TE using unsolicited result code: +CBM: <length><CR><LF><pdu> (PDU mode enabled); or +CBM: <sn>,<mid>,<dc>,<page>,<pages><CR><LF><data> (text mode enabled)</p> |
| <p><ds></p> | <p>(not used in CDMA/EVDO mode)</p> <p>0 – No SMS-STATUS-REPORTs are routed to the TE.</p> <p>1 – SMS-STATUS-REPORTs are routed to the TE using unsolicited result code: +CDS: <length><CR><LF><pdu> (PDU mode enabled); or +CDS: <fo>,<mr>,<ra>,<tora>,<scts>,<dt>,<st> (text mode</p> |

| | |
|-------|---|
| | enabled) |
| | 2 – If SMS-STATUS-REPORT is stored into ME/TA, indication of the memory location is routed to the TE using unsolicited result code: +CDSI: <mem3>,<index>. |
| <bfr> | 0 – TA buffer of unsolicited result codes defined within this command is flushed to the TE when <mode> 1 to 2 is entered (OK response shall be given before flushing the codes). 1 – TA buffer of unsolicited result codes defined within this command is cleared when <mode> 1 to 2 is entered. |

Example

AT+CNMI=2,1 (unsolicited result codes after received messages.)

OK

9.2.10 AT+CGSMS Select service for MO SMS messages

The write command is used to specify the service or service preference that the MT will use to send MO SMS messages.

The test command is used for requesting information on which services and service preferences can be set by using the AT+CGSMS write command

The read command returns the currently selected service or service preference.

Note: This command not support in CDMA/EVDO mode

AT+CGSMS Select service for MO SMS messages

| | |
|--|---|
| Test Command AT+CGSMS=? | Response +CGSMS: (list of supported <service>s) OK |
| Read Command AT+CGSMS? | Response +CGSMS: <service> OK |
| Write Command AT+CGSMS=<service> | Response a) OK b)If failed: ERROR c)If failed: +CMS ERROR: <err> |

Defined Values

| | |
|------------------------|---|
| <service> | <p>A numeric parameter which indicates the service or service preference to be used</p> <p>0 – GPRS(value is not really supported and is internally mapped to 2)</p> <p>1 – circuit switched(value is not really supported and is internally mapped to 3)</p> <p>2 – GPRS preferred (use circuit switched if GPRS not available)</p> <p>3 – circuit switched preferred (use GPRS if circuit switched not available)</p> |
|------------------------|---|

Example

```
AT+CGSMS?
+CGSMS: 3
OK
```

9.2.11 AT+CMGL List SMS messages from preferred store

This command is used to return messages with status value <stat> from message storage <mem1> to the TE.

If the status of the message is 'received unread', the status in the storage changes to 'received read'.

AT+CMGL List SMS messages from preferred store

| | |
|---|--|
| <p>Test Command</p> <p>AT+CMGL=?</p> | <p>Response</p> <p>+CMGL: (list of supported <stat>s)</p> <p>OK</p> |
| <p>Write Command</p> <p>AT+CMGL=<stat></p> | <p>Response</p> <p>a)If text mode (AT+CMGF=1), command successful and SMS-SUBMITs and/or SMS-DELIVERs:</p> <p>+CMGL:<index>,<stat>,<oa>/<da>,[<alpha>],[<scts>],[<toa>/<toda>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><data>[<CR><LF>+CMGL:<index>,<stat>,<oa>/<da>,[<alpha>],[<scts>],[<toa>/<toda>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><data>[...]]</p> |

OK

b)If text mode (AT+CMGF=1), command successful and SMS-STATUS-REPORTS:

+CMGL:<index>,<stat>,<fo>,<mr>,<ra>,<tora>,<scts>,<dt>,<st>[<CR><LF>

+CMGL:<index>,<stat>,<fo>,<mr>,<ra>,<tora>,<scts>,<dt>,<st>[...]]

OK

c)If text mode (AT+CMGF=1), command successful and SMS-COMMANDS:

+CMGL: <index>,<stat>,<fo>,<ct>[<CR><LF>

+CMGL: <index>,<stat>,<fo>,<ct>[...]]

OK

d)If text mode (AT+CMGF=1), command successful and CBM storage:

+CMGL:<index>,<stat>,<sn>,<mid>,<page>,<pages>

<CR><LF><data>[<CR><LF>

+CMGL:<index>,<stat>,<sn>,<mid>,<page>,<pages>

<CR><LF><data>[...]]

OK

e)If PDU mode (AT+CMGF=0) and Command successful:

+CMGL:<index>,<stat>,<alpha>,<length><CR><LF><pdu>[<CR><LF>

+CMGL:<index>,<stat>,<alpha>,<length><CR><LF><pdu>

[...]]

OK

f)If failed:

+CMS ERROR: <err>

Defined Values

<stat>

1. Text Mode:

"REC UNREAD" received unread message (i.e. new message)

"REC READ" received read message

"STO UNSENT" stored unsent message

"STO SENT" stored sent message

"ALL" all messages

2. PDU Mode:

0 – received unread message (i.e. new message)

1 – received read message

2 – stored unsent message

| | |
|-----------------------|--|
| | <p>3 – stored sent message</p> <p>4 – all messages</p> |
| <index> | Integer type; value in the range of location numbers supported by the associated memory and start with zero. |
| <oa> | Originating-Address, Address-Value field in string format; BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set, type of address given by <tooa>. |
| <da> | Destination-Address, Address-Value field in string format; BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set, type of address given by <toda>. |
| <alpha> | String type alphanumeric representation of <da> or <oa> corresponding to the entry found in MT phonebook; implementation of this feature is manufacturer specific; used character set should be the one selected with command Select TE Character Set AT+CSCS. |
| <scts> | TP-Service-Centre-Time-Stamp in time-string format (refer <dt>). |
| <da> | Destination-Address, Address-Value field in string format; BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set, type of address given by <toda>. |
| <tooa> | TP-Originating-Address, Type-of-Address octet in integer format. (default refer <toda>). |
| <toda> | TP-Destination-Address, Type-of-Address octet in integer format. (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129). The range of value is from 128 to 255. |
| <length> | Integer type value indicating in the text mode (AT+CMGF=1) the length of the message body <data> in characters; or in PDU mode (AT+CMGF=0), the length of the actual TP data unit in octets. (i.e. the RP layer SMSC address octets are not counted in the length) |
| <data> | <p>In the case of SMS: TP-User-Data in text mode responses; format:</p> <ol style="list-style-type: none"> If <dcs> indicates that GSM 7 bit default alphabet is used and <fo> indicates that TP-User-Data-Header-Indication is not set: <ol style="list-style-type: none"> If TE character set other than "HEX": ME/TA converts GSM alphabet into current TE character set. If TE character set is "HEX": ME/TA converts each 7-bit character of GSM 7 bit default alphabet into two IRA character long hexadecimal numbers. (e.g. character (GSM 7 bit default alphabet 23) is presented as 17 (IRA 49 and 55)) If <dcs> indicates that 8-bit or UCS2 data coding scheme is used, or <fo> indicates that TP-User-Data-Header-Indication is set: ME/TA converts each 8-bit octet into two IRA character long |

| | |
|--------|---|
| | <p>hexadecimal numbers. (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65))</p> <p>3. If <dc> indicates that GSM 7 bit default alphabet is used:</p> <p>a. If TE character set other than "HEX": ME/TA converts GSM alphabet into current TE character set.</p> <p>b. If TE character set is "HEX": ME/TA converts each 7-bit character of the GSM 7 bit default alphabet into two IRA character long hexadecimal numbers.</p> <p>4. If <dc> indicates that 8-bit or UCS2 data coding scheme is used: ME/TA converts each 8-bit octet into two IRA character long hexadecimal numbers.</p> |
| <fo> | <p>Depending on the command or result code: first octet of GSM 03.40 SMS-DELIVER, SMS-SUBMIT (default 17), SMS-STATUS-REPORT, or SMS-COMMAND (default 2) in integer format. SMS status report is supported under text mode if <fo> is set to 49.</p> |
| <mr> | <p>Message Reference GSM 03.40 TP-Message-Reference in integer format.</p> |
| <ra> | <p>Recipient Address GSM 03.40 TP-Recipient-Address Address-Value field in string format;BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set(refer to command AT+CSCS);type of address given by <tora></p> |
| <tora> | <p>Type of Recipient Address GSM 04.11 TP-Recipient-Address Type-of-Address octet in integer format (default refer <toda>)</p> |
| <dt> | <p>Discharge Time GSM 03.40 TP-Discharge-Time in time-string format: "yy/MM/dd,hh:mm:ss+zz", where characters indicate year (two last digits),month,day,hour,minutes,seconds and time zone.</p> |
| <st> | <p>Status GSM 03.40 TP-Status in integer format 0...255</p> |
| <ct> | <p>Command Type GSM 03.40 TP-Command-Type in integer format 0...255</p> |
| <sn> | <p>Serial Number GSM 03.41 CBM Serial Number in integer format</p> |
| <mid> | <p>Message Identifier GSM 03.41 CBM Message Identifier in integer format</p> |
| <page> | <p>Page Parameter</p> |

| | |
|---------|---|
| | GSM 03.41 CBM Page Parameter bits 4-7 in integer format |
| <pages> | Page Parameter GSM 03.41 CBM Page Parameter bits 0-3 in integer format |
| <pdu> | In the case of SMS: SC address followed by TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal numbers. (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)). |

Example

```
AT+CMGL="ALL"
+CMGL: 1,"STO UNSENT","+10011",,,145,4
Hello World
OK
```

9.2.12 AT+CMGR Read message

This command is used to return message with location value <index> from message storage <mem1> to the TE.

| AT+CMGR Read message | |
|---|--|
| Test Command AT+CMGR=? | Response OK |
| Write Command AT+CMGR=<index> | a)If text mode (AT+CMGF=1), command successful and SMS-DELIVER: +CMGR: <stat>,<oa>,[<alpha>],<scts>[,<toa>,<fo>,<pid>,<dc>],<sca>,<tosca>,<length>]<CR><LF><data> OK |
| | b)If text mode (AT+CMGF=1), command successful and SMS-SUBMIT: +CMGR:<stat>,<da>,[<alpha>][,<toda>,<fo>,<pid>,<dc>],[<vp>],<sca>,<tosca>,<length>]<CR><LF><data> OK |
| | c)If text mode (AT+CMGF=1), command successful and SMS-STATUS-REPORT: +CMGR:<stat>,<fo>,<mr>,[<ra>],[<tora>],<scts>,<dt>,<st> OK |
| | d)If text mode (AT+CMGF=1), command successful and SMS-COMMAND: +CMGR:<stat>,<fo>,<ct>[,<pid>,[<mn>],[<da>],[<toda>],<leng |

| | |
|--|--|
| | <p>th]><CR><LF><data> OK e)If text mode (AT+CMGF=1), command successful and CBM storage: +CMGR:<stat>,<sn>,<mid>,<dc>,<page>,<pages><CR><LF><data> OK f)If PDU mode (AT+CMGF=0) and Command successful: +CMGR:<stat>,<alpha>,<length><CR><LF><pdu> OK g)If failed: +CMS ERROR: <err></p> |
| <p>Execution Command AT+CSDH</p> | <p>Response a) Set default value (<show>=0): OK b)If failed: ERROR</p> |

Defined Values

| | |
|----------------------|--|
| <p><stat></p> | <p>1. Text Mode: "REC UNREAD" received unread message (i.e. new message) "REC READ" received read message "STO UNSENT" stored unsent message "STO SENT" stored sent message "ALL" all messages 2. PDU Mode: 0 – received unread message (i.e. new message) 1 – received read message 2 – stored unsent message 3 – stored sent message 4 – all messages</p> |
| <p><index></p> | <p>Integer type; value in the range of location numbers supported by the associated memory and start with zero.</p> |
| <p><oa></p> | <p>Originating-Address, Address-Value field in string format; BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set, type of address given by <toa>.</p> |
| <p><pid></p> | <p>Protocol Identifier</p> |

| | |
|-----------------------|--|
| | GSM 03.40 TP-Protocol-Identifier in integer format 0...255 |
| <alpha> | String type alphanumeric representation of <da> or <oa> corresponding to the entry found in MT phonebook; implementation of this feature is manufacturer specific; used character set should be the one selected with command Select TE Character Set AT+CSCS. |
| <dcs> | Depending on the command or result code: SMS Data Coding Scheme (default 0), or Cell Broadcast Data Coding Scheme in integer format.. |
| <sca> | RP SC address Address-Value field in string format; BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set, type of address given by <tosca>. |
| <tosca> | RP SC address Address-Value field in string format; BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set, type of address given by <tosca>. |
| <scts> | TP-Service-Centre-Time-Stamp in time-string format (refer <dt>). |
| <da> | Destination-Address, Address-Value field in string format; BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set, type of address given by <toda>. |
| <toa> | TP-Originating-Address, Type-of-Address octet in integer format. (default refer <toda>). |
| <toda> | TP-Destination-Address, Type-of-Address octet in integer format. (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129). The range of value is from 128 to 255. |
| <length> | Integer type value indicating in the text mode (AT+CMGF=1) the length of the message body <data> in characters; or in PDU mode (AT+CMGF=0), the length of the actual TP data unit in octets. (i.e. the RP layer SMSC address octets are not counted in the length) |
| <data> | In the case of SMS: TP-User-Data in text mode responses; format: 1. If <dcs> indicates that GSM 7 bit default alphabet is used and <fo> indicates that TP-User-Data-Header-Indication is not set: a. If TE character set other than "HEX": ME/TA converts GSM alphabet into current TE character set. b. If TE character set is "HEX": ME/TA converts each 7-bit character of GSM 7 bit default alphabet into two IRA character long hexadecimal numbers. (e.g. character (GSM 7 bit default alphabet 23) is presented as 17 (IRA 49 and 55)) 2. If <dcs> indicates that 8-bit or UCS2 data coding scheme is used, or <fo> indicates that TP-User-Data-Header-Indication is set: ME/TA converts each 8-bit octet into two IRA character long |

| | |
|--------|---|
| | <p>hexadecimal numbers. (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65))</p> <p>3. If <dc> indicates that GSM 7 bit default alphabet is used:</p> <p>a. If TE character set other than "HEX": ME/TA converts GSM alphabet into current TE character set.</p> <p>b. If TE character set is "HEX": ME/TA converts each 7-bit character of the GSM 7 bit default alphabet into two IRA character long hexadecimal numbers.</p> <p>4. If <dc> indicates that 8-bit or UCS2 data coding scheme is used: ME/TA converts each 8-bit octet into two IRA character long hexadecimal numbers.</p> |
| <fo> | <p>Depending on the command or result code: first octet of GSM 03.40 SMS-DELIVER, SMS-SUBMIT (default 17), SMS-STATUS-REPORT, or SMS-COMMAND (default 2) in integer format. SMS status report is supported under text mode if <fo> is set to 49.</p> |
| <vp> | <p>Depending on SMS-SUBMIT <fo> setting: TP-Validity-Period either in integer format (default 167) or in time-string format (refer <dt>).</p> |
| <mr> | <p>Message Reference GSM 03.40 TP-Message-Reference in integer format.</p> |
| <ra> | <p>Recipient Address GSM 03.40 TP-Recipient-Address Address-Value field in string format;BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set(refer to command AT+CSCS);type of address given by <tora></p> |
| <tora> | <p>Type of Recipient Address GSM 04.11 TP-Recipient-Address Type-of-Address octet in integer format (default refer <toda>)</p> |
| <dt> | <p>Discharge Time GSM 03.40 TP-Discharge-Time in time-string format: "yy/MM/dd,hh:mm:ss+zz", where characters indicate year (two last digits),month,day,hour,minutes,seconds and time zone.</p> |
| <st> | <p>Status GSM 03.40 TP-Status in integer format 0...255</p> |
| <ct> | <p>Command Type GSM 03.40 TP-Command-Type in integer format 0...255</p> |
| <sn> | <p>Serial Number GSM 03.41 CBM Serial Number in integer format</p> |

| | |
|---------|---|
| <mn> | Message Number GSM 03.40 TP-Message-Number in integer format |
| <mid> | Message Identifier GSM 03.41 CBM Message Identifier in integer format |
| <page> | Page Parameter GSM 03.41 CBM Page Parameter bits 4-7 in integer format |
| <pages> | Page Parameter GSM 03.41 CBM Page Parameter bits 0-3 in integer format |
| <pdu> | In the case of SMS: SC address followed by TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal numbers. (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)). |

Example

```
AT+CMGR=1
+CMGR: "STO UNSENT","+10011",,145,17,0,0,167,"+8613800100500",145,11
Hello World
OK
```

9.2.13 AT+CMGS Send message

This command is used to send message from a TE to the network (SMS-SUBMIT).

| AT+CMGS Send message | |
|--|---|
| Test Command AT+CMGS=? | Response OK |
| Write Command If text mode (AT+CMGF=1): AT+CMGS=<da>[,<toda>]<CR>T ext is entered. <CTRL-Z/ESC> If PDU mode(AT+CMGF=0): AT+CMGS=<length><CR> PDU is entered <CTRL-Z/ESC> | Response a)If sending successfully: +CMGS: <mr>[,<time_stamp>] OK b)If cancel sending: OK c)If sending fails: ERROR d)If sending fails: +CMS ERROR: <err> |

Defined Values

| | |
|------|--|
| <da> | Destination-Address, Address-Value field in string format; BCD |
|------|--|

| | |
|----------|---|
| | numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set, type of address given by <tda>. |
| <tda> | TP-Destination-Address, Type-of-Address octet in integer format. (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129). The range of value is from 128 to 255. |
| <length> | integer type value indicating in the text mode (AT+CMGF=1) the length of the message body <data> > (or <cdata>) in characters; or in PDU mode (AT+CMGF=0), the length of the actual TP data unit in octets. (i.e. the RP layer SMSC address octets are not counted in the length) |
| <mr> | Message Reference GSM 03.40 TP-Message-Reference in integer format. |

Example

```
AT+CMGS="13012832788"<CR>(TEXT MODE)
> ABCD<ctrl-Z/ESC>
+CMGS: 46
OK
```

NOTE

- NOTE: In text mode, the maximum length of an SMS depends on the used coding scheme: It is 160 characters if the 7 bit GSM coding scheme is used.

9.2.14 AT+CMSS Send message from storage

This command is used to send message with location value <index> from preferred message storage <mem2> to the network (SMS-SUBMIT or SMS-COMMAND).

AT+CMSS Send message from storage

| | |
|--|--|
| Test Command AT+CMSS=? | Response OK |
| Write Command AT+CMSS= <index> [,<da>[,<tda>]] | Response a) +CMSS: <mr>[,<time_stamp>] OK b)If failed: ERROR |

| | |
|-------------------------------------|--|
| | c)If sending fails: +CMS ERROR: <err> |
| Execution Command AT+CSDH | Response a) Set default value (<show>=0): OK b)If failed: ERROR |

Defined Values

| | |
|----------------------|---|
| <index> | Integer type; value in the range of location numbers supported by the associated memory and start with zero. |
| <da> | Destination-Address, Address-Value field in string format; BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set, type of address given by <tda>. |
| <mr> | Message Reference GSM 03.40 TP-Message-Reference in integer format. |
| <tda> | TP-Destination-Address, Type-of-Address octet in integer format. (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129). The range of value is from 128 to 255. |

Example

```

AT+CMSS=3
+CMSS: 0
OK
AT+CMSS=3,"13012345678"
+CMSS: 55
OK
  
```

NOTE

- NOTE: In text mode, the maximum length of an SMS depends on the used coding scheme: It is 160 characters if the 7 bit GSM coding scheme is used.

9.2.15 AT+CMGW Write message to memory

This command is used to store message (either SMS-DELIVER or SMS-SUBMIT) to memory storage <mem2>.

AT+CMGW Write message to memory

| | |
|--|---|
| Test Command AT+CMGW=? | Response OK |
| Write Command If text mode (AT+CMGF=1): AT+CMGW=<oa>/<da>[,<toa>/<toda>[,<stat>]]<CR>Text is entered. <CTRL-Z/ESC> If PDU mode(AT+CMGF=0): AT+CMGW=<length>[,<stat>]<CR>PDU is entered. <CTRL-Z/ESC> | Response a)If write successfully: +CMGW: <index> OK b)If cancel write: OK c)If write fails: ERROR d)If write fails: +CMS ERROR: <err> |

Defined Values

| | |
|-----------------------|--|
| <index> | Integer type; value in the range of location numbers supported by the associated memory and start with zero. |
| <oa> | Originating-Address, Address-Value field in string format; BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set, type of address given by <toa>. |
| <toa> | TP-Originating-Address, Type-of-Address octet in integer format. (default refer <toda>). |
| <da> | Destination-Address, Address-Value field in string format; BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set, type of address given by <toda>. |
| <toda> | TP-Destination-Address, Type-of-Address octet in integer format. (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129). The range of value is from 128 to 255. |
| <length> | Integer type value indicating in the text mode (AT+CMGF=1) the length of the message body <data> > (or <cdata>) in characters; or in PDU mode (AT+CMGF=0), the length of the actual TP data unit in octets. (i.e. the RP layer SMSC address octets are not counted in the length). |
| <stat> | 1. Text Mode: "STO UNSENT" stored unsend message "STO SENT" stored send message 2. PDU Mode: 2 - stored unsend message 3 - stored send message |

Example

```
AT+CMGW="13012832788" <CR> (TEXT MODE)
ABCD<ctrl-Z/ESC>
+CMGW:1
OK
```

NOTE

- NOTE: In text mode, the maximum length of an SMS depends on the used coding scheme: It is 160 characters if the 7 bit GSM coding scheme is used.

9.2.16 AT+CMGD Delete message

This command is used to delete message from preferred message storage <mem1> location <index>. If <delflag> is present and not set to 0 then the ME shall ignore <index> and follow the rules for <delflag> shown below.

AT+CMGD Delete message

| | |
|---|--|
| Test Command AT+CMGD=? | Response +CMGD: (list of supported <index>s),(list of supported <delflag>s) OK |
| Write Command AT+CMGD=<index>[,<delflag>] | Response a) OK b)If failed: ERROR c)If failed: +CMS ERROR: <err> |

Defined Values

| | |
|-----------|---|
| <index> | Integer type; value in the range of location numbers supported by the associated memory and start with zero. |
| <delflag> | 0 – (or omitted) Delete the message specified in <index>. 1 – Delete all read messages from preferred message storage, |

leaving unread messages and stored mobile originated messages (whether sent or not) untouched.

2 – Delete all read messages from preferred message storage and sent mobile originated messages, leaving unread messages and unsent mobile originated messages untouched.

3 – Delete all read messages from preferred message storage, sent and unsent mobile originated messages leaving unread messages untouched.

4 – Delete all messages from preferred message storage including unread messages.

Example

AT+CMGD=1

OK

NOTE

- NOTE: If set <delflag>=1, 2, 3 or 4, <index> is omitted, such as AT+CMGD=,1.

9.2.17 AT+CMGMT Change message status

This command is used to change the message status. If the status is unread, it will be changed read. Other statuses don't change.

Note: This command not support in CDMA/EVDO mode

AT+CMGMT Change message status

Test Command

AT+CMGMT=?

Response

OK

Write Command

AT+CMGMT=<index>

Response

a)

OK

b)If failed:

ERROR

c)If failed:

+CMS ERROR: <err>

Defined Values

| | |
|---------|--|
| <index> | Integer type; value in the range of location numbers supported by the associated memory and start with zero. |
|---------|--|

Example

```
AT+CMGMT=1
OK
```

9.2.18 AT+CMVP Set message valid period

This command is used to set valid period for sending short message.

Note: This command not support in CDMA/EVDO mode

| AT+CMVP Set message valid period | |
|--|---|
| Test Command AT+CMVP=? | Response +CMVP: (list of supported <vp>s) OK |
| Read Command AT+CMVP? | Response +CMVP:<vp> OK |
| Write Command AT+CMVP=<vp> | Response a) OK b)If failed: ERROR c)If failed: +CMS ERROR: <err> |

Defined Values

| | |
|------|--|
| <vp> | Validity period value: 0 to 143 (<vp>+1) x 5 minutes (up to 12 hours) 144 to 167 12 hours + (<vp>-143) x 30 minutes 168 to 196 (<vp>-166) x 1 day 197 to 255 (<vp>-192) x 1 week |
|------|--|

Example

```
AT+CMVP=167
OK
```

9.2.19 AT+CMGRD Read and delete message

This command is used to read message, and delete the message at the same time. It integrate AT+CMGR and AT+CMGD, but it doesn't change the message status.

Note: This command not support in CDMA/EVDO mode

| AT+CMGRD Read and delete message | |
|--|--|
| Test Command AT+CMGRD=? | Response OK |
| Write Command AT+CMGRD=<index> | <p>Response</p> <p>a)If text mode(AT+CMGF=1),command successful and SMS-DE-LIVER: +CMGRD:<stat>,<oa>,[<alpha>],<scts>[,<toa>,<fo>,<pid>,<dc>,<cs>,<sca>,<tosca>,<length>]<CR><LF><data> OK</p> <p>b)If text mode(AT+CMGF=1),command successful and SMS-SUBMIT: +CMGRD:<stat>,<da>,[<alpha>],[<toda>,<fo>,<pid>,<dc>],[<vp>],<sca>,<tosca>,<length>]<CR><LF><data> OK</p> <p>c)If text mode(AT+CMGF=1),command successful and SMS-STATUS-REPORT: +CMGRD: <stat>,<fo>,<mr>,[<ra>],[<tora>],<scts>,<dt>,<st> OK</p> <p>d)If text mode(AT+CMGF=1),command successful and SMS-COMMAND: +CMGRD:<stat>,<fo>,<ct>[,<pid>,[<mn>],[<da>],[<toda>],<length>]<CR><LF><data>] OK</p> <p>e)If text mode(AT+CMGF=1),command successful and CBM storage: +CMGRD:<stat>,<sn>,<mid>,<dc>,<page>,<pages><CR><LF><data> OK</p> <p>f)If PDU mode(AT+CMGF=0) and command successful: +CMGRD: <stat>,[<alpha>],<length><CR><LF><pdu> OK</p> <p>b)If failed: ERROR</p> <p>c)If failed: +CMS ERROR: <err></p> |

Defined Values

Refer to command AT+CMGR.

Example

AT+CMGRD=6

```
+CMGRD:"REC READ","+8613917787249",,"06/07/10,12:09:38+32",145,4,0,0,"+8613800210500",145,4
```

How do you do

OK

9.2.20 AT+CMGSEX Send message

This command is used to send message from a TE to the network (SMS-SUBMIT).

Note: This command not support in CDMA/EVDO mode

AT+CMGSEX Send message

Test Command
AT+CMGSEX=?

Response

OK

Write Command

If text mode (AT+CMGF=1):

```
AT+CMGSEX=<da>[,<toda>][,<mr>,<msg_seg>,<msg_total>]<CR>Text is entered.  
<CTRL-Z/ESC>
```

Response

a)If sending successfully:

+CMGSEX: <mr>

OK

b)If cancel sending:

OK

c)If sending fails:

ERROR

d)If sending fails:

+CMS ERROR: <err>

Defined Values

<da>

Destination-Address, Address-Value field in string format; BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set, type of address given by <toda>.

<toda>

TP-Destination-Address, Type-of-Address octet in integer format. (When first character of <da> is + (IRA 43) default is 145, otherwise default is 129). The range of value is from 128 to 255.

<mr>

Message Reference

GSM 03.40 TP-Message-Reference in integer format. The

| | |
|-------------|--|
| | maximum length is 255. |
| <msg_seg> | The segment number for long sms |
| <msg_total> | The total number of the segments for long sms. Its range is from 2 to 255. |

Example

```
AT+CMGSEX="13012832788", 190, 1, 2<CR>(TEXT MODE)
> ABCD<ctrl-Z/ESC>
+CMGSEX: 190
OK
AT+CMGSEX="13012832788", 190, 2, 2<CR>(TEXT MODE)
> ABCD<ctrl-Z/ESC>
+CMGSEX: 191
OK
```

NOTE

- NOTE: In text mode, the maximum length of an SMS depends on the used coding scheme: For single SMS, it is 160 characters if the 7 bit GSM coding scheme is used; For multiple long sms, it is 153 characters if the 7 bit GSM coding scheme is used.

9.2.21 AT+CMSSEX Send multi messages from storage

This command is used to send messages with location value <index1>,<index2>,<index3>... from preferred message storage <mem2> to the network (SMS-SUBMIT or SMS-COMMAND).The max count of index is 13 one time.

Note: This command not support in CDMA/EVDO mode

AT+CMSSEX Send multi messages from storage

| | |
|---|---|
| Test Command AT+CMSSEX=? | Response OK |
| Write Command AT+CMSSEX= <index> [,<index >[,...]] | Response a) +CMSSEX: <mr>[,<mr>[,...]] OK b)If failed: ERROR c)If sending fails: |

[+CMSSEX: <mr>[,<mr>[,...]]]

+CMS ERROR: <err>

Defined Values

| | |
|---------|--|
| <index> | Integer type; value in the range of location numbers supported by the associated memory and start with zero. |
| <mr> | Message Reference GSM 03.40 TP-Message-Reference in integer format. |

NOTE: In text mode, the maximum length of an SMS depends on the used coding scheme: It is 160 characters if the 7 bit GSM coding scheme is used.

Example

```
AT+CMSSEX=0,1
+CMSSEX: 239,240
OK
```

NOTE

- NOTE: In text mode, the maximum length of an SMS depends on the used coding scheme: It is 160 characters if the 7 bit GSM coding scheme is used.

9.2.22 AT+CMGP Set cdma/evdo text mode parameters

The command is used to select values for additional parameters needed when SM is sent to the network or placed in storage when text format message mode is selected.

NOTE: take effect in CDMA/EVDO mode

AT+CMGP Set cdma/evdo text mode parameters

| | |
|---|--|
| Test Command AT+CMGP=? | Response OK |
| Read Command AT+CMGP? | Response +CMGP: <tid>,<vpf>,<vp>,<ddtf>,<ddt> OK |
| Write Command AT+CMGP=[Tid][,<vpf>,<vp>,<ddtf>,<ddt>] | Response OK |

Defined Values

| | |
|---------------------|--|
| <tid> | Teleservice ID,value maybe 4095,4096,4097,4098,4099,4100,4101,4102 Default 4098 |
| <vpf> | Valid Period Format 0, Absolute 1, Relative |
| <vp> | Valid Period "YY/MM/DD,HH/MM/SS" if vpf=0, Integer not exceed 248 if vpf=1 |
| <ddtf> | Deferred Delivery Time Format 0, Absolute 1, Relative |
| <ddt> | Deferred Delivery Time "YY/MM/DD,HH/MM/SS" if ddtf=0, Integer not exceed 248 if ddtf=1 |

Example

```
AT+CMGP=4098,0," 11/04/22,16:21:00" ,1,12
```

```
OK
```

10. AT Commands for SSL

10.1 Overview of AT Commands for SSL

| Command | Description |
|--------------|---|
| AT+CCHSTART | Start SSL service |
| AT+CCHSTOP | Stop SSL service |
| AT+CCHOPEN | Connect to SSL server |
| AT+CCHCLOSE | Disconnect from SSL server |
| AT+CCHSEND | Send data to SSL server |
| AT+CCHRECV | Read the cached data that received from the SSL server |
| AT+CCHCFG | Configure the client context |
| AT+CCHSSLCFG | Set the SSL context |
| AT+CCHSET | Configure the report mode of sending and receiving data |
| AT+CCHMODE | Configure the mode of sending and receiving data |
| AT+CCHADDR | Get the IPV4 address |
| AT+CSSLCFG | Configure the SSL context |
| AT+CCERTDOWN | Download certificate into the module |
| AT+CCERTLIST | List certificates |
| AT+CCERTDELE | Delete certificates |

10.2 Detailed Description of AT Commands for SSL

10.2.1 AT+CCHSTART Start SSL service

| AT+CCHSTART Start SSL service | |
|---|--|
| Execution Command AT+CCHSTART | Response a)If start SSL service successfully: OK +CCHSTART: 0 |

| | |
|-----------------------|--|
| | <p>b)If start SSL service successfully: +CCHSTART: 0</p> <p>OK</p> <p>c)If failed: ERROR</p> <p>d)If failed: OK</p> <p>+CCHSTART: <err></p> |
| Parameter Saving Mode | - |
| Maximum Response Time | 120000ms |
| Reference | - |

Defined Values

| | |
|-------|--|
| <err> | Integer type, which indicates the result code. |
|-------|--|

Example

AT+CCHSTART

OK

+CCHSTART: 0

NOTE

- You must execute AT+CCHSTART before any other SSL related operations

10.2.2 AT+CCHSTOP Stop SSL service

AT+CCHSTOP Stop SSL service

| | |
|-------------------|---|
| Execution Command | Response |
| AT+CCHSTOP | <p>a)If stop SSL service successfully: +CCHSTOP: 0</p> <p>OK</p> <p>b)If stop SSL service successfully: OK</p> <p>+CCHSTOP: 0</p> <p>c)If failed:</p> |

| | ERROR |
|-----------------------|-------|
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|-------|--|
| <err> | Integer type, which indicates the result code. |
|-------|--|

Example

```
AT+CCHSTOP
OK
+CCHSTOP: 0
```

10.2.3 AT+CCHOPEN Connect to SSL server

| AT+CCHOPEN Connect to SSL server | |
|---|--|
| Test Command AT+CCHOPEN=? | Response +CCHOPEN: (0-1),"ADDRESS",(1-65535)[,(1-2)[,(1-65535)]] |
| Read Command AT+CCHOPEN? | Response If connect to a server, it will show the connected information. Otherwise, the connected information is empty. +CCHOPEN: 0,"<host>",<port>,<client_type>[,<bind_port>] +CCHOPEN: 1,"<host>",<port>,<client_type>[,<bind_port>] |
| Write Command AT+CCHOPEN=<session_id>,"host",<port>[,<client_type>[,<bind_port>]] | Response a)If connect successfully: +CCHOPEN: <session_id>,0 OK b)If connect successfully: OK +CCHOPEN: <session_id>,0 c)If connect successfully in transparent mode: CONNECT [<text>] d)If failed: |

| | |
|-----------------------|--|
| | <p>OK</p> <p>+CCHOPEN: <session_id>,<err> [+CCHCLOSE: <session_id>,<err>] e)If failed: ERROR f)If failed in transparent mode: CONNECT FAIL</p> |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|----------------------------|--|
| <session_id> | The session index to operate. It's from 0 to 1. |
| <host> | The server address, length range is 1 to 256. |
| <port> | The server port which to be connected, the range is from 1 to 65535. |
| <client_type> | The type of client: 1 – TCP client. 2 – SSL/TLS client. Default value is 2. |
| <bind_port> | The local port for channel, the range is from 1 to 65535. |
| <text> | CONNECT result code string; the string formats please refer ATX/ATV/AT&E command. |
| <err> | Integer type, the result of operation.0 is success, other value is failure. |

Example

```
AT+CCHOPEN=0,"www.baidu.com",443,2
```

```
OK
```

```
+CCHOPEN: 0,0
```

NOTE

- If you don't set the SSL context by AT+CCHSSLCFG before connecting a SSL/TLS server by AT+CCHOPEN, it will use the <session_id> (the 1'st parameter of AT+CCHOPEN) SSL context when connecting to the server.

10.2.4 AT+CCHCLOSE Disconnect from SSL server

AT+CCHCLOSE Disconnect from SSL server

| | |
|--|--|
| Write Command AT+CCHCLOSE=<session_id> | Response a)If successfully: +CCHCLOSE: <session_id>,0 OK b)If successfully: OK +CCHCLOSE: <session_id>,0 c)If successfully in transparent mode: OK CLOSED d)If failed: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|---------------------------|---|
| <session_id> | The session index to operate. It's from 0 to 1. |
| <err> | Integer type, the result of operation. 0 is success, other value is failure |

Example

```
AT+CCHCLOSE=0
OK
+CCHCLOSE: 0,0
```

10.2.5 AT+CCHSEND Send data to SSL server

AT+CCHSEND Send data to SSL server

| | |
|-------------------------------------|--|
| Test Command AT+CCHSEND=? | Response +CCHSEND: (0-1),(1-2048) OK |
| Read Command AT+CCHSEND? | Response +CCHSEND: 0,<unsent_len_0>,1,<unsent_len_1> |

| | |
|---|---|
| Write Command AT+CCHSEND=<session_id>,<len> | <p>OK</p> <p>Response</p> <p>a)if parameter is right:</p> <p>></p> <p><input data here></p> <p>When the total size of the inputted data reaches <len>, TA will report the following code. Otherwise, the serial port will be blocked.</p> <p>OK</p> <p>b)If parameter is wrong or other errors occur:</p> <p>ERROR</p> |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|-----------------------------|--|
| <session_id> | The session index to operate. It's from 0 to 1. |
| <len> | The length of data to send. Its range is from 1 to 2048 bytes. |
| <unsent_len_0> | The data of connection 0 cached in sending buffer which is waiting to be sent. |
| <unsent_len_1> | The data of connection 1 cached in sending buffer which is waiting to be sent. |

Example

```

AT+CCHSEND=0,125
> GET / HTTP/1.1
Host: www.google.com.hk
User-Agent: MAUI htp User Agent
Proxy-Connection: keep-alive
Content-Length: 0

OK

```

10.2.6 AT+CCHRECV Read the cached data that received from the server

AT+CCHRECV Read the cached data that received from the server

| | |
|------------------------------------|--|
| Read Command AT+CCHRECV? | <p>Response</p> <p>+CCHRECV: LEN,<cache_len_0>,<cache_len_1></p> <p>OK</p> |
|------------------------------------|--|

| | |
|--|---|
| Write Command AT+CCHRECV=<session_id>[<max_rcv_len>] | Response a) if parameter is right and there are cached data: OK [+CCHRECV: DATA,<session_id>,<len> ... +CCHRECV: DATA,<session_id>,<len> ...] +CCHRECV: <session_id>,<err> b) if parameter is not right or any other error occurs: +CCHRECV: <session_id>,<err> ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|----------------------------|--|
| <session_id> | The session_id to operate. It's from 0 to 1. |
| <max_rcv_len> | Maximum bytes of data to receive in the current AT+CCHRECV calling. It will read all the received data when the value is greater than the length of RX data cached for session <session_id>. 0 means the maximum bytes to receive is 2048 bytes. (But, when 2048 is greater than the length of RX data cached for session <session_id>, 0 means the length of RX data cached for session <session_id>). The default value is the length of RX data cached for session <session_id>. It will be not allowed when there is no data in the cache. |
| <cache_len_0> | The length of RX data cached for connection 0. |
| <cache_len_1> | The length of RX data cached for connection 1. |
| <len> | The length of data followed. |
| <err> | String type, displays the cause of occurring error, please refer to Chapter 10.3 for details. |

Example

```
AT+CCHRECV=1
OK
+CCHRECV: DATA,1,249
HTTP/1.1 200 OK
Content-Type: text/html
Content-Language: zh-CN
Content-Length: 57
```


Date: Tue, 31 Mar 2009 01:56:05 GMT

Connection: Close

Proxy-Connection: Close

```
<html>
<header>test</header>
<body>
Test body
</body>
```

+CCHRECV: 1,0

10.2.7 AT+CCHADDR Get IPV4 address

AT+CCHADDR Get IPV4 address

| | |
|--|---|
| Execution Command AT+CCHADDR | Response: +CCHADDR: <ip_address> OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|---------------------------|--|
| <ip_address> | A string parameter that identifies the IPv4 address after PDP activated. |
|---------------------------|--|

Example

```
AT+CCHADDR
+CCHADDR: 10.71.155.118

OK
```

10.2.8 AT+CCHCFG Configure the client context

AT+CCHCFG Configure the client context

| Test Command | Response |
|--------------|----------|
|--------------|----------|

| | |
|--|--|
| AT+CCHCFG=? | <p>+CCHCFG: "sendtimeout",(0-1),(60-150) +CCHCFG: "sslctx",(0-1),(0-9)</p> <p>OK</p> |
| Read Command AT+CCHCFG? | <p>Response</p> <p>+CCHCFG: 0,<sendtimeout_val>,<sslctx_index> +CCHCFG: 1,<sendtimeout_val>,<sslctx_index></p> <p>OK</p> |
| Write Command /*Configure the timeout value of the specified client when sending data*/ | <p>Response</p> <p>If successfully:</p> <p>OK</p> <p>If failed:</p> <p>ERROR</p> |
| AT+CCHCFG="sendtimeout",<session_id>,<sendtimeout_val> | |
| Write Command /*Configure the SSL context index, it's as same as AT+CSSLCFG*/ | <p>Response</p> <p>If successfully:</p> <p>OK</p> <p>If failed:</p> <p>ERROR</p> |
| AT+CCHCFG="sslctx",<session_id>,<sslctx_index> | |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|-------------------|--|
| <session_id> | The session_id to operate. It's from 0 to 1. |
| <sendtimeout_val> | The timeout value used in sending data stage. The range is 60-150 seconds. The default value is 150. |
| <sslctx_index> | The SSL context ID which will be used in the SSL connection. Refer to the <ssl_ctx_index> of AT+CSSLCFG . |

Example

```
AT+CCHCFG="sendtimeout",0,60
OK
```

NOTE

- This command must be called before AT+CCHOPEN and after AT+CCHSTART. The setting will be cleared after AT+CCHOPEN failed or AT+CCHCLOSE.

10.2.9 AT+CCHSSLCFG Set the SSL context

| AT+CCHSSLCFG Set the SSL context | |
|---|---|
| Test Command AT+CCHSSLCFG=? | Response +CCHSSLCFG: (0-1),(0-9) OK |
| Read Command AT+CCHSSLCFG? | Response +CCHSSLCFG: <session_id>,[ssl_ctx_index] +CCHSSLCFG: <session_id>,[ssl_ctx_index] OK |
| Write Command AT+CCHSSLCFG=<session_id>,<ssl_ctx_index> | Response a) If successfully: OK b) If failed: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|------------------------------|--|
| <session_id> | The session_id to operate. It's from 0 to 1. |
| <ssl_ctx_index> | The SSL context ID which will be used in the SSL connection. Refer to the <ssl_ctx_index> of AT+CSSLCFG . |

Example

```
AT+CCHSSLCFG=?
+CCHSSLCFG: (0-1),(0-9)

OK
AT+CCHSSLCFG=1,1
OK
```

NOTE

- This command must be called before AT+CCHOPEN and after AT+CCHSTART. The setting will be cleared after AT+CCHOPEN failed or AT+CCHCLOSE.
- If you don't set the SSL context by this command before connecting to SSL/TLS server by AT+CCHOPEN, the CCHOPEN operation will use the SSL context as same as index <session_id> (the 1st parameter of AT+CCHOPEN) when connecting to the server.

10.2.10 AT+CCHMODE Configure the mode of sending and receiving data

| AT+CCHMODE Configure the mode of sending and receiving mode | |
|---|---|
| Test Command AT+CCHMODE=? | Response +CCHMODE: (0-1) OK |
| Read Command AT+CCHMODE? | Response +CCHMODE: <mode> OK |
| Write Command AT+CCHMODE=<mode> | Response a) If successfully: OK b) If failed: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|---------------------|--|
| <mode> | The mode value: 0 – Normal 1 – Transparent mode The default value is 0. |
|---------------------|--|

Example

```

AT+CCHMODE=?
+CCHMODE: (0-1)

OK
AT+CCHMODE=1
OK
  
```

NOTE

- This command must be called before AT+CCHSTART.
- There is only one session in the transparent mode, it's the first session.

10.2.11 AT+CCHSET Configure the report mode of sending and receiving data

| AT+CCHSET Configure the report mode of sending and receiving data | |
|--|---|
| Test Command AT+CCHSET=? | Response +CCHSET: (0-1),(0,1) OK |
| Read Command AT+CCHSET? | Response +CCHSET: <report_send_result>,<recv_mode> OK |
| Write Command AT+CCHSET=<report_send_result>[,<recv_mode>] | Response a) If successfully: OK b) If failed: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|-----------------------------------|---|
| <report_send_result> | Whether to report result of CCHSEND, the default value is 0: 0 – No. 1–Yes. Module will report +CCHSEND: <session_id>,<err> to MCU when complete sending data. |
| <recv_mode> | The receiving mode: 0 -- Output the data to MCU whenever received data. 1 -- Module caches the received data and notifies MCU with +CCHEVENT: <session_id>, RECV EVENT. MCU can use AT+CCHRECV to receive the cached data (only in manual receiving mode). |

Example

```

AT+CCHSET=?
+CCHSET: (0-1),(0,1)

OK
AT+CCHSET=1,1
OK

```

NOTE

- This command must be called before AT+CCHSTART.

10.2.12 AT+CSSLCFG Configure the SSL context

AT+CSSLCFG Configure the SSL context

Test Command
AT+CSSLCFG=?

Response
+CSSLCFG: "sslversion",(0-9),(0-4)
+CSSLCFG: "authmode",(0-9),(0-3)
+CSSLCFG: "ignorelocaltime",(0-9),(0,1)
+CSSLCFG: "negotiatetime",(0-9),(10-300)
+CSSLCFG: "cacert",(0-9),(5-128)
+CSSLCFG: "clientcert",(0-9),(5-128)
+CSSLCFG: "clientkey",(0-9),(5-128)
+CSSLCFG: "enableSNI",(0-9),(0,1)
+CSSLCFG: "keypwd",(0-9),(0-128)
+CSSLCFG: "ciphersuites",(0-9),(0x002F,0xFFFF)

Read Command
AT+CSSLCFG=?

OK
 Response
+CSSLCFG:
 0,<sslversion>,<authmode>,<ignoreltime>,<negotiatetime>,<ca_file>,<clientcert_file>,<clientkey_file>,<enalbeSNI_flag>,<keypwd>,<ciphersuites>
+CSSLCFG:
 1,<sslversion>,<authmode>,<ignoreltime>,<negotiatetime>,<ca_file>,<clientcert_file>,<clientkey_file>,<enalbeSNI_flag>,<keypwd>,<ciphersuites>
+CSSLCFG:
 2,<sslversion>,<authmode>,<ignoreltime>,<negotiatetime>,<ca_file>,<clientcert_file>,<clientkey_file>,<enalbeSNI_flag>,<keypwd>,<ciphersuites>
+CSSLCFG:
 3,<sslversion>,<authmode>,<ignoreltime>,<negotiatetime>,<ca_file>,<clientcert_file>,<clientkey_file>,<enalbeSNI_flag>,<keypwd>,<ciphersuites>
+CSSLCFG:
 4,<sslversion>,<authmode>,<ignoreltime>,<negotiatetime>,<ca_file>,<clientcert_file>,<clientkey_file>,<enalbeSNI_flag>,<keypwd>,<ciphersuites>
+CSSLCFG:

| | |
|--|--|
| | <p>5,<sslversion>,<authmode>,<ignoreltime>,<negotiatetime>,<ca_file>,<clientcert_file>,<clientkey_file>,<enalbeSNI_flag>,<keypwd>,<ciphersuites> +CSSLCFG: 6,<sslversion>,<authmode>,<ignoreltime>,<negotiatetime>,<ca_file>,<clientcert_file>,<clientkey_file>,<enalbeSNI_flag>,<keypwd>,<ciphersuites> +CSSLCFG: 7,<sslversion>,<authmode>,<ignoreltime>,<negotiatetime>,<ca_file>,<clientcert_file>,<clientkey_file>,<enalbeSNI_flag>,<keypwd>,<ciphersuites> +CSSLCFG: 8,<sslversion>,<authmode>,<ignoreltime>,<negotiatetime>,<ca_file>,<clientcert_file>,<clientkey_file>,<enalbeSNI_flag>,<keypwd>,<ciphersuites> +CSSLCFG: 9,<sslversion>,<authmode>,<ignoreltime>,<negotiatetime>,<ca_file>,<clientcert_file>,<clientkey_file>,<enalbeSNI_flag>,<keypwd>,<ciphersuites></p> <p>OK</p> |
| <p>Write Command /*Query the configuration of the specified SSL context*/ AT+CSSLCFG=<ssl_ctx_index></p> | <p>Response +CSSLCFG: <ssl_ctxindex>,<sslversion>,<authmode>,<ignoreltime>,<negotiatetime>,<ca_file>,<clientcert_file>,<clientkey_file>,<enalbeSNI_flag>,<keypwd>,<ciphersuites></p> <p>OK</p> |
| <p>Write Command /*Configure the version of the specified SSL context*/ AT+CSSLCFG="sslversion",<ssl_ctx_index>,<sslversion></p> | <p>Response a)If successfully: OK b)If failed: ERROR</p> |
| <p>Write Command /*Configure the authentication of the specified SSL context*/ AT+CSSLCFG="authmode",<ssl_ctx_index>,<authmode></p> | <p>Response a)If successfully: OK b)If failed: ERROR</p> |
| <p>Write Command /*Configure the ignore local time flag of the specified SSL context*/ AT+CSSLCFG="ignorelocalti</p> | <p>Response a)If successfully: OK b)If failed: ERROR</p> |

| | |
|---|--|
| <p>me”,<ssl_ctx_index>,<ignore ltime></p> <p>Write Command /*Configure the negotiate timeout value of the specified SSL context*/</p> <p>AT+CSSLCFG="negotiatetim e”,<ssl_ctx_index>,<negotiat etime></p> | <p>Response a)If successfully: OK b)If failed: ERROR</p> |
| <p>Write Command /*Configure the server root CA of the specified SSL context*/</p> <p>AT+CSSLCFG="cacert”,<ssl_ ctx_index>,<ca_file></p> | <p>Response a)If successfully: OK b)If failed: ERROR</p> |
| <p>Write Command /*Configure the client certificate of the specified SSL context*/</p> <p>AT+CSSLCFG="clientcert”,<s sl_ctx_index>,<clientcert_file ></p> | <p>Response a)If successfully: OK b)If failed: ERROR</p> |
| <p>Write Command /*Configure the client key of the specified SSL context*/</p> <p>AT+CSSLCFG="clientkey”,<s sl_ctx_index>,<clientkey_file ></p> | <p>Response a)If successfully: OK b)If failed: ERROR</p> |
| <p>Write Command /*Configure the enableSNI flag of the specified SSL context*/</p> <p>AT+CSSLCFG="enableSNI”,< ssl_ctx_index>,<enableSNI_F lag></p> | <p>Response a)If successfully: OK b)If failed: ERROR</p> |
| <p>Write Command /*Configure the password of the specified SSL context*/</p> <p>AT+CSSLCFG="keypwd”,<ss l_ctx_index>,<keypwd></p> | <p>Response a)If successfully: OK b)If failed: ERROR</p> |
| <p>Write Command /*Configure the ciphersuite of the specified SSL context*/</p> | <p>Response a)If successfully: OK</p> |

| | |
|---|------------------------------|
| AT+CSSLCFG="ciphersuites",<ssl_ctx_index>,<ciphersuites> | b)If failed: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|------------------------------|--|
| <ssl_ctx_index> | The SSL context ID. The range is 0-9. |
| <sslversion> | <p>The SSL version, the default value is 4.</p> <p>0 – SSL3.0 1 – TLS1.0 2 – TLS1.1 3 – TLS1.2 4 – All</p> <p>The configured version should be support by server. So you should use the default value if you can't confirm the version which the server supported.</p> |
| <authmode> | <p>The authentication mode, the default value is 0.</p> <p>0 – no authentication. 1 –server authentication. It needs the root CA of the server. 2 –server and client authentication. It needs the root CA of the server, the cert and key of the client. 3 –client authentication and no server authentication. It needs the cert and key of the client.</p> |
| <ignoreltime> | <p>The flag to indicate how to deal with expired certificate, the default value is 1.</p> <p>0 – care about time check for certification. 1 – ignore time check for certification</p> <p>When set the value to 0, it need to set the right current date and time by AT+CCLK when need SSL certification.</p> |
| <negotiatetime> | The timeout value which is used in SSL negotiating stage. The range is 10-300 seconds. The default value is 300. |
| <ca_file> | <p>The root CA file name of SSL context. The file name must have type like ".pem" or ".der". The length of filename is from 5 to 128 bytes.</p> <p>If the filename contains non-ASCII characters, the file path parameter should contain a prefix of {non-ascii} and the quotation mark (The string in the quotation mark should be hexadecimal of the filename's UTF8 code).</p> <p>There are two ways to download certificate files to module:</p> |

| | | | | | |
|--------------------------------|--|--------|------------------------------|--------|-------------|
| | <ol style="list-style-type: none"> 1. By AT+CCERTDOWN. 2. By FTPS or HTTPS commands. Please refer to chapter 12 and 13. | | | | |
| <clientcert_file> | <p>The client cert file name of SSL context. The file name must have type like “.pem” or “.der”. The length of filename is from 5 to 128 bytes.</p> <p>If the filename contains non-ASCII characters, the file path parameter should contain a prefix of {non-ascii} and the quotation mark (The string in the quotation mark should be hexadecimal of the filename’s UTF8 code).</p> <p>There are two ways to download certificate files to module:</p> <ol style="list-style-type: none"> 1. By AT+CCERTDOWN. 2. By FTPS or HTTPS commands. Please refer to chapter 12 and 13. | | | | |
| <clientkey_file> | <p>The client key file name of SSL context. The file name must have type like “.pem” or “.der”. The length of filename is from 5 to 128 bytes.</p> <p>If the filename contains non-ASCII characters, the file path parameter should contain a prefix of {non-ascii} and the quotation mark (The string in the quotation mark should be hexadecimal of the filename’s UTF8 code).</p> <p>There are two ways to download certificate files to module:</p> <ol style="list-style-type: none"> 1. By AT+CCERTDOWN. 2. By FTPS or HTTPS commands. Please refer to chapter 12 and 13. | | | | |
| <enableSNI_flag> | <p>The flag to indicate that enable the SNI flag or not, the default value is 0.</p> <p>0 – not enable SNI. 1 – enable SNI.</p> | | | | |
| <keypwd> | <p>The password of the client key file of SSL context. When the client needs to be authorized, client key file is needed. Because the client key file may be encrypted, we need the <keypwd> to decrypt it. The length of <keypwd> is from 0 to 128 bytes.</p> | | | | |
| <ciphersuites> | <p>Numeric type, SSL ciphersuites</p> <table border="0"> <tr> <td>0x002F</td> <td>TLS_RSA_WITH_AES_128_CBC_SHA</td> </tr> <tr> <td>0xFFFF</td> <td>Support all</td> </tr> </table> | 0x002F | TLS_RSA_WITH_AES_128_CBC_SHA | 0xFFFF | Support all |
| 0x002F | TLS_RSA_WITH_AES_128_CBC_SHA | | | | |
| 0xFFFF | Support all | | | | |

Example

```
AT+CSSLCFG="sslversion",1,1
OK
```

10.2.13 AT+CCERTDOWN Download certificate into the module

AT+CCERTDOWN Download certificate into the module

| | |
|---|---|
| Test Command AT+CCERTDOWN=? | Response +CCERTDOWN: (5-128),(1-10240) OK |
| Write Command AT+CCERTDOWN=<filename>,<len> | Response a)If it can be download: > <input data here> OK b)If failed: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|-------------------------|---|
| <filename> | The name of the certificate/key file. The file name must have type like “.pem” or “.der”. The length of filename is from 5 to 128 bytes. If the filename contains non-ASCII characters, the file path parameter should contain a prefix of {non-ascii} and the quotation mark (The string in the quotation mark should be hexadecimal of the filename’s UTF8 code). For example: If you want to download a file with name “中华.pem”, you should convert the “ 中 华 .pem” to UTF8 coding (中华.pem), then input the hexadecimal (262378344532443B262378353334453B2E70656D) of UTF8 coding. |
| len> | The length of the file data to send. The range is from 1 to 10240 bytes. |

Example

```
AT+CCERTDOWN="client_key.der",611
> file content.....
OK
```

10.2.14 AT+CCERTLIST List certificates

AT+CCERTLIST List certificates

| | |
|--|---|
| Execution Command AT+CCERTLIST | Response [+CCERTLIST: <file_name> |
|--|---|

| | |
|-----------------------|---|
| | [+CCERTLIST: <file_name>] ... <CR><LF>] OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|-------------|--|
| <file_name> | The certificate/key files which has been downloaded to the module. If the filename contains non-ASCII characters, it will show the non-ASCII characters as UTF8 code. |
|-------------|--|

Example

```
AT+CCERTLIST
+CCERTLIST: "ca_cert.der"
+CCERTLIST: "client_key.pem"

OK
```

10.2.15 AT+CCERTDELE Delete certificates

| AT+CCERTDELE Delete certificates | |
|---|--|
| Write Command AT+CCERTDELE=<filename> | Response a)If delete successfully: OK b)If failed: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|------------|--|
| <filename> | The name of the certificate/key file. The file name must have type like ".pem" or ".der". The length of filename is from 5 to 128 bytes. If the filename contains non-ASCII characters, the file path parameter should contain a prefix of {non-ascii} and the quotation mark (The string in the quotation mark should be hexadecimal of the filename's |
|------------|--|

UTF8 code).

For example: If you want to download a file with name “中华.pem”, you should convert the “ 中 华 .pem” to UTF8 coding (中华.pem), then input the hexadecimal (262378344532443B262378353334453B2E70656D) of UTF8 coding.

Example

```
AT+CCERTDELETE="server_ca.der"
```

```
OK
```

10.3 Command result <err> codes

| Result Code | |
|-------------|--------------------------|
| 0 | Operation succeeded |
| 1 | Alerting state(reserved) |
| 2 | Unknown error |
| 3 | Busy |
| 4 | Peer closed |
| 5 | Operation timeout |
| 6 | Transfer failed |
| 7 | Memory error |
| 8 | Invalid parameter |
| 9 | Network error |
| 10 | Open session error |
| 11 | State error |
| 12 | Create socket error |
| 13 | Get DNS error |
| 14 | Connect socket error |
| 15 | Handshake error |
| 16 | Close socket error |
| 17 | Nonet |
| 18 | Send data timeout |
| 19 | Not set certificates |

10.4 Unsolicited result codes

| Information | Description |
|---|---|
| +CCHEVENT: <session_id>,RECV EVENT | In manual receiving mode, when new data of a connection arriving to the module, this unsolicited result code will be reported to MCU. |
| +CCH_RECV_CLOSED: <session_id>,<err> | When receive data occurred any error, this unsolicited result code will be reported to MCU. |
| +CCH_PEER_CLOSED: <session_id> | The connection is closed by the server. |

SIMCom
Confidential

11. AT Commands for TCPIP

11.1 Overview of AT Commands for TCPIP

| Command | Description |
|----------------|---|
| AT+NETOPEN | Start TCPIP service |
| AT+NETCLOSE | Stop TCPIP service |
| AT+CIOOPEN | Setup TCP/UDP client socket connection |
| AT+CIPCLOSE | Destroy TCP/UDP client socket connection |
| AT+CIPSEND | Send TCP/UDP data |
| AT+CIPRXGET | Retrieve TCP/UDP buffered data |
| AT+IPADDR | Get IP address of PDP context |
| AT+CIPHEAD | Add an IP header when receiving data |
| AT+CIPSRIP | Show remote IP address and port |
| AT+CIPMODE | Select TCP/IP application mode |
| AT+CIPSENDMOE | Set sending mode |
| AT+CIPTIMEOUT | Set TCP/IP timeout value |
| AT+CIPCCFG | Configure parameters of socket |
| AT+SERVERSTART | Startup TCP server |
| AT+SERVERSTOP | Stop TCP server |
| AT+CIPACK | Query TCP connection data transmitting status |
| AT+CDNSGIP | Query the IP address of given domain name |
| AT+CDNSGHNAME | Query the domain name of given IP address |
| AT+CIPDNSSET | Set DNS query parameters |
| AT+CPING | Ping destination address |
| AT+CPINGSTOP | Stop an ongoing ping session |

11.2 Detailed Description of AT Commands for TCPIP

11.2.1 AT+NETOPEN Start TCPIP service

AT+NETOPEN Start TCPIP service

| | |
|--|---|
| Read Command AT+NETOPEN? | Response +NETOPEN: <net_state> OK |
| Execution Command AT+NETOPEN | Response If the PDP context has not been activated or the network closed abnormally, response: OK +NETOPEN: <err> when the PDP context has been activated successfully, if you execute AT+NETOPEN again, response: +IP ERROR: Network is already opened ERROR other: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | 120000ms |
| Reference | - |

Defined Values

| | |
|--------------------------|--|
| <net_state> | Integer type, which indicates the state of PDP context activation. 0 network close (deactivated) 1 network open(activated) |
| <err> | Integer type, the result of operation. 0 is success, other value is failure. |

Example

```

AT+NETOPEN
OK

+NETOPEN: 0
AT+NETOPEN?
+NETOPEN: 1

OK

```

NOTE

- You must execute AT+NETOPEN before any other TCP/UDP related operations

11.2.2 AT+NETCLOSE Stop TCPIP service

AT+NETCLOSE Stop TCPIP service

| | |
|---|---|
| Execution Command AT+NETCLOSE | Response If the PDP context has been activated, response: OK +NETCLOSE: <err> If the PDP context has not been activated, response: +NETCLOSE: <err> ERROR other: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|-------|---|
| <err> | Integer type, the result of operation.0 is success, other value is failure. |
|-------|---|

Example

```
AT+NETCLOSE
OK
+NETCLOSE: 0
```

NOTE

- “AT+NETCLOSE” can close all the opened socket connections when you didn’t close these connections by “AT+CIPCLOSE”.

11.2.3 AT+CIPOPEN Setup TCP/UDP client socket connection

AT+CIPOPEN Setup TCP/UDP client socket connection

| | |
|--|--|
| <p>Test Command AT+CIOPEN=?</p> | <p>Response +CIOPEN: (0-9),("TCP","UDP")</p> <p>OK</p> |
| <p>Read Command AT+CIOPEN?</p> | <p>Response +CIOPEN: <link_num> [<type>,<serverIP>,<serverPort>,<index>] +CIOPEN: <link_num> [<type>,<serverIP>,<serverPort>,<index>] [...]</p> <p>OK</p> <p>If a connection identified by <link_num> has not been established successfully, +CIOPEN: <link_num> will be returned.</p> |
| <p>Write Command TCP connection AT+CIOPEN=<link_num>,<type>,<serverIP>,<serverPort>,<localPort></p> | <p>Response if PDP context has been activated successfully, response: OK</p> <p>+CIOPEN: <link_num>,<err> when the <link_num> is greater than 10, response: +IP ERROR: Invalid parameter</p> <p>ERROR</p> <p>If PDP context has not been activated, or the connection has been established, or parameter is incorrect, or other errors, response: +CIOPEN: <link_num>,<err></p> <p>ERROR</p> <p>Transparent mode for TCP connection: When you want to use transparent mode to transmit data, you should set AT+CIPMODE=1 before AT+NETOPEN. And if AT+CIPMODE=1 is set, the <link_num> is restricted to be only 0. if success CONNECT [<text>]</p> <p>if failure CONNECT FAIL</p> <p>other: ERROR</p> |
| <p>Write Command UDP connection AT+CIOPEN=<link_num>,<type>,<localPort></p> | <p>if PDP context has been activated successfully, response: +CIOPEN: <link_num>,0</p> <p>OK</p> <p>when the <link_num> is greater than 10, response:</p> |

+IP ERROR: Invalid parameter

ERROR

If PDP context has not been activated, or the connection has been established, or parameter is incorrect, or other errors, response:

+CIPOPEN: <link_num>,<err>

ERROR

Transparent mode for UDP connection:

When you want to use transparent mode to transmit UDP data, you should set AT+CIPMODE=1 before AT+NETOPEN. And if AT+CIPMODE=1 is set, the <link_num> is restricted to be only 0. <serverIP> and <serverPort> should be set if AT+CIPMODE=1.

if success

CONNECT [<text>]

if failure

CONNECT FAIL

Other:

ERROR

| | |
|-----------------------|----------|
| Parameter Saving Mode | - |
| Maximum Response Time | 120000ms |
| Reference | - |

Defined Values

| | |
|---------------------------|--|
| <link_num> | Integer type, identifies a connection. Range is 0-9. If AT+CIPMODE=1 is set, the <link_num> is restricted to be only 0. |
| <type> | String type, identifies the type of transmission protocol. TCP Transmission Control Protocol UDP User Datagram Protocol |
| <serverIP> | String type, identifies the IP address of server. The IP address format consists of 4 octets, separated by decimal point, like "AAA.BBB.CCC.DDD". Also the domain name is supported here. NOTE: If the domain name is inputted here, the timeout value for the AT+CIPOPEN shall be decided by AT+CIPDNSSET . |
| <serverPort> | Integer type, identifies the port of TCP server, range is 0-65535. NOTE: When open port as TCP, the port must be the opened TCP port; When open port as UDP, the port may be any port. But, for Qualcomm, connecting the port 0 is regarded as an invalid |

| | |
|-------------|---|
| | operation. |
| <localPort> | Integer type, identifies the port of local socket, range is 0-65535. |
| <index> | Integer type, which indicates whether the module is used as a client or server. When used as server, the range is 0-3. <index> is the server index to which the client is linked. (-1) -- TCP/UDP client (0-3) -- TCP server index |
| <text> | String type, which indicates CONNECT result code. Please refer to ATX/ATV/AT&E command for the string formats. |
| <err> | Integer type, the result of operation.0 is success, other value is failure. |

Example

```
AT+CIOPEN=0,"TCP","116.228.221.51",100
```

```
OK
```

```
+CIOPEN: 0,0
```

```
AT+CIOPEN=1,"UDP",,,8080
```

```
+CIOPEN: 1,0
```

```
OK
```

```
AT+CIOPEN=?
```

```
+CIOPEN: (0-9),("TCP","UDP")
```

```
OK
```

```
AT+CIOPEN?
```

```
+CIOPEN: 0,"TCP","116.228.221.51",100,-1
```

```
+CIOPEN: 1
```

```
+CIOPEN: 2
```

```
+CIOPEN: 3
```

```
+CIOPEN: 4
```

```
+CIOPEN: 5
```

```
+CIOPEN: 6
```

```
+CIOPEN: 7
```

```
+CIOPEN: 8
```

```
+CIOPEN: 9
```

```
OK
```

11.2.4 AT+CIPCLOSE Destroy TCP/UDP client socket connection

| AT+CIPCLOSE Destroy TCP/UDP client socket connection | |
|--|---|
| Test Command AT+CIPCLOSE=? | Response +CIPCLOSE: (0-9) OK |
| Read Command AT+CIPCLOSE? | Response +CIPCLOSE: <link0_state>,<link1_state>,<link2_state>,<link3_state>,<link4_state>,<link5_state>,<link6_state>,<link7_state>,<link8_state>,<link9_state> OK |
| Write Command AT+CIPCLOSE=<link_num> | Response If service type is TCP and the connection identified by <link_num> has been established, response: OK +CIPCLOSE: <link_num>,<err> If service type is TCP and the access mode is transparent mode, response: OK CLOSED +CIPCLOSE: <link_num>,<err> If service type is UDP and the connection identified by <link_num> has been established, response: +CIPCLOSE: <link_num>,0 OK If service type is UDP and access mode is transparent mode, response: CLOSED +CIPCLOSE: <link_num>,<err> OK If the connection has not been established, abnormally closed, or parameter is incorrect, response: +CIPCLOSE: <link_num>,<err> ERROR |

| | |
|-----------------------|------------------------|
| | Other: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|--------------|--|
| <link_num> | Integer type, which identifies a connection. Range is 0-9. |
| <link_state> | Integer type, which indicates the state of connection identified by <link_num>. Range is 0-1. 0 -- disconnected 1 -- connected |
| <err> | Integer type, the result of operation. 0 is success, other value is failure |

Example

```

AT+CIPCLOSE?
+CIPCLOSE: 1,0,0,0,0,0,0,0,0,0

OK
AT+CIPCLOSE=?
+CIPCLOSE: (0-9)

OK
AT+CIPCLOSE=0
OK

+CIPCLOSE: 0,0

```

11.2.5 AT+CIPSEND Send TCP/UDP data

| AT+CIPSEND Send TCP/UDP data | |
|---|---|
| Test Command AT+CIPSEND=? | Response +CIPSEND: (0-9),(1-1500) |
| | OK |
| Write Command If service type is "TCP", send data with changeable length | Response If the connection identified by <link_num> has been established successfully, response: |

| | |
|--|--|
| <p>AT+CIPSEND=<link_num>,</p> <p>Response “>”, then type data to send, tap CTRL+Z to send data, tap ESC to cancel the operation</p> | <p>></p> <p><input data></p> <p>CTRL+Z</p> <p>OK</p> <p>+CIPSEND: <link_num>,<reqSendLength>, <cnfSendLength></p> <p>If <reqSendLength> is equal <cnfSendLength>, it means that the data has been sent to TCP/IP protocol stack successfully.</p> <p>If the connection has not been established, abnormally closed, or parameter is incorrect, response:</p> <p>+CIPERROR: <err></p> |
| <p>Write Command</p> <p>If service type is “TCP”, send data with fixed length</p> <p>AT+CIPSEND=<link_num>,<length></p> <p>Response “>”, type data until the data length is equal to <length></p> | <p>ERROR</p> <p>Other:</p> <p>ERROR</p> <p>Response:</p> <p>If the connection identified by <link_num> has been established successfully, response:</p> <p>></p> <p><input data with specified length></p> <p>OK</p> <p>+CIPSEND: <link_num>,<reqSendLength>, <cnfSendLength></p> <p>If <reqSendLength> is equal <cnfSendLength>, it means that the data has been sent to TCP/IP protocol stack successfully.</p> <p>If the connection has not been established, abnormally closed, or parameter is incorrect, response:</p> <p>+CIPERROR: <err></p> <p>ERROR</p> <p>Other:</p> <p>ERROR</p> |
| <p>Write Command</p> <p>If service type is “UDP”, send data with changeable length</p> <p>AT+CIPSEND=<link_num>,,<serverIP>,<serverPort></p> <p>Response “>”, then type data to send, tap CTRL+Z to send</p> | <p>ERROR</p> <p>Other:</p> <p>ERROR</p> <p>Response:</p> <p>If the connection identified by <link_num> has been established successfully, response:</p> <p>></p> <p><input data></p> <p>CTRL+Z</p> <p>OK</p> <p>+CIPSEND: <link_num>,<reqSendLength>, <cnfSendLength></p> |

| | |
|---|--|
| data, tap ESC to cancel the operation | If the connection has not been established, abnormally closed, or parameter is incorrect, response: +CIPERROR: <err> |
| | ERROR |
| | Other: ERROR |
| Write Command If service type is “UDP”, send data with fixed length | Response: If the connection identified by <link_num> has been established successfully, response: > |
| AT+CIPSEND=<link_num>,<length>,<serverIP>,<serverPort> | <input data with specified length> OK |
| Response “>”, type data until the data length is equal to <length> | +CIPSEND: <link_num>,<reqSendLength>, <cnfSendLength> If the connection has not been established, abnormally closed, or parameter is incorrect, response: +CIPERROR: <err> |
| | ERROR |
| | Other: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | 120000ms |
| Reference | - |

Defined Values

| | |
|-----------------|---|
| <link_num> | Integer type, identifies a connection. Range is 0-9. |
| <length> | Integer type, indicates the length of sending data, range is 1-1500. |
| <serverIP> | String type, which identifies the IP address of server. The IP address format consists of 4 octets, separated by decimal point, like “AAA.BBB.CCC.DDD”. |
| <serverPort> | Integer type, identifies the port of TCP server, range is 0-65535. NOTE: When open port as TCP, the port must be the opened TCP port; When open port as UDP, the port may be any port. But, for Qualcomm, connecting the port 0 is regarded as an invalid operation. |
| <reqSendlength> | Integer type, the length of the data requested to be sent |
| <cnfSendLength> | Integer type, the length of the data confirmed to have been sent. -1 the connection is disconnected. 0 own send buffer or other side’s congestion window are full. |

| | |
|-------|---|
| | Note: If the <cnfSendLength> is not equal to the <reqSendLength>, the socket then cannot be used further. |
| <err> | Integer type, the result of operation.0 is success, other value is failure. |

Example

```

AT+CIPSEND=0,1
>S
OK

+CIPSEND: 0,1,1
AT+CIPSEND=1,1,"116.236.221.75",6775
>S
OK

+CIPSEND: 1,1,1
AT+CIPSEND=2,
>Hello<Ctrl+Z>
OK

+CIPSEND: 2,5,5
AT+CIPSEND=3,,,"116.236.221.75",6775
>Hello World<Ctrl+Z>
OK

+CIPSEND: 3,11,11
AT+CIPSEND=2,
>Hello<ESC>
ERROR
AT+CIPSEND?
+CIPSEND: (0-9),(1-1500)

OK

```

NOTE

- Each <Ctrl+Z> character present in the data should be coded as <ETX><Ctrl+Z>. Each <ESC> character present in the data should be coded as <ETX><ESC>. Each <ETX> character will be coded as <ETX><ETX>. Single <Ctrl+Z> means end of the input data. Single <ESC> is used to cancel the sending.
- <ETX> is 0x03, and <Ctrl+Z> is 0x1A and <ESC> is 0x1B.

11.2.6 AT+CIPRXGET Retrieve TCP/UDP buffered data

| AT+CIPRXGET Retrieve TCP/UDP buffered data | |
|---|---|
| Test Command AT+CIPRXGET=? | Response +CIPRXGET: (0-4),(0-9),(1-1500) OK |
| Read Command AT+CIPRXGET? | Response +CIPRXGET: <mode> OK |
| Write Command AT+CIPRXGET=<mode> In this case, <mode> can only be 0 or 1 | Response If the parameter is correct, response: OK Else, response: ERROR |
| Write Command AT+CIPRXGET=2,<link_num>[,<len>] Retrieve data in ACSII form | Response: If <length> field is empty, the default value to read is 1500. If the buffer is not empty, response: +CIPRXGET: <mode>,<link_num>,<read_len>,<rest_len><data>ACSII form OK If the buffer is empty, response: +IP ERROR: No data ERROR If the parameter is incorrect or other error, response: +IP ERROR: <err_info> ERROR Other: ERROR |
| Write Command AT+CIPRXGET=3,<link_num>[,<len>] Retrieve data in hex form | Response: If <length> field is empty, the default value to read is 750. If the buffer is not empty, response: +CIPRXGET: <mode>,<link_num>,<read_len>,<rest_len><data>hex form OK If the buffer is empty, response: +IP ERROR: No data ERROR |

| | |
|--|---|
| | <p>If the parameter is incorrect or other error, response: +IP ERROR: <err_info></p> <p>ERROR Other: ERROR</p> |
| <p>Write Command AT+CIPRXGET=4,<link_num></p> | <p>Response: If the parameter is correct, response: +CIPRXGET: 4,<link_num>,<rest_len></p> <p>OK If the parameter is incorrect or other error, response: +IP ERROR: <err_info></p> <p>ERROR Other: ERROR</p> |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|-------------------------|---|
| <mode> | <p>Integer type, sets the mode to retrieve data. Default value is 0.</p> <ul style="list-style-type: none"> 0 – set the way to get the network data automatically 1 – set the way to get the network data manually 2 – read data, the max read length is 1500 3 – read data in HEX form, the max read length is 750 4 – get the rest data length |
| <link_num> | Integer type, identifies a connection. Range is 0-9. |
| <len> | <p>Integer type, the data length to be read.</p> <p>Not required, the default value is 1500 when <mode>=2, and 750 when <mode>=3.</p> |
| <read_len> | Integer type, the length of data that has been read. |
| <rest_len> | Integer type, the length of data which has not been read in the buffer. |
| <err_info> | String type, displays the cause of occurring error, please refer to Chapter 3 for details. |

Example

```

AT+CIPRXGET=?
+CIPRXGET: (0-4),(1-1500)

OK

```

AT+CIPRXGET?

+CIPRXGET: 1

OK

AT+CIPRXGET=1

OK

AT+CIPRXGET=2,0,100

+CIPRXGET: 2,0,100,1300

01234567890123456789012345678901234567
89012345678901234567890123456789012345
678901234567890123456789

OK

AT+CIPRXGET=3,0,100

+CIPRXGET: 3,0,100,1200

30313233343536373839303132333435363738
39303132333435363738393031323334353637
38393031323334353637383930313233343536
37383930313233343536373839303132333435
36373839303132333435363738393031323334
3536373839

OK

AT+CIPRXGET=4,0

+CIPRXGET: 4,0,1200

OK

NOTE

- If set <mode> to 1, after receiving data, the module will buffer it and report a URC as "+CIPRXGET: 1,<link_num>" to notify the host. Then host can retrieve data by AT+CIPRXGET.
- If set <mode> to 0, the received data will be outputted to COM port directly by URC as "RECV FROM:<IP ADDRESS>:<PORT><CR><LF>+IPD(data length)<CR><LF><data>".
- If the buffer is not empty, and the module receives data again, then it will not report a new URC until all the received data has been retrieved by AT+CIPRXGET from buffer.
- The default value of <mode> is 0. When <mode> is set to 1 and the 2-4 mode will take effect.
- If initially set <mode> to 1, after doing some data transmitting, set <mode> to 0, then the buffered data of the previously established connection will be output to the serial port directly, and the maximum length of output data at a time is 1500.

11.2.7 AT+IPADDR Get IP address of PDP context

AT+IPADDR Get IP address of PDP context

| | |
|---------------------------------------|---|
| Execution Command AT+IPADDR | Response: If PDP context has been activated successfully, response +IPADDR: <ip_address> OK Else, response: +IP ERROR: Network not opened |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|---------------------------|--|
| <ip_address> | String type, identifies the IP address of current active socket PDP. |
|---------------------------|--|

Example

```
AT+IPADDR
+IPADDR: 10.71.155.118

OK
```

11.2.8 AT+CIPHEAD Add an IP header when receiving data

AT+CIPHEAD Add an IP header when receiving data

| | |
|---|---|
| Test Command AT+CIPHEAD=? | Response +CIPHEAD: (0-1) OK |
| Read Command AT+CIPHEAD? | Response +CIPHEAD: <mode> OK |
| Write Command AT+CIPHEAD=<mode> | Response If the parameter is correct, response: OK |

| | |
|--|--|
| | Else, response: ERROR |
| Execution Command AT+CIPHEAD | Response: Set default value:(<mode>=1) OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|--------|--|
| <mode> | Integer type, indicates whether adding an IP header or not when receiving data. Default value is 1. 0 – not add IP header 1 – add IP header, the format is “+IPD(data length)” |
|--------|--|

Example

```
AT+CIPHEAD=?
+CIPHEAD: (0-1)

OK
AT+CIPHEAD=0
OK
```

11.2.9 AT+CIPSRIP Show remote IP address and port

| AT+CIPSRIP Show remote IP address and port | |
|---|--|
| Test Command AT+CIPSRIP=? | Response +CIPSRIP: (0-1) OK |
| Read Command AT+CIPSRIP? | Response +CIPSRIP: <mode> OK |
| Write Command AT+CIPSRIP=<mode> | Response If the parameter is correct, response: OK Else, response: ERROR |

| | |
|--|--|
| Execution Command AT+CIPSRIP | Response: Set default value:(<mode>=1) OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|--------|---|
| <mode> | Integer type, indicates whether to show IP address and port of server or not when receiving data. Default value is 1. 0 – not show 1 – show, the format is as follows: “RECV FROM:<IP ADDRESS>:<PORT>” |
|--------|---|

Example

```
AT+CIPSRIP=?
+CIPSRIP: (0-1)

OK
AT+CIPSRIP=1
OK
```

11.2.10 AT+CIPMODE Select TCP/IP application mode

| AT+CIPMODE Select TCP/IP application mode | |
|---|--|
| Test Command AT+CIPMODE=? | Response +CIPMODE: (0-1) OK |
| Read Command AT+CIPMODE? | Response +CIPMODE: <mode> OK |
| Write Command AT+CIPMODE=<mode> | Response If the parameter is correct, response: OK Else, response: ERROR |
| Execution Command AT+CIPMODE | Response: Set default value:(<mode>=0) |

| | |
|-----------------------|-----------|
| | OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|---------------------|---|
| <mode> | Integer type, sets TCP/IP application mode. Default value is 0. 0 – Non transparent mode 1 – Transparent mode |
|---------------------|---|

Example

```

AT+CIPMODE=?
+CIPMODE: (0-1)

OK
AT+CIPMODE=1
OK

```

11.2.11 AT+CIPSENDMODE Set sending mode

| AT+CIPSENDMODE Set sending mode | |
|---|--|
| Test Command AT+CIPSENDMODE=? | Response +CIPSENDMODE: (0-1) OK |
| Read Command AT+CIPSENDMODE? | Response +CIPSENDMODE: <mode> OK |
| Write Command AT+CIPSENDMODE=<mode> | Response If the parameter is correct, response: OK Else, response: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|---------------------|---|
| <mode> | Integer type, sets sending mode. Default value is 0. 0 – Sending without waiting peer TCP ACK mode 1 – Sending wait peer TCP ACK mode |
|---------------------|---|

Example

```

AT+CIPSENDMODE=?
+CIPSENDMODE: (0-1)

OK
AT+CIPSENDMODE=1
OK

```

11.2.12 AT+CIPTIMEOUT Set TCP/IP timeout value

| AT+CIPTIMEOUT Set TCP/IP timeout value | |
|--|--|
| Read Command AT+CIPTIMEOUT? | Response +CIPTIMEOUT: <netopen_timeout>,<cipopen_timeout>,<cipsend_timeout> OK |
| Write Command AT+CIPTIMEOUT=[<netopen_timeout>],[<cipopen_timeout>],[<cipsend_timeout>]] | Response If the parameter is correct, response: OK Else, response: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|--------------------------------|--|
| <netopen_timeout> | Integer type, timeout value for AT+NETOPEN. default is120000ms. Range is 3000ms-120000ms. |
| <cipopen_timeout> | Integer type, timeout value for AT+CIPOPEN. default is120000ms. Range is 3000ms-120000ms. |
| <cipsend_timeout> | Integer type, timeout value for AT+CIPSEND. default is120000ms. Range is 3000ms-120000ms. |

Example

AT+CIPTIMEOUT?

+CIPTIMEOUT: 30000,20000,40000

OK

AT+CIPTIMEOUT=30000,20000,40000

OK

11.2.13 AT+CIPCCFG Configure parameters of socket

| AT+CIPCCFG Configure parameters of socket | |
|--|---|
| Test Command AT+CIPCCFG=? | Response +CIPCCFG: (0-10),(0-1000),(0),(0-1),(0-1),(0-1),(500-120000) OK |
| Read Command AT+CIPCCFG? | Response +CIPCCFG: <NmRetry>,<DelayTm>,<Ack>,<errMode>,<HeaderType>,<Asyn cMode>,<TimeoutVal> OK |
| Write Command AT+CIPCCFG=[<NmRetry>][, [<DelayTm>][, [<Ack>][, [<errM ode>][, [<HeaderType>][, [[<As yncMode>][, [<TimeoutVal>]]]]]]]] | Response If the parameter is correct, response: OK Else, response: ERROR |
| Execution Command AT+CIPCCFG | Response Set default value: OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|------------------------|---|
| <NmRetry> | Integer type, number of retransmission to be made for an IP packet. Range is 0-10. The default value is 10. |
| <DelayTm> | Integer type, number of milliseconds to delay to output data of Receiving. Range is 0-1000. The default value is 0. |
| <Ack> | Integer type, it can only be set to 0. It's used to be compatible with old TCP/IP command set. |

| | |
|---------------------------|--|
| <errMode> | Integer type, sets mode of reporting <err_info>, default value is 1. 0 error result code with numeric values 1 error result code with string values |
| <HeaderType> | Integer type, select which data header is used when receiving data, it only takes effect in multi-client mode. Default value is 0. 0 add data header, the format is "+IPD<data length>" 1 add data header, the format is "+RECEIVE,<link num>,<data length>" |
| <AsyncMode> | Integer type, range is 0-1. Default value is 0. It's used to be compatible with old TCP/IP command set. |
| <TimeoutVal> | Integer type, set the minimum retransmission timeout value for TCP connection. Range is 500ms-120000ms. Default is 500ms. |

Example

```

AT+CIPCCFG=?
+CIPCCFG:
(0-10),(0-1000),(0),(0-1),(0-1),(0),(500-120000)

OK
AT+CIPCCFG=3,500,0,1,1,1,500
OK

```

11.2.14 AT+SERVERSTART Startup TCP server

| AT+SERVERSTART Startup TCP server | |
|--|---|
| Test Command AT+SERVERSTART=? | Response +SERVERSTART: (0-65535),(0-3) OK |
| Read Command AT+SERVERSTART? | Response If the PDP context has not been activated successfully, response: +CIPERROR: <err> ERROR If there exists opened server, response: [+SERVERSTART: <server_index>,< port> ...] OK Other: |

| | |
|--|--|
| Write Command AT+SERVERSTART=<port>,<server_index>[,<backlog>] | <p>ERROR</p> <p>Response</p> <p>If there is no error, response:</p> <p>OK</p> <p>If the PDP context has not been activated, or the server identified by <server_index> has been opened, or the parameter is not correct, or other errors, response:</p> <p>+CIPERROR: <err></p> <p>ERROR</p> <p>Other:</p> <p>ERROR</p> |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|----------------|---|
| <port> | Integer type, identifies the listening port of module when used as a TCP server. Range is 0-65535. |
| <server_index> | Integer type, the TCP server index, range is 0-3. |
| <Ack> | Integer type, it can only be set to 0. It's used to be compatible with old TCP/IP command set. |
| <backlog> | Integer type, the maximum connections can be queued in listening queue. Range is 1-3. Default is 3. |

Example

```
AT+SERVERSTART=?
+SERVERSTART: 0,1000
```

```
OK
AT+SERVERSTART=8080,1
OK
```

NOTE

- After the "AT+SERVERSTART" executes successfully, an unsolicited result code is returned when a client tries to connect with module and module accepts request. The unsolicited result code is +CLIENT: <link_num>,<server_index>,<client_IP>:<port>.

11.2.15 AT+SERVERSTOP Stop TCP server

| AT+SERVERSTOP Stop TCP server | |
|--|---|
| Write Command AT+SERVERSTOP=<server_index> | Response If there exists open connection with the server identified by <server_index>, or the server identified by <server_index> has not been opened, or the parameter is incorrect, response: +SERVERSTOP: <server_index>,<err> ERROR If the server socket is closed immediately, response: +SERVERSTOP: <server_index>,0 OK (In general, the result is shown as below.) If the server socket starts to close, response: OK +SERVERSTOP: <server_index>,<err> Other: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|----------------|---|
| <server_index> | Integer type, the TCP server index, range is 0-3. |
| <err> | Integer type, the result of operation.0 is success, other value is failure. |

Example

```
AT+SERVERSTOP=0
+SERVERSTOP: 0,0
```

OK

NOTE

- Before stopping a TCP server, all sockets <server_index> of which equals to the closing TCP server index must be closed first.

11.2.16 AT+CIPACK Query TCP connection data transmitting status

| AT+CIPACK Query TCP connection data transmitting status | |
|---|--|
| Test Command AT+CIPACK=? | Response +CIPACK: (0-9) OK |
| Write Command AT+CIPACK=<link_num> | Response If the PDP context has not been activated, or the connection identified by <link_num> has not been established, abnormally closed, or the parameter is incorrect, or other errors, response: +IP ERROR: <err_info> ERROR If the connection has been established, and the service type is "TCP", response: +CIPACK: <sent_data_size>,<ack_data_size>,<recv_data_size> OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|------------------|--|
| <link_num> | Integer type, identifies a connection. Range is 0-9. |
| <sent_data_size> | Integer type, the total length of sent data |
| <ack_data_size> | Integer type, the total length of acknowledged data. |
| <recv_data_size> | Integer type, the total length of received data |
| <err> | Integer type, the result of operation. 0 is success, other value is failure. |
| <err_info> | String type, displays the cause of occurring error, please refer to Chapter 3 for details. |

Example

```

AT+CIPACK=?
+CIPACK: (0-9)

OK
AT+CIPACK=0
+CIPACK: 16,16,5

OK

```

11.3 DNS&PING

11.3.1 AT+CDNSGIP Query the IP address of given domain name

| AT+CDNSGIP Query the IP address of given domain name | |
|--|---|
| Test Command AT+CDNSGIP=? | Response OK |
| Write Command AT+CDNSGIP=<domain name> | Response If the given domain name has related IP, response: +CDNSGIP: 1,<domain name>,<IP address> OK If the given name has no related IP, response: +CDNSGIP: 0,<dns error code> ERROR Other: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|-------------------------------|--|
| <domain name> | String type (string should be included in quotation marks), indicates the domain name. The maximum length of domain name is 254. Valid characters allowed in the domain name area-z, A-Z, 0-9, “-“(hyphen) and “.”. A domain name is made up of one label name or more label names separated by “.” (e.g. AT+CDNSGIP=”aa.bb.cc”). For label names separated by “.”, length of each label must be no more than 63 characters. The beginning character of the domain name and of labels should be an alphanumeric character. |
| <IP address> | String type, indicates the IP address corresponding to the domain name. |
| <dns error code> | Integer type, indicates the error code. 10 DNS GENERAL ERROR |

Example

```
AT+CDNSGIP="www.baidu.com"
+CDNSGIP:
1,"www.baidu.com","61.135.169.21"

OK
```

11.3.2 AT+CDNSGHNAME Query the domain name of given IP address

| AT+CDNSGHNAME Query the domain name of given IP address | |
|--|--|
| Test Command AT+CDNSGHNAME=? | Response OK |
| Write Command AT+CDNSGHNAME=<IP address> | Response If the given IP address has related domain name, response: +CDNSGHNAME: <index>,<domain name>,<IP address> OK If the given IP address has no related domain name, response: +CDNSGHNAME: 0,<dns error code> ERROR Other: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|-------------------------------|--|
| <domain name> | String type (string should be included in quotation marks), indicates the domain name. The maximum length of domain name is 254. Valid characters allowed in the domain name area-z, A-Z, 0-9, “-”(hyphen) and “.”. A domain name is made up of one label name or more label names separated by “.” (e.g. AT+CDNSGIP="aa.bb.cc"). For label names separated by “.”, length of each label must be no more than 63 characters. The beginning character of the domain name and of labels should be an alphanumeric character. |
| <IP address> | String type (string should be included in quotation marks), indicates the IP address corresponding to the domain name. |
| <dns error code> | Integer type, which indicates the error code. 10 DNS GENERAL ERROR |
| <index> | Integer type, which indicates DNS result index. This value is always 1 if performing successfully. Currently only the |

first record returned from the DNS server will be reported.

Example

```
AT+CDNSGNAME="58.32.231.148"
+CDNSGNAME: 1,"mail.sim.com","58.32.231.148"

OK
```

11.3.3 AT+CIPDNSSET Set DNS query parameters

AT+CIPDNSSET Set DNS query parameters

| | |
|--|--|
| Read Command AT+CIPDNSSET? | Response +CIPDNSSET: 3,30000,7 OK |
| Write Command AT+CIPCCFG=[<max_net_retries>][,<net_timeout>][,<max_query_retries>]]] | Response If the parameter is correct, response: OK Else, response: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|----------------------------------|--|
| <max_net_retries> | Integer type, maximum retry times for opening PS network to perform DNS query. Range is 0-3. Default is 3. |
| <netopen_timeout> | Integer type, timeout value for each opening PS network operation when performing DNS query. Range is 3000ms-120000ms. Default value is 30000ms. |
| <max_query_retries> | Integer type, maximum retry times for performing DNS query using UDP packet. Range is 0-7. Default value is 7. |

Example

```
AT+CIPDNSSET?
+CIPDNSSET: 1,30000,3

OK
```

```
AT+CIPDNSSET=1,30000,1
OK
```

11.3.4 AT+CPING Ping destination address

| AT+CPING Ping destination address | |
|--|--|
| Test Command AT+CPING=? | Response +CPING: IP address, (list of supported <dest_addr_type>s),(1-100),(4-188),(1000-10000),(10000-100000), (16-255) OK |
| Write Command AT+CPING=<dest_addr>,<dest_addr_type>[,<num_pings>[,<data_packet_size>[,<interval_time>[,<wait_time>[,<TTL>]]]]] | Response OK If ping's result_type = 1 +CPING: <result_type>,<resolved_ip_addr>,<data_packet_size>,<rtt>,<TTL> If ping's result_type = 2 +CPING: <result_type> If ping's result_type = 3 +CPING: <result_type>,<num_pkts_sent>,<num_pkts_rcvd>,<num_pkts_lost>,<min_rtt>,<max_rtt>,<avg_rtt> |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined values

| | |
|---------------------------------|---|
| <dest_addr> | The destination is to be pinged; it can be an IP address or a domain name. |
| <dest_addr_type> | Integer type. Address family type of the destination address 1 – IPv4. 2 – IPv6(reserved) |
| <num_pings> | Integer type. The num_pings specifies the number of times the ping request (1-100) is to be sent. The default value is 4. |
| <data_packet_size> | Integer type. Data byte size of the ping packet (4-188). The default value is 64 bytes. |

| | |
|--------------------|---|
| <interval_time> | Integer type. Interval between each ping. Value is specified in milliseconds (1000ms-10000ms). The default value is 2000ms. |
| <wait_time> | Integer type. Wait time for ping response. An ping response received after the timeout shall not be processed. Value specified in milliseconds (10000ms-100000ms). The default value is 10000ms |
| <TTL> | Integer type. TTL(Time-To-Live) value for the IP packet over which the ping(ICMP ECHO Request message) is sent (16-255), the default value is 255. |
| <result_type> | 1 – Ping success 2 – Ping time out 3 – Ping result |
| <num_pkts_sent> | Indicates the number of ping requests that were sent out. |
| <num_pkts_recvd> | Indicates the number of ping responses that were received. |
| <num_pkts_lost> | Indicates the number of ping requests for which no response was received |
| <min_rtt> | Indicates the minimum Round Trip Time(RTT). |
| <max_rtt> | Indicates the maximum RTT. |
| <avg_rtt> | Indicates the average RTT. |
| <resolved_ip_addr> | Indicates the resolved ip address. |
| < rtt> | Round Trip Time. |

Examples

```

AT+CPING="www.baidu.com",1,4,64,1000,10
000,255
OK

+CPING: 1,119.75.217.56,64,410,255

+CPING: 1,119.75.217.56,64,347,255

+CPING: 1,119.75.217.56,64,346,255

+CPING: 1,119.75.217.56,64,444,255

+CPING: 3,4,4,0,346,444,386

```

11.3.5 AT+CPINGSTOP Stop an ongoing ping session

AT+CPINGSTOP Stop an ongoing ping session

| | |
|---------------------------------------|---|
| Test Command AT+CPINGSTOP=? | Response OK |
| Write Command AT+CPINGSTOP | +CPING: <result_type>,<num_pkts_sent>,<num_pkts_recvd>,<num_pkts_lost>,<min_rtt>,<max_rtt>,<avg_rtt> OK ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined values

| | |
|--------------------|---|
| <result_type> | 1 – Ping success 2 – Ping time out 3 – Ping result |
| <num_pkts_sent> | Indicates the number of ping requests that were sent out. |
| <num_pkts_recvd> | Indicates the number of ping responses that were received. |
| <num_pkts_lost> | Indicates the number of ping requests for which no response was received. |
| <resolved_ip_addr> | Indicates the resolved ip address. |
| <min_rtt> | Indicates the minimum Round Trip Time (RTT). |
| <max_rtt> | Indicates the maximum RTT. |
| <avg_rtt> | Indicates the average RTT. |

Examples

```
AT+CPINGSTOP
OK
```

11.4 Information Elements related to TCP/IP

| Information | Description |
|---|---|
| +CIPEVENT: NETWORK CLOSED UNEXPECTEDLY | Network is closed for network error (Out of service, etc). When this event happens, user's application needs to check and close all opened sockets, and then uses AT+NETCLOSE to release the network library if "AT+NETOPEN?" shows the network |

| | |
|---|---|
| +IPCLOSE: <client_index>, <close_reason> | <p>library is still opened.</p> <p>Socket is closed passively.</p> <p><client_index> is the link number.</p> <p><close_reason>:</p> <p>0 - Closed by local, active</p> <p>1 - Closed by remote, passive</p> <p>2 - Closed for sending timeout</p> |
| +CLIENT: < link_num>,<server_index>,<client_IP>:<port> | <p>While TCP server accepted a new socket client, the index is <link_num>. The TCP server index is <server_index>. The peer IP address is <client_IP>. The peer port is <port>.</p> |

11.5 Description of <err_info>

The fourth parameter <errMode> of AT+CIPCCFG is used to determine how <err_info> is displayed. If <errMode> is set to 0, the <err_info> is displayed with numeric value. If <errMode> is set to 1, the <err_info> is displayed with string value. The default is displayed with string value.

| Numeric Value | String Value |
|---------------|-----------------------------------|
| 21 | Operation failed |
| 0 | Connection time out |
| 1 | Bind port failed |
| 2 | Port overflow |
| 3 | Create socket failed |
| 4 | Network is already opened |
| 5 | Network is already closed |
| 6 | No clients connected |
| 7 | No active client |
| 8 | Network not opened |
| 9 | Client index overflow |
| 10 | Connection is already created |
| 11 | Connection is not created |
| 12 | Invalid parameter |
| 13 | Operation not supported |
| 14 | DNS query failed |
| 15 | TCP busy |
| 16 | Netclose failed for socket opened |

| | |
|----|-----------------------------------|
| 17 | Sending time out |
| 18 | Sending failure for network error |
| 19 | Open failure for network error |
| 20 | Server is already listening |
| 21 | No data |
| 22 | Port overflow |

11.6 Description of <err>

| <err> | Description of <err> |
|-------|---------------------------------|
| 0 | Operation succeeded |
| 1 | Network failure |
| 2 | Network not opened |
| 3 | Wrong parameter |
| 4 | Operation not supported |
| 5 | Failed to create socket |
| 6 | Failed to bind socket |
| 7 | TCP server is already listening |
| 8 | Busy |
| 9 | Sockets opened |
| 10 | Timeout |
| 11 | DNS parse failed for AT+CIOPEN |
| 12 | Unknown error |

12. AT Commands for FTPS

12.1 Overview of AT Commands for FTPS

| Command | Description |
|------------------|--|
| AT+CFTPSSTART | Start FTP(S) service |
| AT+CFTPSSTOP | Stop FTP(S) Service |
| AT+CFTPSLOGIN | Login to a FTP(S)server |
| AT+CFTPSLOGOUT | Logout FTP(S) server |
| AT+CFTPSMKD | Create a new directory on FTP(S) server |
| AT+CFTPSRMD | Delete a directory on FTP(S) server |
| AT+CFTPSDELE | Delete a file on FTP(S) server |
| AT+CFTPSCWD | Delete a file on FTP(S) server |
| AT+CFTPSPWD | Get the current directory on FTP(S) server |
| AT+CFTPSTYPE | set the transfer type on FTP(S) serve |
| AT+CFTPSLIST | List the items in the directory on FTP(S) server |
| AT+CFTPSGETFILE | Get a file from FTP(S) server to module |
| AT+CFTPSPUTFILE | Put a file from module to FTP(S) server |
| AT+CFTPSGET | Get a file from FTP(S) server to serial port |
| AT+CFTPSPUT | Put a file to FTP(S) server through serial port |
| AT+CFTPSSINGLEIP | Set FTP(S) data socket address type |
| AT+CFTPSCACHERD | Set FTP(S) data socket address type |
| AT+CFTPSABORT | Abort FTP(S) operations |
| AT+CFTPSSIZE | Get the File Size on FTP(S) server |

12.2 Detailed Description of AT Commands for FTPS

12.2.1 AT+CFTPSSTART Start FTP(S) service

| AT+CFTPSSTART Start FTP(S) service | |
|------------------------------------|-----------|
| Execution Command | Response |
| AT+CFTPSSTART | OK |

| | |
|-----------------------|--|
| | <p>+CFTPSSTART: <errcode> or +CFTPSSTART: <errcode></p> <p>OK or ERROR</p> |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|------------------------|--|
| <errcode> | The result of start FTP(S) service,0 is success, others are failure. Please refer to chapter 12.3.1. |
|------------------------|--|

Example

```
AT+CFTPSSTART
OK
+CFTPSSTART: 0
```

12.2.2 AT+CFTPSSTOP Stop FTP(S) Service

AT+CFTPSSTOP Stop FTP(S) Service

| | |
|-----------------------|--|
| Execution Command | Response |
| AT+CFTPSSTOP | OK |
| | <p>+CFTPSSTOP: <errcode> or +CFTPSSTOP: <errcode></p> <p>OK or ERROR</p> |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|------------------------|---|
| <errcode> | The result of stop FTP(S) service,0 is success, others are failure. Please refer to chapter 12.3.1. |
|------------------------|---|

Example

```
AT+CFTPSSTOP
OK

+CFTPSSTOP: 0
```

12.2.3 AT+CFTPSLOGIN Login to a FTP(S) server

| AT+CFTPSLOGIN Login to a FTP(S) server | |
|---|---|
| Test Command AT+CFTPSLOGIN=? | Response +CFTPSLOGIN: "ADDRESS",(1-65535)[,"USERNAME","PASSWORD"[(0-3)]] |
| | OK |
| Write Command AT+CFTPSLOGIN="<host>" ,<port>,"<username>","<password>"[<server_type>] | Response OK +CFTPSLOGIN: <errcode> or +CFTPSLOGIN: <errcode> |
| | OK or +CFTPSLOGIN: <errcode> |
| | ERROR or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-------------------------|--|
| <host> | Host address, string type, maximum length is 256 |
| <port> | The host listening port for FTP(S), the range is from 1 to 65535 |
| <username> | FTP(S) user name, string type, maximum length is 256 |

| | |
|----------------------------|--|
| <password> | The user password, string type, maximum length is 256 |
| <server_type> | FTP(S)server type,numeric,from0-3,default is 3 0 – FTP server. 1 – Explicit FTPS server with AUTH SSL. 2 – Explicit FTPS server with AUTH TLS. 3 – Implicit FTPS server. |
| <errcode> | The result code of the FTP/FTPS login. 0 is success. Others are failure, please refer to chapter 12.3.1. |

Example

```
AT+CFTPSLOGIN="112.74.93.163",21,"tmf","tmf123",0
OK
+CFTPSLOGIN: 0
```

12.2.4 AT+CFTPSLOGOUT Logout FTP(S) server

| AT+CFTPSLOGOUT Logout FTP(S) server | |
|--|--|
| Test Command AT+CFTPSLOGOUT=? | Response OK |
| Execution Command AT+CFTPSLOGOUT | Response OK +CFTPSLOGOUT: <errcode> or +CFTPSLOGOUT: <errcode> OK or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|------------------------|---|
| <errcode> | The result code of the FTP/FTPS logout. 0 is success. Others are failure, please refer to chapter 12.3.1. |
|------------------------|---|

Example

AT+CFTPSLOGOUT

OK

+CFTPSLOGOUT: 0

12.2.5 AT+CFTPSMKD Create a new directory on FTP(S) server

AT+CFTPSMKD Create a new directory on FTP(S) server

| Test Command | Response |
|---|--|
| AT+CFTPSMKD=? | +CFTPSMKD: "DIR" OK |
| Write Command AT+CFTPSMKD="<dir>" | Response OK +CFTPSMKD: 0 or OK +CFTPSMKD: <errcode> or ERROR or +CFTPSMKD: <errcode> ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-----------|---|
| <dir> | The directory to be created, string type, maximum length is 256. |
| <errcode> | The result of create directory, 0 is success, others are failure, please refer to chapter 12.3.1. |

Example

AT+CFTPSMKD="TEST"

OK

+CFTPSMKD: 0

12.2.6 AT+CFTPSRMD Delete a directory on FTP(S) server

AT+CFTPSRMD Delete a directory on FTP(S) server

| Test Command | Response |
|---|---|
| AT+CFTPSRMD=? | +CFTPSRMD: "DIR" OK |
| Write Command AT+CFTPSRMD="<dir>" | Response 1)if delete the directory successfully: OK +CFTPSRMD: 0 2)if delete the directory failed: OK +CFTPSRMD: <errcode> 3) if parameter format or any errors: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|------------------------|---|
| <dir> | The directory to be removed. If the directory contains non-ASCII characters, the <dir> parameter should contain a prefix of {non-ascii}.String type, maximum length is 256. |
| <errcode> | The result of remove directory, 0 is success, others are failure, please refer to chapter 12.3.1. |

Example

```
AT+CFTPSRMD="test"
OK

+CFTPSRMD: 0
```

12.2.7 AT+CFTPSDELE Delete a file on FTP(S) server

| AT+CFTPSDELE Delete a file on FTP(S)server | |
|---|--|
| Test Command AT+CFTPSDELE=? | Response +CFTPSDELE: "FILENAME" |
| | OK |
| Write Command AT+CFTPSDELE="<filename>" | Response 1)if delete file successfully: OK |
| | +CFTPSDELE: 0 |
| | 2)if failed: OK |
| | +CFTPSDELE: <errcode> |
| | 3)if parameter format or any other errors: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-------------------------|--|
| <filename> | The name of the file to be deleted. If the file name contains non-ASCII characters, the <filename> parameter should contain a prefix of {non-ascii}.String type,the maximum length is 256. |
| <errcode> | The result of delete a file, 0 is success, others are failure,please refer to chapter 12.3.1. |

Example

```
AT+CFTPSDELE="TEST.txt"
OK
+CFTPSDELE: 0
```

12.2.8 AT+CFTPSCWD Change the current directory on FTP(S) server

| AT+CFTPSCWD Change the current directory on FTP(S) sever | |
|--|----------|
| Test Command | Response |

| | |
|---|--|
| AT+CFTPSCWD=? | +CFTPSCWD: "DIR" |
| | OK |
| Write Command AT+CFTPSCWD="<dir>" | Response 1)if delete file successfully: OK |
| | +CFTPSCWD: 0 2)if failed: OK |
| | +CFTPSCWD: <errcode> 2)if failed: +CFTPSCWD: <errcode> |
| | ERROR 3)if parameter format or any other errors: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|------------------------|--|
| <dir> | The directory to be changed. If the directory contains non-ASCII characters, the <dir> parameter should contain a prefix of {non-ascii}.String type,the maximum length is 256. |
| <errcode> | The result of change the current directory, 0 is success, others are failure, please refer to chapter 12.3.1. |

Example

```
AT+CFTPSCWD="/lu.liu/TEST7600"
OK
+CFTPSCWD: 0
```

12.2.9 AT+CFTPSPWD Get the current directory on FTPS server

AT+CFTPSPWD Get the current directory on FTPS server

| | |
|---|-----------------------|
| Execution Command AT+CFTPSPWD | Response OK |
|---|-----------------------|

| | |
|-----------------------|---|
| | <p>+CFTPSPWD: "<dir>" or +CFTPSPWD: "<dir>"</p> <p>OK or +CFTPSPWD: <errcode></p> <p>ERROR or OK</p> <p>+CFTPSPWD: <errcode> or ERROR</p> |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-----------|--|
| <dir> | The name of the file to be deleted. If the file name contains non-ASCII characters, the <filename> parameter should contain a prefix of {non-ascii}.String type,the maximum length is 256. |
| <errcode> | The result of change current directory, 0 is success, others are failure, please refer to chapter 12.3.1. |

Example

```
AT+CFTPSPWD
OK
+CFTPSPWD: "/test12"
```

12.2.10 AT+CFTPSTYPE Set the transfer type on FTP(S) server

AT+CFTPSTYPE Set the transfer type on FTP(S) server

| | |
|-----------------------|-------------------|
| Test Command | Response |
| AT+CFTPSTYPE=? | +CFTPSTYPE: (A,I) |
| | OK |

| | |
|---|--|
| Read Command AT+CFTPSTYPE? | Response +CFTPSTYPE: <type> OK |
| Write Command AT+CFTPSTYPE=<type> | Response a)if set type successfully: OK +CFTPSTYPE: 0 b)if set type failed: OK +CFTPSTYPE: <errcode> |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|------------------------|---|
| <type> | The type of transferring: A – ASCII. I– Binary |
| <errcode> | The result of set type, 0 is success, others are failure, please refer to chapter 12.3.1. |

Example

```
AT+CFTPSTYPE=A
OK
+CFTPSTYPE: 0
```

12.2.11 AT+CFTPSSLIST List the items in the directory on FTP(S) server

AT+CFTPSSLIST List the items in the directory on FTP(S) server

| | |
|---|--|
| Write Command AT+CFTPSSLIST[="<dir>"] | Response a)if set type successfully: OK +CFTPSSLIST: DATA,<len> ... +CFTPSSLIST: 0 |
|---|--|

| | |
|-----------------------|--|
| | b)if set type failed: OK |
| | +CFTPSLIST: <errcode> |
| | c)if parameter format or any other errors: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|------------------------|---|
| <dir> | The directory to be listed. If the directory contains non-ASCII characters, the <dir> parameter should contain a prefix of {non-ascii}.String type, the maximum length is 256 |
| <errcode> | The result code of the listing.0 is success, others are failure,please refer to chapter12.3.1. |

Example

```
AT+CFTPSLIST="/"
```

```
OK
```

```
+CFTPSLIST: DATA,1480
```

```
-rw-r--r-- 1 ftp ftp          10 Mar 19
```

```
13:51 111.TXT
```

```
-rw-r--r-- 1 ftp ftp           7 Mar 18
```

```
10:39 1111.txt
```

```
-rw-r--r-- 1 ftp ftp       10240 Mar 23
```

```
10:20 112.txt
```

```
-rw-r--r-- 1 ftp ftp          10 Mar 16
```

```
15:26 11K4.txt
```

```
-rw-r--r-- 1 ftp ftp        1434 Mar 18
```

```
10:47 1434B.txt
```

```
-rw-r--r-- 1 ftp ftp     307200 Mar 18
```

```
10:40 300K.txt
```

```
-rw-r--r-- 1 ftp ftp           9 Mar 18
```

```
10:53 333.txt
```

```
-rw-r--r-- 1 ftp ftp          16 Mar 17
```

```
14:11 36.txt
```

```
+CFTPSLIST: 0
```

12.2.12 AT+CFTPSGETFILE Get a file from FTP(S) server to module

| AT+CFTPSGETFILE Get a file from FTP(S) server to module | |
|---|--|
| Test Command AT+CFTPSGETFILE=? | Response +CFTPSGETFILE: [{non-ascii}]"FILEPATH"[,(1-4)] OK |
| Write Command AT+CFTPSGETFILE="<filepath h>"[,<dir>[,<offset>]] | Response a) if download file successfully : OK +CFTPSGETFILE: 0 b) if failed: OK +CFTPSGETFILE: <errcode> c) if parameter format or any other errors: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-------------------------|--|
| <filepath> | The remote file path. When the file path doesn't contain "/", this command transfers file from the current remote FTPS directory. If the file path contains non-ASCII characters, the file path parameter should contain a prefix of {non-ascii}.String type, maximum length is 256. |
| <dir> | The directory to save the downloaded file.Numeric type, range is 1-4, default is 1(/cache) 1 – F:/ (/cache) 2 – D:/(sd card) 3 – E:/ (/data/media/) 4 – /mssl_cert/(this is for CA file downloading) |
| <offset> | Integer type, the download start position used for resume-from-break-point. |
| <errcode> | The result code of download file from FTP(s) server.0 is success, others are failure,please refer to chapter 12.3.1. |

Example

```
AT+CFTPSGETFILE="settings.dat",3
OK
```

+CFTPSGETFILE: 0

12.2.13 AT+CFTPSPUTFILE Put a file from module to FTP(S) server

AT+CFTPSPUTFILE Put a file from module to FTP(S) server

| | |
|--|---|
| Test Command AT+CFTPSPUTFILE=? | Response +CFTPSPUTFILE: [{non-ascii}]"FILEPATH"[,(1-3),(0-2147483647)] OK |
| Write Command AT+CFTPSPUTFILE="<filepath>",<dir>[,<rest_size>] | Response a)if upload file successfully : OK +CFTPSPUTFILE: 0 b)if failed: OK +CFTPSPUTFILE: <errcode> |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|--------------------------|--|
| <filepath> | The remote file path. When the file path doesn't contain "/", this command transfers file to the current remote FTPS directory. If the file path contains non-ASCII characters, the file path parameter should contain a prefix of {non-ascii}.String type, maximum length is 256. |
| <dir> | The directory that contains the uploaded file. Numeric type, range is 1-3, default is 1(/cache) 1 – F:/ (/cache) 2 – D:/ (sd card) 3 – E:/ (/data/media/) |
| <rest_size> | The value for FTP "REST" command which is used for broken transfer when transferring failed last time. Numeric type, the range is from 0 to 2147483647. |
| <errcode> | The result code of upload file to FTP(S)server.0 is success, others are failure,please refer to chapter12.3.1. |

Example

AT+CFTPSPUTFILE="/LK/LM/sim_ZXX.TXT"

OK

+CFTPSPUTFILE: 0

12.2.14 AT+CFTPSET Get a file from FTP(S) server to serial port

AT+CFTPSET Get a file from FTP(S) server to serial port

Test Command

AT+CFTPSET=?

Response

+CFTPSET: [{non-ascii}]"FILEPATH"[,<rest_size>[(0,1)]]

OK

Write Command

AT+CFTPSET="<filepath>**"[
<rest_size>],[**<using_cache>**]
]**

Response

a)if<using_cache> is 0(default),and get file successfully :

OK

+CFTPSET: DATA,<len>

...

+CFTPSET: DATA, <len>

...

...

+CFTPSET: 0

b) if <using_cache> is 1 and get file successfully:

OK

+CFTPS: RECV EVENT

AT+CFTPSCACHERD?

//you can use this command to check the size of the received data

+CFTPSCACHERD: 102400

OK

//output cached data now:

AT+CFTPSCACHERD

+CFTPSET: DATA,<len>

.....

OK

.....

+CFTPSET: 0

| | |
|-----------------------|-----------------------------------|
| | c)if failed: OK |
| | +CFTPSGET: <errcode> |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|----------------------------|---|
| <filepath> | The remote file path. When the file path doesn't contain "/", this command transfer file from the current remote FTPS directory. If the file path contains non-ASCII characters, the file path parameter should contain a prefix of {non-ascii}.String type, maximum length is 256. |
| <rest_size> | The value for FTP "REST" command which is used for broken transfer when transferring failed last time. Numeric type, the range is from 0 to 2147483647 |
| <using_cache> | Numeric, rang is 0-1 0—Do not use cache, module will output the items data to serial port when list successfully. 1 – Use cache, module will report "+CFTPS: RECV EVENT" when list successfully (Data will be output using AT+CFTPSCACHERD command) |
| <errcode> | The result code of download file from FTP(s) server.0 is success, others are failure, please refer to chapter 12.3.1. |

Example

```
AT+CFTPSGET="/BBB.TXT"
```

```
OK
```

```
+CFTPSGET: DATA,110
```

```
FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF
```

```
FFFFFFFFFFFFFFFFHHHHHHHHHHHHHHHHHHHH
```

```
HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH
```

```
HHHHHHHHHHHHHHHHHH
```

```
+CFTPSGET: 0
```

12.2.15 AT+CFTPSPUT Put a file to FTP(S) server through serial port

AT+CFTPSPUT Put a file to FTP(S) server through serial port

| | |
|--|--|
| Test Command AT+CFTPSPUT=? | Response +CFTPSPUT: [{non-ascii}]"FILEPATH"[,<data_len>,<rest_size>]] |
| Write Command AT+CFTPSPUT="<filepath>"[,<data_len>,<rest_size>]] | <p>OK</p> <p>Response</p> <p>a)if upload file through serial port successfully: OK</p> <p>+CFTPSPUT: 0</p> <p>b)if failed before input data: +CFTPSPUT: <errcode></p> <p>ERROR</p> <p>c)if failed after input data: OK</p> <p>+CFTPSPUT: <errcode></p> <p>d)if parameter format i or any other errors: ERROR</p> |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|--------------------------|--|
| <filepath> | The remote file path. When the file path doesn't contain "/", this command transfers file to the current remote FTPS directory. If the file path contains non-ASCII characters, the file path parameter should contain a prefix of {non-ascii}.String type, maximum length is 256. |
| <data_len> | Numeric type,The length of the data to send, the maximum length is 2048.if parameter<data_len> is omitted, Each <Ctrl+Z>character present in the data flow of serial port when downloading FTP data will be coded as <ETX><Ctrl+Z>. Each <ETX> character will be coded as <ETX><ETX>. Single <Ctrl+Z> means end of the FTP data.<ETX> is 0x03, and <Ctrl+Z> is 0x1A. |
| <rest_size> | The value for FTP "REST" command which is used for broken transfer when transferring failed last time. Numeric type, the range is from 0 to 2147483647. |
| <errcode> | The result code of upload data to FTP(s) server.0 is success, others are failure, please refer to chapter 12.3.1. |

Example

```
AT+CFTPSPUT="/LK/LM/LO.TXT"
>123457860
OK

+CFTPSPUT: 0
```

12.2.16 AT+CFTPSSINGLEIP Set FTP(S) data socket address type

| AT+CFTPSSINGLEIP Set FTP(S) data socket address type | |
|---|--|
| Test Command AT+CFTPSSINGLEIP=? | Response +CFTPSSINGLEIP: (0,1) OK |
| Read Command AT+CFTPSSINGLEIP? | Response +CFTPSSINGLEIP: <singleip> OK |
| Write Command AT+CFTPSSINGLEIP=<singleip> | Response If parameter format is right and set successfully: OK If parameter format is not right or any other error occurs: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

The FTPS data socket IP address type:

<singleip>

0 – decided by PORT response from FTPS server

1 – the same as the control socket.

Example

```
AT+CFTPSSINGLEIP=1
OK
```

12.2.17 AT+CFTPSCACHERD Output cached data to MCU

| AT+CFTPSCACHERD Output cached data to MCU | |
|---|---|
| Read Command AT+CFTPSCACHERD? | Response +CFTPSCACHERD: <len> OK |
| Execution Command AT+CFTPSCACHERD | Response If cache data is AT+CFTPSET, and everything goes well: +CFTPSET: DATA,<out_len><CR><LF> ... OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-----------|--|
| <len> | Numeric type, The bytes of data cached in FTPS module. |
| <out_len> | The bytes of data to output. The maximum value is 1024 for each AT+CFTPSCACHERD calling. |

Example

| |
|---|
| AT+CFTPSCACHERD? +CFTPSCACHERD: 21078 OK |
|---|

12.2.18 AT+CFTPABORT Abort FTP(S) Operations

| AT+CFTPABORT Abort FTP(S) Operations | |
|--|---|
| Execution Command AT+CFTPABORT | Response if abort FTP(S) operation successfully: OK +CFTPABORT: 0 sometimes abort successfully returns: |

| | |
|-----------------------|---|
| | <p>+CFTPSABORT: 0</p> <p>OK</p> <p>if failed:</p> <p>OK</p> <p>+CFTPSABORT: <errcode></p> <p>if any other error occurs:</p> <p>ERROR</p> |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|------------------------|--|
| <errcode> | The result of abort FTP(S) service,0 is success, others are failure. Please refer to chapter 12.3.1. |
|------------------------|--|

Example

```

AT+CFTPSABORT
OK

+CFTPSABORT: 0
  
```

12.2.19 AT+CFTPSSIZE Get the File Size on FTP(S) server

| AT+CFTPSSIZE Get the File Size on FTP(S) server | |
|---|---|
| Test Command AT+CFTPSSIZE=? | Response +CFTPSSIZE: "<filepath>" |
| | OK |
| Write Command AT+CFTPSSIZE="<filepath>" | Response OK |
| | +CFTPSSIZE: <filesize> |
| | or OK |
| | +CFTPSSIZE: <errcode> |

| | |
|-----------------------|--|
| | or ERROR or +CFTPSSIZE: <errcode> |
| | ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-------------------------|--|
| <filepath> | The remote filepath on FTP(S) server.String type,max length is 256 |
| <filesize> | Numeric type, size of the remote file on FTP(S) server. |
| <errcode> | The result code of get file size. Please refer to chapter 12.3.1. |

Example

```
AT+CFTPSSIZE="TEST.txt"
OK
+CFTPSSIZE: 1024
```

12.3 Summary of result codes for FTPS

12.3.1 Summary of Command result <errcode>

| Code of <errcode> | Meaning |
|-------------------|---|
| 0 | Success |
| 1 | SSL alert |
| 2 | Unknown error |
| 3 | Busy |
| 4 | Connection closed by server |
| 5 | Timeout |
| 6 | Transfer failed |
| 7 | File not exists or any other memory error |
| 8 | Invalid parameter |
| 9 | Operation rejected by server |

| | |
|-----|---|
| 10 | Network error |
| 11 | State error |
| 12 | Failed to parse server name |
| 13 | Create socket error |
| 14 | Connect socket failed |
| 15 | Close socket failed |
| 16 | SSL session closed |
| 17 | File error,file not exist or other error. |
| 421 | Server response connection time out, while received error code 421,you need do AT+CFTPSLOGOUT to logout server then AT+CFTPSLOGIN again for further operations. |

12.3.2 Summary of Unsolicited Result Codes

| Unsolicited codes | Description |
|---------------------------------|---|
| +CFTPSNOTIFY:PEER CLOSED | When client disconnect passively, URC "+CFTPSNOTIFY: PEER CLOSED" will be reported, then user need to execute AT+CFTPSLOGOUT andlog in again. |

13. AT Commands for HTTPS

13.1 Overview of AT Commands for HTTPS

| Command | Description |
|-----------------|--|
| AT+HTTPINIT | Start HTTP(S) service |
| AT+HTTPTERM | Stop HTTP(S) service. |
| AT+HTTPPARA | Set HTTP(S) Parameter |
| AT+HTTPACTION | HTTP(S) Method Action |
| AT+HTTPHEAD | Read the HTTP(S) Header Information of Server Response |
| AT+HTTPREAD | Read the response Information of HTTP(S) Server |
| AT+HTTPDATA | Input HTTP(S) Data |
| AT+HTTPPOSTFILE | Send HTTP(S) Request to HTTP server by File |
| AT+HTTPREADFILE | Receive HTTP(S) Response Content to a file |

13.2 Detailed Description of AT Commands for HTTPS

13.2.1 AT+HTTPINIT Start HTTP(S) service

| AT+HTTPINIT Start HTTP(S) service | |
|---|--|
| Execution Command AT+HTTPINIT | Response a)If start HTTP service successfully: OK b)If failed: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | 120000ms |
| Reference | |

Example

AT+HTTPINIT

OK

13.2.2 AT+HTTPTERM Stop HTTP(S) Service

AT+HTTPTERM Stop HTTP(S) service

| | |
|---|---|
| Execution Command AT+HTTPTERM | Response a)If stop HTTP service successfully: OK b)If failed: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | 120000ms |
| Reference | |

Example

```
AT+HTTPTERM
OK
```

13.2.3 AT+HTTTPARA Set HTTP(S) Parameters value

AT+HTTTPARA Set HTTP(S) Parameters value

| | |
|--|--|
| Write Command AT+HTTTPARA="URL", "<url>" | Response a)If parameter format is right: OK b) If parameter format is not right or other errors occur: ERROR |
| Write Command AT+HTTTPARA="CONNECTT O", <conn_timeout> | Response a)If parameter format is right: OK b) If parameter format is not right or other errors occur: ERROR |
| Write Command AT+HTTTPARA="RCVTO", <rcv_timeout> | Response a)If parameter format is right: OK b) If parameter format is not right or other errors occur: ERROR |
| Write Command AT+HTTTPARA="CONTENT", | Response a)If parameter format is right: |

| | |
|--|--|
| "<content_type>" | <p>OK</p> <p>b) If parameter format is not right or other errors occur:</p> <p>ERROR</p> |
| Write Command AT+HTTTPARA="ACCEPT","<accept-type>" | <p>Response</p> <p>a) If parameter format is right:</p> <p>OK</p> <p>b) If parameter format is not right or other errors occur:</p> <p>ERROR</p> |
| Write Command AT+HTTTPARA="UA","<user_agent>" | <p>Response</p> <p>a) If parameter format is right:</p> <p>OK</p> <p>b) If parameter format is not right or other errors occur:</p> <p>ERROR</p> |
| Write Command AT+HTTTPARA="SSLCFG","<sslcfg_id>" | <p>Response</p> <p>a) If parameter format is right:</p> <p>OK</p> <p>b) If parameter format is not right or other errors occur:</p> <p>ERROR</p> |
| Write Command AT+HTTTPARA="USERDATA","<user_data>" | <p>Response</p> <p>a) If parameter format is right:</p> <p>OK</p> <p>b) If parameter format is not right or other errors occur:</p> <p>ERROR</p> |
| Write Command AT+HTTTPARA="BREAK",<break> | <p>Response</p> <p>a) If parameter format is right:</p> <p>OK</p> <p>b) If parameter format is not right or other errors occur:</p> <p>ERROR</p> |
| Write Command AT+HTTTPARA="BREAKEND",<breakend> | <p>Response</p> <p>a) If parameter format is right:</p> <p>OK</p> <p>b) If parameter format is not right or other errors occur:</p> <p>ERROR</p> |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-------|--|
| <url> | <p>URL of network resource. String, start with "http://" or "https://"</p> <p>a) http://server'/path':tcpPort'</p> <p>b) https://server'/path':tcpPort'</p> <p>"server": DNS domain name or IP address</p> <p>"path": path to a file or directory of a server</p> <p>"tcpPort": http default value is 80, https default value is 443.(can be</p> |
|-------|--|

| | |
|----------------|---|
| | omitted) |
| <conn_timeout> | Timeout for accessing server, Numeric type, range is 20-120s, default is 120s. |
| <recv_timeout> | Timeout for receiving data from server, Numeric type range is 2-120s, default is 10s. |
| <content_type> | This is for HTTP "Content-Type" tag, String type, max length is 256, default is "text/plain". |
| <accept-type> | This is for HTTP "Accept-type" tag, String type, max length is 256, default is "*/*". |
| <user_agent> | Parameter for HTTP header User-Agent information. String type, max length is 256. |
| <sslcfg_id> | This is setting SSL context id, Numeric type, range is 0-9. Default is 0. |
| <user_data> | The customized HTTP header information. String type, max length is 512. |
| <break> | Parameter for HTTP method "GET", used for resuming broken transfer. The start of the broken transfer. Default is 0. |
| <breakend> | Parameter for HTTP method "GET", used for resuming broken transfer. The end of the broken transfer. Default is 0. If both "break" and "breakend" are 0, the resume broken transfer function is disabled. If "breakend" is bigger than "break", the transfer scope is from "break" to "breakend". If "breakend" is smaller than "break", the transfer scope is from "break" to the end of the file. |

Example

```
AT+HTTTPARA="USERDATA", "Authorization: Basic Y2FycGx1c2dvOmNhcnBsdXgz"
OK
```

13.2.4 AT+HTTPACTION HTTP(S) Method Action

| AT+HTTPACTION HTTP(S) Method Action | |
|--|---|
| Test Command AT+HTTPACTION=? | Response +HTTPACTION: (0-3) OK |
| Write Command AT+HTTPACTION=<method> | Response a) If parameter format is right : OK +HTTPACTION: <method>,<statusCode>,<datalen> |

| | |
|-----------------------|---|
| | b)If parameter format is not right or other errors occur: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | 120000ms |
| Reference | |

Defined Values

| | |
|--------------|---|
| <method> | HTTP method specification: 0: GET 1: POST 2: HEAD 3: DELETE |
| <statuscode> | Please refer to chapter 13.3.1 |
| <datalen> | The length of data received |

Example

```
AT+HTTPACTION=1
OK
+HTTPACTION: 1,200,2800
```

13.2.5 AT+HTTPHEAD Read the HTTP(S) Header Information of Server Response

AT+HTTPHEAD Read the HTTP(S) Header Information of Server Response

| | |
|---|---|
| Execution Command AT+HTTPHEAD | Response a)If read the header information successfully: +HTTPHEAD: DATA,<data_len> <data> OK b)If read failed: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|------------|---|
| <data_len> | The length of HTTP header |
| <data> | The header information of HTTP response |

Example

```

AT+CHTTPHEAD
+HTTPHEAD: 750
HTTP/1.1 200 OK
Date: Thu, 29 Mar 2018 09:21:12 GMT
Content-Type: text/html
Content-Length: 14615
Last-Modified: Thu, 15 Mar 2018 08:23:00 GMT
Connection: Keep-Alive
Vary: Accept-Encoding
Set-Cookie: BAIDUID=EF38663A5539EBEAE702321037D5491B:FG=1; expires=Thu, 31-Dec-37
23:55:55 GMT; max-age=2147483647; path=/; domain=.baidu.com
Set-Cookie: BIDUPSID=EF38663A5539EBEAE702321037D5491B; expires=Thu, 31-Dec-37
23:55:55 GMT; max-age=2147483647; path=/; domain=.baidu.com
Set-Cookie: PSTM=1522315272; expires=Thu, 31-Dec-37 23:55:55 GMT; max-age=2147483647;
path=/; domain=.baidu.com
P3P: CP=" OTI DSP COR IVA OUR IND COM "
Server: BWS/1.1
X-UA-Compatible: IE=Edge,chrome=1
Pragma: no-cache
Cache-control: no-cache
Accept-Ranges: bytes
OK

```

13.2.6 AT+HTTPREAD Read the Response Information of HTTP(S) Server

AT+HTTPREAD Read the Response Information of HTTP(S) Server

| AT+HTTPREAD Read the Response Information of HTTP(S) Server | |
|---|--|
| Read Command AT+HTTPREAD? | Response a)If check successfully: +HTTPREAD: LEN,<len> OK b)If failed(no more data other error): ERROR |
| Write Command AT+HTTPREAD=<byte_size> | Response a)If read the response info successfully: OK +HTTPREAD: DATA,<data_len> <data> |

| | |
|-----------------------|--|
| | <p>[+HTTPREAD: DATA,<data_len> <data> ...] +HTTPREAD: 0</p> <p>If <byte_size> is bigger than the data size received, module will only return actual data size.</p> <p>b) If read failed: ERROR</p> |
| Parameter Saving Mode | - |
| Maximum Response Time | 120000ms |
| Reference | |

Defined Values

| | |
|-------------|------------------------------------|
| <byte_size> | The length of data to read |
| <data_len> | The actual length of read data |
| <data> | Response content from HTTP server |
| <len> | Total size of data saved in buffer |

Example

```
AT+HTTPREAD=0,10
```

```
OK
```

```
+HTTPREAD: 10
```

```
<!doctype>
```

```
+HTTPREAD: 0
```

13.2.7 AT+HTTPDATA Input HTTP(S) Data

AT+HTTPDATA Input HTTP(S) Data

Write Command

```
AT+HTTPDATA=<size>,<time>  
>
```

Response

a)if parameter format is right:

DOWNLOAD

<input data here>

When the total size of the inputted data reaches <size>, TA will report the following code. Otherwise, the serial port will be blocked.

OK

b)If parameter format is wrong or other errors occur:

| | ERROR |
|-----------------------|-------|
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|--------|---|
| <size> | Size in bytes of the data to post. range is 1- 153600 (bytes) |
| <time> | Maximum time in seconds to input data, range is 10-65535. |

Example

```
AT+HTTPDATA=14,10000
DOWNLOAD
1234567890qwer
OK
```

13.2.8 AT+HTTPPOSTFILE Send HTTP Request to HTTP(S) server by File

AT+HTTPPOSTFILE Send HTTP Request to HTTP(S) server by File

| | |
|--|---|
| Test Command AT+HTTPPOSTFILE=? | Response +HTTPPOSTFILE: <filename>[(1-3)][(0-3)][(0-1)] OK |
| Write Command AT+HTTPPOSTFILE=<filename>[,<path>][,<method>][,<send_header>] | Response a)if parameter format is right and server connected successfully: a.1 server response and content is not null OK +HTTPPOSTFILE: <method>,<httpstatuscode>,<content_len> a.2 server response but has no content OK +HTTPPOSTFILE: <method>,<httpstatuscode>,0 b)if parameter format is right but server connected unsuccessfully: OK +HTTPPOSTFILE: <method>,<errcode>,0 c)if parameter format is not right or any other error occurs: ERROR |

| | |
|-----------------------|----------|
| Parameter Saving Mode | - |
| Maximum Response Time | 120000ms |
| Reference | |

Defined Values

| | |
|------------------|---|
| <filename> | String type, filename, the max length is 64.unit:byte. |
| <path> | The directory where the sent file saved. Numeric type, range is 1-3 1 –F:/ (/cache) 2 – D:/(sd card) 3 –E:/ (/data/media/) |
| <method> | HTTP method specification: 0–GET 1– POST 2– HEAD 3– DELETE |
| <httpstatuscode> | Please refer to chapter 13.3.1 |
| <errcode> | Please refer to chapter13.3.2 |
| <send_header> | Send file as HTTP header and Body or Only as Body. Numeric type, the range is 0-1, the default is 0. 0 –Send file as HTTP header and body 1 – Send file as Body |

Example

```
AT+HTTPPOSTFILE="baidu.txt",3
OK
+HTTPPOSTFILE: 1,714,0
```

13.2.9 AT+HTTPREADFILE Receive HTTP(S) Response Content to a file

AT+HTTPREADFILE Receive HTTP(S) Response Content to a File

| | |
|--|--|
| Test Command AT+HTTPREADFILE=? | Response +HTTPREADTFILE: <filename>[, (1-4)] |
| | OK |
| Write Command AT+HTTPREADFILE=<filename>[, <path>] | Response a)if parameter format is right : OK |
| | +HTTPREADFILE: <result> |

b)if parameter format is right:

+HTTPREADFILE: <result>

OK

c)if failed:

+HTTPREADFILE: <result>

ERROR

d)if parameter format is not right or any other error occurs:

ERROR

Parameter Saving Mode

-

Maximum Response Time

-

Reference

Defined Values

<filename>

String type, filename, the max length is 64.unit:byte.

<path>

1 – F:/ (/cache/)

2 – D:/(sd card)

3 – E:/ (/data/media/)

4 – /mssl_cert/(this is for CA file downloading)

Example

```
AT+HTTPREADFILE="baidu.txt",3
```

```
OK
```

```
+HTTPREADFILE: 0
```

13.3 Summary of result codes for HTTPS

13.3.1 Summary of HTTP(S) Response Code

| Code of <httpstatuscode> | Meaning |
|--------------------------|---------------------|
| 100 | Continue |
| 101 | Switching Protocols |

| | |
|-----|---------------------------------|
| 200 | OK |
| 201 | Created |
| 201 | Accepted |
| 203 | Non-Authoritative Information |
| 204 | No Content |
| 205 | Reset Content |
| 206 | Partial Content |
| 300 | Multiple Choices |
| 301 | Moved Permanently |
| 302 | Found |
| 303 | See Other |
| 304 | Not Modified |
| 305 | Use Proxy |
| 307 | Temporary Redirect |
| 400 | Bad Request |
| 401 | Unauthorized |
| 402 | Payment Required |
| 403 | Forbidden |
| 404 | Not Found |
| 405 | Method Not Allowed |
| 406 | Not Acceptable |
| 407 | Proxy Authentication Required |
| 408 | Request Timeout |
| 409 | Conflict |
| 410 | Gone |
| 411 | Length Required |
| 412 | Precondition Failed |
| 413 | Request Entity Too Large |
| 414 | Request-URI Too Large |
| 415 | Unsupported Media Type |
| 416 | Requested range not satisfiable |
| 417 | Expectation Failed |
| 500 | Internal Server Error |
| 501 | Not Implemented |
| 502 | Bad Gateway |
| 503 | Service Unavailable |
| 504 | Gateway timeout |
| 505 | HTTP Version not supported |
| 600 | Not HTTP PDU |
| 601 | Network Error |
| 602 | No memory |

| | |
|-----|------------|
| 603 | DNS Error |
| 604 | Stack Busy |

13.3.2 Summary of HTTP(S) error Code

| Code of <errcode> | Meaning |
|-------------------|---------------------------------------|
| 0 | Success |
| 701 | Alert state |
| 702 | Unknown error |
| 703 | Busy |
| 704 | Connection closed error |
| 705 | Timeout |
| 706 | Receive/send socket data failed |
| 707 | File not exists or other memory error |
| 708 | Invalid parameter |
| 709 | Network error |
| 710 | start a new ssl session failed |
| 711 | Wrong state |
| 712 | Failed to create socket |
| 713 | Get DNS failed |
| 714 | Connect socket failed |
| 715 | Handshake failed |
| 716 | Close socket failed |
| 717 | No network error |
| 718 | Send data timeout |
| 719 | CA missed |

14. AT Commands for HTP

14.1 Overview of AT Commands for HTP

| Command | Description |
|--------------|---------------------------------------|
| AT+CHTPSERV | Set HTP server info |
| AT+CHTUPDATE | Updating date time using HTP protocol |

14.2 Detailed Description of AT Commands for HTP

14.2.1 AT+CHTPSERV Set HTP server info

| AT+CHTPSERV Set HTP server info | |
|---|---|
| Test Command AT+CHTPSERV=? | Response +CHTPSERV: "ADD","HOST",(1-65535), (0-1)[,"PROXY",(1-65535)] +CHTPSERV: "DEL",(0-15) |
| Read Command AT+CHTPSERV? | Response +CHTPSERV: <index>"<host>",<port>,<http_version> [,"<proxy>",<proxy_port>] ... +CHTPSERV: <index>"<host>",<port>[,"<proxy>",<proxy_port>] OK or OK (if HTP server not setted) |
| Write Command AT+CHTPSERV="<cmd>",<host_or_idx>",<port>,<http_version>",<proxy>",<prox | Response OK or ERROR |

y_port>]]

| | |
|-----------------------|---|
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|----------------|---|
| <cmd> | This command to operate the HTP server list. “ADD”: add a HTP server item to the list “DEL”: delete a HTP server item from the list |
| <host_or_idx> | If the <cmd> is “ADD”, this field is the same as <host>, needs quotation marks; If the <cmd> is “DEL”, this field is the index of the HTP server item to be deleted from the list, does not need quotation marks. |
| <host> | The HTP server address. |
| <port> | The HTP server port. |
| <http_version> | The HTTP version of the HTP server: 0-HTTP 1.0 1-HTTP 1.1 |
| <proxy> | The proxy address |
| <proxy_port> | The port of the proxy |
| <index> | The HTP server index. |

Example

```
AT+CHTSPERV="ADD","www.google.com",80,1
OK
```

14.2.2 AT+CHTUPDATE Updating date time using HTP protocol

AT+CHTUPDATE Updating date time using HTP protocol

| | |
|-----------------------|-----------------------------------|
| Test Command | Response |
| AT+CHTUPDATE=? | OK |
| Read Command | Response |
| AT+CHTUPDATE? | +CHTUPDATE: <status> |
| | OK |
| Execution Command | Response |
| AT+CHTUPDATE | OK |

| | |
|-----------------------|---|
| | +CHTPUPDATE: <err> or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-----------------------|--|
| <status> | The status of HTP module: Updating: HTP module is synchronizing date time NULL: HTP module is idle now |
| <err> | The result of the HTP updating |

Example

```
AT+CHTPUPDATE
OK
+CHTPUPDATE: 0
```

14.2.3 Unsolicited HTP Codes

Code of <err>

| | |
|---|--------------------------------|
| 0 | Operation succeeded |
| 1 | Unknown error |
| 2 | Wrong parameter |
| 3 | Wrong date and time calculated |
| 4 | Network error |

15. AT Commands for NTP

15.1 Overview of AT Commands for NTP

| Command | Description |
|---------|--------------------|
| AT+CNTP | Update system time |

15.2 Detailed Description of AT Commands for NTP

15.2.1 AT+CNTP Update system time

| AT+CNTP Update system time | |
|---|--|
| Test Command AT+CNTP=? | Response +CNTP: 255,(-96~96) OK |
| Read Command AT+CNTP? | Response +CNTP: <host>,<timezone> OK |
| Write Command AT+CNTP="<host>"[,<timezone>] | Response OK or ERROR |
| Execution Command AT+CNTP | Response +CNTP: <host>,<timezone> OK or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |

Reference -

Defined Values

| | |
|------------|--|
| <host> | NTP server address, length is 255. |
| <timezone> | Local time zone,the range is(-96 to 96), default value is 0. |

Example

```
AT+CNTP="202.120.2.101",32
```

```
OK
```

```
AT+CNTP
```

```
OK
```

```
+CNTP: 0
```

15.2.2 Unsolicited NTP Codes

Code of <err>

| | |
|---|--------------------------------|
| 0 | Operation succeeded |
| 1 | Unknown error |
| 2 | Wrong parameter |
| 3 | Wrong date and time calculated |
| 4 | Network error |
| 5 | Time zone error |
| 6 | Time out error |

16. AT Commands for MQTT(S)

16.1 Overview of AT Commands for MQTT(S)

| Command | Description |
|--------------------|-----------------------------------|
| AT+CMQTTSTART | Start MQTT service |
| AT+CMQTTSTOP | STOP MQTT service |
| AT+CMQTTACCQ | Acquire a client |
| AT+CMQTTREL | Release a client |
| AT+CMQTTSSLCFG | Set the SSL context |
| AT+CMQTTWILLTOPIC | Input the will topic |
| AT+CMQTTWILLMSG | Input the will message |
| AT+CMQTTCONNECT | Connect to MQTT server |
| AT+CMQTTDISC | Disconnect from server |
| AT+CMQTTTOPIC | Input the publish message topic |
| AT+CMQTTPAYLOAD | Input the publish message body |
| AT+CMQTTPUB | Publish a message to server |
| AT+CMQTTSUBTOPIC | Input a subscribe message topic |
| AT+CMQTTSUB | Subscribe a message to server |
| AT+CMQTTUNSUBTOPIC | Input a unsubscribe message topic |
| AT+CMQTTUNSUB | Unsubscribe a message to server |
| AT+CMQTTCFG | Configure the MQTT Context |

16.2 Detailed Description of AT Commands for MQTT(S)

16.2.1 AT+CMQTTSTART Start MQTT service

| AT+CMQTTSTART Start MQTT service | |
|----------------------------------|---------------------------------|
| Execution Command | Response |
| AT+CMQTTSTART | OK |
| | +CMQTTSTART: <err> |

or
+CMQTTSTART: <err>

OK

or
ERROR

+CMQTTSTART: <err>

or
+CMQTTSTART: <err>

ERROR

or
ERROR

Defined Values

<err> The result code, please refer to chapter 16.3.1

Example

```
AT+CMQTTSTART
OK
+CMQTTSTART: 0
```

NOTE

- It must be executed before any other MQTT related operations

16.2.2 AT+CMQTTSTOP STOP MQTT service

AT+CMQTTSTOP STOP MQTT service

| Execution Command | Response |
|---------------------|--------------------------------|
| AT+CMQTTSTOP | OK |
| | +CMQTTSTOP: <err> |
| | or |
| | +CMQTTSTOP: <err> |

| | |
|-----------------------|--|
| | OK or ERROR |
| | +CMQTTSTOP: <err> or +CMQTTSTOP: <err> |
| | ERROR or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-------|---|
| <err> | The result code, please refer to chapter 16.3.1 |
|-------|---|

Example

```
AT+CMQTTSTOP
OK

+CMQTTSTOP: 0
```

16.2.3 AT+CMQTTACCQ Acquire a client

| AT+CMQTTACCQ Acquire a client | |
|---|--|
| Test Command AT+CMQTTACCQ=? | Response +CMQTTACCQ: (0-1),(1-128),(0-1),(3-4) |
| | OK |
| Read Command AT+CMQTTACCQ? | Response +CMQTTACCQ: <client_index>,<clientID>,<server_type> +CMQTTACCQ: <client_index>,<clientID>,<server_type> |
| | OK |
| Write Command AT+CMQTTACCQ=<client_index>,<clientID>[,<server_type>[,<mqtt_version>]] | Response OK or +CMQTTACCQ: <client_index>,<err> |

| | |
|-----------------------|------------------------------------|
| | ERROR or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-----------------------------|---|
| <client_index> | A numeric parameter that identifies a client. The range of permitted values is 0 to 1. |
| <clientID> | The UTF-encoded string. It specifies a unique identifier for the client. The string length is from 1 to 128 bytes. |
| <server_type> | A numeric parameter that identifies the server type. The default value is 0. 0 - MQTT server with TCP 1 - MQTT server with SSL/TLS |
| <mqtt_version> | A numeric parameter that identifies the MQTT protocol version. The permitted value is 3 or 4. 3 - MQTT version 3.1 4 - MQTT version 3.1.1 |
| <err> | The result code, please refer to chapter 16.3.1 |

Example

```
AT+CMQTTACCQ=0,"client test0",0,4
OK
```

NOTE

- It must be called before all commands about MQTT connect and after AT+CMQTTSTART

16.2.4 AT+CMQTTREL Release a client

AT+CMQTTREL Release a client

| | |
|--------------------------------------|--|
| Test Command AT+CMQTTREL=? | Response +CMQTTREL: (0-1) OK |
|--------------------------------------|--|

| | |
|--|---|
| Read Command AT+CMQTTREL? | Response OK |
| Write Command AT+CMQTTREL=<client_index> | Response OK or +CMQTTREL: <client_index>,<err> ERROR or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | 120000ms |
| Reference | |

Defined Values

| | |
|-----------------------------|--|
| <client_index> | A numeric parameter that identifies a client. The range of permitted values is 0 to 1. |
| <err> | The result code, please refer to chapter 16.3.1 |

Example

```
AT+CMQTTREL=0
OK
```

NOTE

- It must be called after AT+CMQTTDISC and before AT+CMQTTSTOP

16.2.5 AT+CMQTTSSLCFG Set the SSL context

AT+CMQTTSSLCFG Set the SSL context

| | |
|---|--|
| Test Command AT+CMQTTSSLCFG=? | Response +CMQTTSSLCFG: (0,1),(0-9) OK |
| Read Command AT+CMQTTSSLCFG? | Response +CMQTTSSLCFG: <session_id>,<ssl_ctx_index > +CMQTTSSLCFG: <session_id>,<ssl_ctx_index > |

| | |
|--|---|
| | OK |
| Write Command AT+CMQTTSSLCFG=<sessi on_id>,<ssl_ctx_index> | Response OK or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|------------------------------|---|
| <session_id> | A numeric parameter that identifies a client. The range of permitted values is 0 to 1. |
| <ssl_ctx_index> | The SSL context ID which will be used in the SSL connection. Refer to the <ssl_ctx_index> of AT+CSSLCFG |

Example

```
AT+CMQTTSSLCFG=0,1
OK
```

NOTE

- If you don't set the SSL context by this command before connecting to server by AT+CMQTTCONNECT, the CMQTTCONNECT operation will use the SSL context as same as index <session_id> (the 1st parameter of AT+ CMQTTCONNECT) when connecting to the server

16.2.6 AT+CMQTTWILLTOPIC Input the will topic

| AT+CMQTTWILLTOPIC Input the will topic | |
|--|---|
| Test Command AT+CMQTTWILLTOPIC=? | Response +CMQTTWILLTOPIC: (0-1),(1-1024) |
| Write Command AT+CMQTTWILLTOPIC=<cli ent_index>,<req_length> | Response > <input data here> OK or |

| | |
|-----------------------|--|
| | +CMQTTWILLTOPIC: <client_index>,<err> |
| | ERROR or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-----------------------------|--|
| <client_index> | A numeric parameter that identifies a client. The range of permitted values is 0 to 1. |
| <req_length> | The length of input topic. The will topic should be UTF-encoded string. The range is from 1 to 1024 bytes. |
| <err> | The result code, please refer to chapter 16.3.1 |

Example

```
AT+CMQTTWILLTOPIC=0,15
>simcomwilltopic
OK
```

16.2.7 AT+CMQTTWILLMSG Input the will message

| AT+CMQTTWILLMSG Input the will message | |
|--|---|
| Test Command AT+CMQTTWILLMSG=? | Response +CMQTTWILLMSG: (0-1),(1-1024),(0-2) OK |
| Write Command AT+CMQTTWILLMSG=<client_index>,<req_length>,<qs> | Response > <input data here> OK or +CMQTTWILLMSG: <client_index>,<err> ERROR or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |

Reference

Defined Values

| | |
|-----------------------------|---|
| <client_index> | A numeric parameter that identifies a client. The range of permitted values is 0 to 1. |
| <req_length> | The length of input data. The will message should be UTF-encoded string. The range is from 1 to 1024 bytes. |
| <qos> | The qos value of the will message. The range is from 0 to 2. |
| <err> | The result code, please refer to chapter 16.3.1 |

Example

```
AT+CMQTTWILLMSG=0,17,0
>simcomwillmessage
OK
```

16.2.8 AT+CMQTTDISC Disconnect from server

AT+CMQTTDISC Disconnect from server

| | |
|---|---|
| Test Command AT+CMQTTDISC=? | Response +CMQTTDISC: (0-1),(0,60-180) OK |
| Read Command AT+CMQTTDISC? | Response +CMQTTDISC: 0,<disc_state> +CMQTTDISC: 1,<disc_state> OK |
| Write Command AT+CMQTTDISC=<client_index>,<timeout> | Response OK +CMQTTDISC: <client_index>,<err> or +CMQTTDISC: <client_index>,<err> OK or +CMQTTDISC: <client_index>,<err> ERROR or |

| | |
|-----------------------|--------------|
| | ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | 120000ms |
| Reference | |

Defined Values

| | |
|----------------|--|
| <client_index> | A numeric parameter that identifies a client. The range of permitted values is 0 to 1. |
| <timeout> | The timeout value for disconnection. The unit is second. The range is 60s to 180s. The default value is 0s (not set the timeout value) |
| <disc_state> | 1 - disconnection 0 - connection |
| <err> | The result code, please refer to chapter 16.3.1 |

Example

```
AT+CMQTTDISC=0,120
```

```
OK
```

```
+CMQTTDISC: 0,0
```

16.2.9 AT+CMQTTCONNECT Connect to MQTT server

AT+CMQTTCONNECT Connect to MQTT server

| | |
|--|---|
| Test Command AT+CMQTTCONNECT=? | Response +CMQTTCONNECT: (0-1),(9-256),(1-64800),(0-1) OK |
| Read Command AT+CMQTTCONNECT? | Response +CMQTTCONNECT: 0[,<server_addr>,<keepalive_time>,<clean_session>[,<user_name>,<pass_word>]]] +CMQTTCONNECT: 1[,<server_addr>,<keepalive_time>,<clean_session>[,<user_name>,<pass_word>]]] OK |
| Write Command AT+CMQTTCONNECT=<client_index>,<server_addr>,<keepalive_time>,<clean_sess | Response OK +CMQTTCONNECT: <client_index>,<err> |

| | |
|--|--|
| <code>ion>[,<user_name>[,<pass_word>]]</code> | or <code>+CMQTTCONNECT: <client_index>,<err></code> |
| | ERROR or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | 120000ms |
| Reference | |

Defined Values

| | |
|-------------------------------------|---|
| <code><client_index></code> | A numeric parameter that identifies a client. The range of permitted values is 0 to 1. |
| <code><server_addr></code> | The string that described the server address and port. The range of the string length is 9 to 256 bytes. The string should be like this "tcp://116.247.119.165:5141", must begin with "tcp://". If the <code><server_addr></code> not include the port, the default port is 1883. |
| <code><keepalive_time></code> | The time interval between two messages received from a client. The client will send a keep-alive packet when there is no message sent to server after song long time. The range is from 1s to 64800s (18 hours) |
| <code><clean_session></code> | The clean session flag. The value range is from 0 to 1, and default value is 0. 0 - the server must store the subscriptions of the client after it disconnected. This includes continuing to store QoS 1 and QoS 2 messages for the subscribed topics so that they can be delivered when the client reconnects. The server must also maintain the state of in-flight messages being delivered at the point the connection is lost. This information must be kept until the client reconnects. 1 - the server must discard any previously maintained information about the client and treat the connection as "clean". The server must also discard any state when the client disconnects. |
| <code><user_name></code> | The user name identifies the name of the user which can be used for authentication when connecting to server. The string length is from 1 to 256 bytes. |
| <code><password></code> | The password corresponding to the user which can be used for authentication when connecting to server. The string length is from 1 to 256 bytes. |
| <code><err></code> | The result code, please refer to chapter 16.3.1 |

Example

```
AT+CMQTTCONNECT=0,"tcp://hooleeping.com:8883",60,1
OK
```

+CMQTTCONNECT: 0,0

NOTE

- If you don't set the SSL context by AT+CMQTTSSLCFG before connecting a SSL/TLS MQTT server by AT+CMQTTCONNECT, it will use the <client_index> (the 1st parameter of AT+CMQTTCONNECT) SSL context when connecting to the server.

16.2.10 AT+CMQTTTOPIC Input the publish message topic

AT+CMQTTTOPIC Input the publish message topic

| | |
|---|--|
| Test Command AT+CMQTTTOPIC=? | Response +CMQTTTOPIC: (0-1),(1-1024) OK |
| Write Command AT+CMQTTTOPIC=<client_index>,<req_length> | Response > <input data here> OK or +CMQTTTOPIC: <client_index>,<err> ERROR or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|----------------|--|
| <client_index> | A numeric parameter that identifies a client. The range of permitted values is 0 to 1. |
| <req_length> | The length of input topic data. The publish message topic should be UTF-encoded string. The range is from 1 to 1024 bytes. |
| <err> | The result code, please refer to chapter 16.3.1 |

Example

```
AT+CMQTTTOPIC=0,11
>simcomtopic
OK
```

NOTE

- The topic will be clean after execute AT+CMQTTTPUB

16.2.11 AT+CMQTTTPAYLOAD Input the publish message body

AT+CMQTTTPAYLOAD Input the publish message body

| | |
|--|---|
| Test Command AT+CMQTTTPAYLOAD=? | Response +CMQTTTPAYLOAD: (0-1),(1-10240) |
| Write Command AT+CMQTTTPAYLOAD=<client_index>,<req_length> | Response OK |
| | > <input data here> OK +CMQTTTPAYLOAD: <client_index>,<err> |
| Parameter Saving Mode | ERROR |
| Maximum Response Time | or ERROR |
| Reference | - |
| | - |

Defined Values

| | |
|-----------------------------|--|
| <client_index> | A numeric parameter that identifies a client. The range of permitted values is 0 to 1. |
| <req_length> | The length of input message data. The publish message should be UTF-encoded string. The range is from 1 to 10240 bytes |
| <err> | The result code, please refer to chapter 16.3.1 |

Example

```
AT+CMQTTTPAYLOAD=0,13
>simcompayload
OK
```


NOTE

- The payload will be clean after execute AT+CMQTTPUB

16.2.12 AT+CMQTTPUB Publish a message to server

AT+CMQTTPUB Publish a message to server

| | |
|--|---|
| Test Command AT+CMQTTPUB=? | Response +CMQTTPUB: (0-1),(0-2),(60-180),(0-1),(0-1) |
| Write Command AT+CMQTTPUB=<client_index>,<qos>,<pub_timeout>[,<retained> [,<dup>]] | Response OK +CMQTTPUB: <client_index>,<err> or +CMQTTPUB: <client_index>,<err> ERROR or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | 120000ms |
| Reference | |

Defined Values

| | |
|-----------------------------|---|
| <client_index> | A numeric parameter that identifies a client. The range of permitted values is 0 to 1. |
| <qos> | The publish message's qos. The range is from 0 to 2. 0 – at most once 1 – at least once 2 – exactly once |
| <pub_timeout> | The publishing timeout interval value. Since the client publish a message to server, it will report failed if the client receive no response from server after the timeout value seconds. The range is from 60s to 180s |
| <retained> | The retain flag of the publish message. The value is 0 or 1. The default value is 0. When a client sends a PUBLISH to a server, if the retain flag is set to |

| | |
|-------|--|
| | 1, the server should hold on to the message after it has been delivered to the current subscribers |
| <dup> | The dup flag to the message. The value is 0 or 1. The default value is 0. The flag is set when the client or server attempts to re-deliver a message |
| <err> | The result code, please refer to chapter 16.3.1 |

Example

```
AT+CMQTTPUB=0,0,120
```

```
OK
```

```
+CMQTTPUB: 0,0
```

16.2.13 AT+CMQTTSUBTOPIC Input a subscribe message topic

AT+CMQTTSUBTOPIC Input a subscribe message topic

| | |
|---|---|
| Test Command AT+CMQTTSUBTOPIC=? | Response +CMQTTSUBTOPIC: (0-1),(1-1024),(0-2) OK |
| Write Command AT+CMQTTSUBTOPIC=<client_index>,<req_length>,<qs> | Response > <input data here> OK or +CMQTTSUBTOPIC: <client_index>,<err> ERROR or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|----------------|--|
| <client_index> | A numeric parameter that identifies a client. The range of permitted values is 0 to 1. |
| <req_length> | The length of input topic data. The publish message topic should be UTF-encoded string. The range is from 1 to 1024 bytes. |

| | |
|-------|---|
| | NOTE: The max length of the total cached topics is 5120 |
| <qos> | The publish message's qos. The range is from 0 to 2. 0 – at most once 1 – at least once 2 – exactly once |
| <err> | The result code, please refer to chapter 16.3.1 |

Example

```
AT+CMQTTSUBTOPIC=0,11,0
>simcomtopic
OK
```

NOTE

- The topic will be clean after execute AT+CMQTTSUB.

16.2.14 AT+CMQTTSUB Subscribe a message to server

AT+CMQTTSUB Subscribe a message to server

| | |
|--------------------------------------|--|
| Test Command AT+CMQTTSUB=? | Response +CMQTTSUB: (0-1),(1-1024),(0-2),(0-1) |
|--------------------------------------|--|

OK

| | |
|---|---|
| Write Command /*subscribe one or more topics which input by AT+CMQTTSUBTOPIC*/ AT+CMQTTSUB=<client_index>[,<dup>] | Response OK +CMQTTSUB: <client_index>,<err> or +CMQTTSUB: <client_index>,<err> |
|---|---|

ERROR

or

ERROR

| | |
|--|--|
| Write Command /* subscribe one topic*/ AT+CMQTTSUB=<client_index>,<reqLength>,<qos>[,<dup>] | Response > <input data here> OK +CMQTTSUB: <client_index>,<err> or |
|--|--|

| | |
|-----------------------|--|
| | +CMQTTSUB: <client_index>,<err> |
| | ERROR or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | 120000ms |
| Reference | |

Defined Values

| | |
|-----------------------------|---|
| <client_index> | A numeric parameter that identifies a client. The range of permitted values is 0 to 1. |
| <req_length> | The length of input topic data. The message topic should be UTF-encoded string. The range is from 1 to 1024 bytes. |
| <qos> | The publish message's qos. The range is from 0 to 2. 0 – at most once 1 – at least once 2 – exactly once |
| <dup> | The dup flag to the message. The value is 0 or 1. The default value is 0. The flag is set when the client or server attempts to re-deliver a message. |
| <err> | The result code, please refer to chapter 16.3.1 |

Example

```
AT+CMQTTSUB=0
OK
+CMQTTSUB: 0,0
```

16.2.15 AT+CMQTTUNSUBTOPIC Input a unsubscribe message topic

| AT+CMQTTUNSUBTOPIC Input a unsubscribe message topic | |
|--|--|
| Test Command AT+CMQTTUNSUBTOPIC=? | Response +CMQTTUNSUBTOPIC: (0-1),(1-1024) OK |
| Write Command AT+CMQTTUNSUBTOPIC=<client_index>,<req_length> | Response > <input data here> OK |

| | |
|-----------------------|---|
| | or +CMQTTUNSUBTOPIC: <client_index>,<err> |
| | ERROR |
| | or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-----------------------------|--|
| <client_index> | A numeric parameter that identifies a client. The range of permitted values is 0 to 1. |
| <req_length> | The length of input topic data. The publish message topic should be UTF-encoded string. The range is from 1 to 1024 bytes. |
| <err> | The result code, please refer to chapter 16.3.1 |

Example

```
AT+CMQTTUNSUBTOPIC=0,11
>simcomtopic
OK
```

NOTE

- The max length of the total cached topics is 5120.
- The topic will be clean after execute AT+CMQTTUNSUB

16.2.16 AT+CMQTTUNSUB Unsubscribe a message to server

AT+CMQTTUNSUB Unsubscribe a message to server

| | |
|--|---|
| Test Command AT+CMQTTUNSUB=? | Response +CMQTTUNSUB: (0-1),(1-1024),(0-1) |
| | OK |
| Write Command /* unsubscribe one or more topics which input by AT+CMQTTUNSUBTOPIC*/ | Response OK +CMQTTUNSUB: <client_index>,<err> |

| | |
|--|--|
| <code>AT+CMQTTUNSUB=<client_index>,<dup></code> | or <code>+CMQTTUNSUB: <client_index>,<err></code> |
| | ERROR or ERROR |
| Write Command /* unsubscribe one topic*/ <code>AT+CMQTTUNSUB=<client_index>,<reqLength>,<dup></code> | Response > <input data here> OK <code>+CMQTTUNSUB: <client_index>,<err></code> or <code>+CMQTTUNSUB: <client_index>,<err></code> ERROR or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | 120000ms |
| Reference | |

Defined Values

| | |
|----------------|---|
| <client_index> | A numeric parameter that identifies a client. The range of permitted values is 0 to 1. |
| <req_length> | The length of input topic data. The message topic should be UTF-encoded string. The range is from 1 to 1024 bytes. |
| <dup> | The dup flag to the message. The value is 0 or 1. The default value is 0. The flag is set when the client or server attempts to re-deliver a message. |
| <err> | The result code, please refer to chapter 16.3.1 |

Example

```
AT+CMQTTUNSUB =0,0
OK

+CMQTTUNSUB: 0,0
```

16.2.17 AT+CMQTTCFG Configure the MQTT Context

| AT+CMQTTCFG Configure the MQTT Context | |
|--|---|
| Test Command AT+CMQTTCFG=? | Response +CMQTTCFG: "checkUTF8",(0-1),(0-1) +CMQTTCFG: "optimeout",(0-1),(20-120) OK |
| Read Command AT+CMQTTCFG? | Response +CMQTTCFG: 0,<checkUTF8_flag>,<optimeout_val> +CMQTTCFG: 1,<checkUTF8_flag>,<optimeout_val> OK |
| Write Command /*Configure the check UTF8 flag of the specified MQTT client context*/ AT+CMQTTCFG="checkUTF8",<client_index>,<checkUTF8_flag> | Response OK or +CMQTTCFG: <client_index>,<err> OK or ERROR |
| Write Command /*Configure the max timeout interval of the send or receive data operation*/ AT+CMQTTCFG="optimeout",<client_index>,<optimeout_val> | Response OK or +CMQTTCFG: <client_index>,<err> OK or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-------------------------------|---|
| <client_index> | A numeric parameter that identifies a client. The range of permitted values is 0 to 1. |
| <checkUTF8_flag> | The flag to indicate whether to check the string is UTF8 coding or not, the default value is 1. 0 – Not check UTF8 coding. 1 – Check UTF8 coding. |
| <optimeout_val> | The max timeout interval of sending or receiving data operation. The range is from 20 seconds to 120 seconds, the default value is 120 seconds. |
| <err> | The result code, please refer to chapter 16.3.1 |

Example

AT+CMQTTCFG="checkUTF8",0,0

OK

AT+CMQTTCFG="optimeout",0,120

OK

NOTE

- It must be called before AT+CMQTTCONNECT and after AT+CMQTTACCQ. The setting will be cleared after AT+CMQTTREL

16.3 Summary of result codes for MQTT(S)

16.3.1 Summary of Command result <err> codes

| Code of <err> | Meaning |
|---------------|-------------------------|
| 0 | operation succeeded |
| 1 | failed |
| 2 | bad UTF-8 string |
| 3 | sock connect fail |
| 4 | sock create fail |
| 5 | sock close fail |
| 6 | message receive fail |
| 7 | network open fail |
| 8 | network close fail |
| 9 | network not opened |
| 10 | client index error |
| 11 | no connection |
| 12 | invalid parameter |
| 13 | not supported operation |
| 14 | client is busy |
| 15 | require connection fail |
| 16 | sock sending fail |
| 17 | timeout |
| 18 | topic is empty |
| 19 | client is used |

| | |
|----|---|
| 20 | client not acquired |
| 21 | client not released |
| 22 | length out of range |
| 23 | network is opened |
| 24 | packet fail |
| 25 | DNS error |
| 26 | socket is closed by server |
| 27 | connection refused: unaccepted protocol version |
| 28 | connection refused: identifier rejected |
| 29 | connection refused: server unavailable |
| 30 | connection refused: bad user name or password |
| 31 | connection refused: not authorized |
| 32 | handshake fail |
| 33 | not set certificate |
| 34 | open SSL session failed |

16.3.2 Summary of Unsolicited Result Codes

| Unsolicited codes | Description |
|---|---|
| +CMQTTCONNLOST: <client_index>,<cause> | When client disconnect passively, URC "+CMQTTCONNLOST" will be reported, then user need to connect MQTT server again. |
| +CMQTTPING: <client_index>,<err> | When send ping (which keep-alive to the server) to server failed, the module will report this URC. If received this message, you should disconnect the connection and re-connect |
| +CMQTTNONET | When the network is become no network, the module will report this URC. If received this message, you should restart the MQTT service by AT+CMQTTSTART. |
| +CMQTTTRXSTART: <client_index>,<topic_total_len> >,<payload_total_len> | If a client subscribes to one or more topics, any message published to those topics are sent by the server to the client. The following URC is used for transmitting the message published from server to client. |
| +CMQTTTRXTOPIC: <client_index>,<sub_topic_len> <sub_topic> | 1) +CMQTTTRXSTART: <client_index>,<topic_total_len>,<payload_total_len> At the beginning of receiving published message, the module will report this to user, and indicate client index with <client_index>, the topic total length with <topic_total_len> and the payload total length with <payload_total_len>. |
| <i>/*for long topic, split to multiple packets to report*/</i> [<CR><LF>+CMQTTTRXTOPIC: <client_index>,<sub_topic_len> <sub_topic>] | 2) +CMQTTTRXTOPIC: <client_index>,<sub_topic_len>\r\n<sub_topic> |

+CMQTTRXPAYLOAD: After the command “+CMQTTRXSTART” received, the module will report the second message to user, and indicate client index with <client_index>, the topic packet length with <sub_topic_len> and the topic content with <sub_topic> after “\r\n”.

<client_index>,<sub_payload_len>
<sub_payload>

/*for long payload, split to multiple packets to report*/ For long topic, it will be split to multiple packets to report and the command “+CMQTTRXTOPIC” will be send more than once with the rest of topic content. The sum of <sub_topic_len> is equal to <topic_total_len>.

[+CMQTTRXPAYLOAD: 3)**+CMQTTRXPAYLOAD:**
<client_index>,<sub_payload_len>\r\n<sub_payload>

<sub_payload>] After the command “+CMQTTRXTOPIC” received, the module will send third message to user, and indicate client index with <client_index>, the payload packet length with <sub_payload_len> and the payload content with <sub_payload> after “\r\n”.

+CMQTTRXEND: <client_index> For long payload, the same as “+CMQTTRXTOPIC”.

4) **+CMQTTRXEND: <client_index>** At last, the module will send fourth message to user and indicate the topic and payload have been transmitted completely.

Defined Values

| | |
|---------------------|---|
| <client_index> | A numeric parameter that identifies a client. The range of permitted values is 0 to 1. |
| <cause> | The cause of disconnection. 1 – Socket is closed passively. 2 – Socket is reset. 3 – Network is closed. |
| <topic_total_len> | The length of message topic received from MQTT server. The range is from 1 to 1024 bytes. |
| <payload_total_len> | The length of message body received from MQTT server. The range is from 1 to 10240 bytes. |
| <sub_topic_len> | The sub topic packet length, The sum of <sub_topic_len> is equal to <topic_total_len>. |
| <sub_topic> | The sub topic content. |
| <sub_payload_len> | Max length is 1500. The sub message body packet length. The sum of <sub_payload_len> is equal to <payload_total_len>. |
| <sub_payload> | The sub message body content. |
| <err> | The result code, please refer to chapter 16.3.1 |

17. AT Commands for GPS

17.1 Overview of AT Commands for GPS

| Command | Description |
|-----------------|--|
| AT+CGPS | Start/Stop GPS session |
| AT+CGPSINFO | Get GPS fixed position information |
| AT+CGPSCOLD | Cold start GPS |
| AT+CGPSHOT | Hot start GPS |
| AT+CGPSURL | Set AGPS default server URL |
| AT+CGPSSSL | Set AGPS transport security |
| AT+CGPSAUTO | Start GPS automatic |
| AT+CGPSNMEA | Configure NMEA sentence type |
| AT+CGPSNMEARATE | Set NMEA output rate |
| AT+CGPSMD | Configure AGPS MO method |
| AT+CGPSFTM | Start GPS test mode |
| AT+CGPSDEL | Delete the GPS information |
| AT+CGPSXE | Enable/Disable GPS XTRA function |
| AT+CGPSXD | Download XTRA assistant file |
| AT+CGPSXDAUTO | Download XTRA assistant file automatically |
| AT+CGPSINFOCFG | Report GPS NMEA-0183 sentence |
| AT+CGPSPMD | Configure positioning mode |
| AT+CGPSMSB | Configure based mode switch to standalone |
| AT+CGPSHOR | Configure positioning desired accuracy |
| AT+CGPSNOTIFY | LCS respond position request |
| AT+CGNSSINFO | Get GNSS fixed position information |
| AT+CGNSSMODE | Configure GNSS support mode |
| AT+CGPSIPV6 | Set AGPS IPV6 Addr&Port |
| AT+CGPSXTRADATA | Query the validity of the current gpsOne XTRA data |

17.2 Detailed Description of AT Commands for GPS

17.2.1 AT+CGPS Start/Stop GPS session

| AT+CGPS Start/Stop GPS Session | |
|--|--|
| Test Command AT+CGPS=? | Response +CGPS: (list of supported <on/off>s),(list of supported <mode>s) OK |
| Read Command AT+CGPS? | Response +CGPS: <on/off>,<mode> OK |
| Write Command AT+CGPS=<on/off>[,<mode> >] | Response OK <i>If UE-assisted mode, when fixed will report indication:</i> +CGPS:<lat>,<lon>,<alt>,<date>,<time> <i>If <off>, it will report indication:</i> +CGPS:0 or ERROR |

Defined Values

| | |
|---------------------|--|
| <on/off> | Values reserved by the present document: 0 – stop GPS session 1 – start GPS session |
| <mode> | Ignore - standalone mode 1 – standalone mode 2 – UE-based mode 3 – UE-assisted mode |
| <lat> | Latitude of current position. Unit is in 10 ⁸ degree |
| <lon> | Longitude of current position. Unit is in 10 ⁸ degree |
| <alt> | MSL Altitude. Unit is meters. |
| <date> | UTC Date. Output format is ddmmyyyy |
| <time> | UTC Time. Output format is hhmmss.s |
| <unconfidence> | Unconfidence of the location, GPS fixed report 39, cell fixed report 100. |
| <uncertainty_meter> | Uncertainty meters. |

Example

```
AT+CGPS?
+CGPS:1
```

OK
AT+CGPS=1
OK

NOTE

- Output of NMEA sentences is automatic; no control via AT commands is provided. If executing AT+CGPS=1, the GPS session will choose cold or hot start automatically.
- UE-based and UE-assisted mode depend on URL (AT+CGPSURL). When UE-based mode fails, it will switch standalone mode.
- UE-assisted mode is singly fixed. Standalone and UE-based mode is consecutively fixed.
- After the GPS closed, it should to wait about 2s~30s for start again. Reason : If the signal conditions are right (strong enough signals to allow ephemeris demodulation) or ephemeris demodulation is on going, sometimes MGP will stay on longer in order to demodulate more ephemeris. This will help the engine provide faster TTFF and possibly better yield later (up to 2 hours), because it has the benefit of more ephemeris available.
- For SIM7600E-H-M2/SIM7600SA-H-M2/SIM7600A-H-M2 module, GPS started should be decided by the physical switch of GPS flight mode in the module firstly. Close the switch, GPS will be started automatically, then you can open or close gps by AT command, otherwise, GPS could not be started in any way.

17.2.2 AT+CGPSINFO Get GPS fixed position information

AT+CGPSINFO Get GPS fixed position information

| | |
|--|--|
| Test Command AT+CGPSINFO=? | Response +CGPSINFO: (scope of <time>) OK |
| Read Command AT+CGPSINFO? | Response +CGPSINFO: <time> OK |
| Write Command AT+CGPSINFO=<time> | Response OK +CGPSINFO:[<lat>],[<N/S>],[<log>],[<E/W>],[<date>],[<UTC time>],[<alt>],[<speed>],[<course>] <i>If <off>, it will report indication:</i> OK (if <time>=0) |
| Execution Command AT+CGPSINFO | Response +CGPSINFO:[<lat>],[<N/S>],[<log>],[<E/W>],[<date>],[<UTC time>],[<alt>],[<speed>],[<course>] |

OK

Defined Values

| | |
|------------|---|
| <lat> | Latitude of current position. Output format is ddmm.mmmmmm |
| <N/S> | N/S Indicator, N=north or S=south |
| <log> | Longitude of current position. Output format is dddmm.mmmmmm |
| <E/W> | E/W Indicator, E=east or W=west |
| <date> | Date. Output format is ddmmyy |
| <UTC time> | UTC Time. Output format is hhmmss.s |
| <alt> | MSL Altitude. Unit is meters. |
| <speed> | Speed Over Ground. Unit is knots. |
| <course> | Course. Degrees. |
| <time> | The range is 0-255, unit is second, after set <time> will report the GPS information every the seconds. |

Example

```

AT+CGPSINFO=?
+CGPSINFO: (0-255)

OK
AT+CGPSINFO?
+CGPSINFO: 0

OK
AT+CGPSINFO
+CGPSINFO:3113.343286,N,12121.234064,E,250311,072809.3,44.1,0.0,0

OK

```

17.2.3 AT+CGPSCOLD Cold Start GPS

AT+CGPSCOLD Cold Start GPS

| Test Command | Response |
|----------------------|-----------|
| AT+CGPSCOLD=? | OK |
| Execution Command | Response |
| AT+CGPSCOLD | OK |

Example

AT+CGPSCOLD=?

OK

AT+CGPSCOLD

OK

NOTE

- Before using this command, it must use AT+CGPS=0 to stop GPS session.

17.2.4 AT+CGPSHOT Hot Start GPS

AT+CGPSHOT Hot Start GPS

| | |
|--------------|----------|
| Test Command | Response |
|--------------|----------|

| | |
|---------------------|-----------|
| AT+CGPSHOT=? | OK |
|---------------------|-----------|

| | |
|-------------------|----------|
| Execution Command | Response |
|-------------------|----------|

| | |
|-------------------|-----------|
| AT+CGPSHOT | OK |
|-------------------|-----------|

Example

AT+CGPSHOT=?

OK

AT+CGPSHOT

OK

NOTE

- Before using this command, it must use AT+CGPS=0 to stop GPS session.

17.2.5 AT+CGPSURL Set AGPS default server URL

AT+CGPSURL Set AGPS default server URL

| | |
|--------------|----------|
| Test Command | Response |
|--------------|----------|

| | |
|---------------------|-----------|
| AT+CGPSURL=? | OK |
|---------------------|-----------|

| | |
|--------------|----------|
| Read Command | Response |
|--------------|----------|

| | |
|--------------------|------------------------------|
| AT+CGPSURL? | +CGPSURL: <URL> |
|--------------------|------------------------------|

| | |
|--|-----------|
| | OK |
|--|-----------|

| | |
|--|---|
| Write Command AT+CGPSURL=<URL> | Response OK or ERROR |
|--|---|

Defined Values

| | |
|-------|--|
| <URL> | AGPS default server URL. It needs double quotation marks. NOTE: Max length of URL is 128. |
|-------|--|

Example

```
AT+CGPSURL="123.123.123.123:8888"
OK
AT+CGPSURL?
+CGPSURL: "123.123.123.123:8888"
OK
```

NOTE

- It will take effect only after restarting.

17.2.6 AT+CGPSSSL Set AGPS transport security

AT+CGPSSSL Set AGPS transport security

| | |
|--|---|
| Test Command AT+CGPSSSL=? | Response +CGPSSSL: (list of supported<SSL>s) OK |
| Read Command AT+CGPSSSL? | Response +CGPSSSL: <SSL> OK |
| Write Command AT+CGPSSSL=<SSL> | Response OK or ERROR |

Defined Values

| | |
|-------|---------------------------|
| <SSL> | 0 – don't use certificate |
|-------|---------------------------|

1 – use certificate

Example

```
AT+CGPSSSL=0
OK
```

17.2.7 AT+CGPSAUTO Start GPS automatic

| AT+CGPSAUTO Start GPS automatic | |
|--|---|
| Test Command AT+CGPSAUTO=? | Response +CGPSAUTO: (list of supported<auto>s) OK |
| Read Command AT+CGPSAUTO? | Response +CGPSAUTO: <auto> OK |
| Write Command AT+CGPSAUTO=<auto> | Response OK or ERROR |

Defined Values

| | | |
|--------|---|-----------------|
| <auto> | 0 | – Non-automatic |
| | 1 | – automatic |

Example

```
AT+CGPSAUTO=1
OK
```

NOTE

- If GPS start automatically, its operation mode is standalone mode..

17.2.8 AT+CGPSNMEA Configure NMEA sentence type

| AT+CGPSNMEA Configure NMEA sentence type | |
|--|---|
| Test Command AT+CGPSNMEA=? | Response +CGPSNMEA: (list of supported<auto>s) OK |
| Read Command AT+CGPSNMEA? | Response +CGPSNMEA: <nmea> OK |
| Write Command AT+CGPSNMEA=<nmea> | Response OK or <i>If GPS engine is running:</i> ERROR |

Defined Values

| | |
|---------------------|--|
| <auto> | <p>Range – 0 to 262143</p> <p>Each bit enables an NMEA sentence output as follows:</p> <ul style="list-style-type: none"> <u>Bit 0</u> – GPGLGA (global positioning system fix data) <u>Bit 1</u> – GPRMCR (recommended minimum specific GPS/TRANSIT data) <u>Bit 2</u> – GPGLSV (GPS satellites in view) <u>Bit 3</u> – GPGLSA (GPS DOP and active satellites) <u>Bit 4</u> – GPVTRG (track made good and ground speed) <u>Bit 5</u> – PQXFI (Global Positioning System Extended Fix Data.) <u>Bit 6</u> – GLGLSV (GLONASS satellites in view GLONASS fixes only) <u>Bit 7</u> – GNGLSA (1. GPS/2. Glonass/3. GALILE DOP and Active Satellites.) <u>Bit 8</u> – GNGLNS (fix data for GNSS receivers;output for GPS, GLONASS, GALILEO) <u>Bit 9</u> – Reserved <u>Bit 10</u> – GAGSV (GALILEO satellites in view) <u>Bit 11</u> –Reserved <u>Bit 12</u> –Reserved <u>Bit 13</u> –Reserved <u>Bit 14</u> –Reserved <u>Bit 15</u> –Reserved, <u>Bit 16</u> –BDGLSA/PQGLSA (BEIDOU/QZSS DOP and active satellites) <u>Bit 17</u> –BDGLSV/PQGLSV (BEIDOUQZSS satellites in view) <p>Set the desired NMEA sentence bit(s). If multiple NMEA sentence formats are desired, “OR” the desired bits together.</p> |
|---------------------|--|

NOTE: Reserved default 0, set invalid.

Example

```
AT+CGPSNMEA=200191
```

```
OK
```

NOTE

- If nmea bit 2 GPGSV doesn't configure, GPGSV sentence also doesn't output on AT/modem port even set AT+CGPSFTM=1.
- Module should reboot to take effect.

17.2.9 AT+CGPSNMEARATE Set NMEA output rate

AT+CGPSNMEARATE Set NMEA output rate

| | |
|--|--|
| Test Command AT+CGPSNMEARATE=? | Response +CGPSNMEARATE: (list of supported<rate>) OK |
| Read Command AT+CGPSNMEARATE? | Response +CGPSNMEARATE: <rate> OK |
| Write Command AT+CGPSNMEA=<rate> | Response OK or ERROR |

Defined Values

| | | |
|--------|---|------------------|
| <rate> | 0 | output rate 1HZ |
| | 1 | output rate 10HZ |

Example

```
AT+CGPSNMEARATE=1
```

```
OK
```

17.2.10 AT+CGPSMD Configure AGPS MO method

| AT+CGPSMD Configure AGPS MO method | |
|--|---|
| Test Command AT+CGPSMD=? | Response +CGPSMD: (scope of<method>) OK |
| Read Command AT+CGPSMD? | Response +CGPSMD: <method> OK |
| Write Command AT+CGPSMD=<method> | Response OK or <i>If GPS engine is running:</i> ERROR |

Defined Values

| | |
|-----------------------|-------------------------------------|
| <method> | 0 – Control plane 1 – User plane |
|-----------------------|-------------------------------------|

Example

```
AT+CGPSMD=1  
OK
```

17.2.11 AT+CGPSFTM Start GPS test mode

| AT+CGPSFTM Start GPS test mode | |
|---|--|
| Test Command AT+CGPSFTM=? | Response OK |
| Read Command AT+CGPSFTM? | Response +CGPSFTM: <on/off> OK |
| Write Command AT+CGPSFTM=<on/off> | Response OK or ERROR |

Defined Values

| | |
|------------|---|
| <on/off> | <u>0</u> – Close test mode 1 – Start test mode |
| <CNo> | Satellite CNo value. Floating value. |
| URC format | \$GPGSV[,<SV>,<CNo>][...] \$GLGSV[,<SV>,<CNo>][...] \$BDGSV[,<SV>,<CNo>][...] \$GAGSV[,<SV>,<CNo>][...] \$PQGSV[,<SV>,<CNo>][...] |

Example

```
AT+CGPSFTM=1
```

```
OK
```

```
$GLGSV,78,20.6,66,25.6,77,21.6,79,21.9,67,26.2,68,23.6
```

```
$GPGSV,10,36.3,12,33.5,14,26.5,15,27.0,18,30.6,20,29.4,21,14.9,  
24,32.8,25,30.6,31,29.1,32,27.0
```

```
$BDGSV,201,28.7,204,29.0,206,27.3,207,25.9,209,25.0,210,18.5
```

NOTE

- If test mode starts, the URC will report on AT port, Modem port and UART port.
- If testing on actual signal, <SV> should be ignored, and GPS must be started by AT+CGPS, AT+CGPSCOLD or AT+CGPSHOT.
- If testing on GPS signal simulate equipment, <SV> must be choiced, and GPS will start automatically.
- URC sentence will report every 1 second.

17.2.12 AT+CGPSDEL Delete the GPS information

AT+CGPSDEL Delete the GPS infomation

| | |
|--------------|----------|
| Test Command | Response |
|--------------|----------|

| | |
|---------------------|-----------|
| AT+CGPSDEL=? | OK |
|---------------------|-----------|

| | |
|-------------------|----------|
| Execution Command | Response |
|-------------------|----------|

| | |
|-------------------|-----------|
| AT+CGPSDEL | OK |
|-------------------|-----------|

Example

AT+CGPSDEL=?

OK

AT+CGPSDEL

OK

NOTE

- This command must be executed after GPS stopped

17.2.13 AT+CGPSXE Enable/Disable GPS XTRA function

AT+CGPSXE Enable/Disable GPS XTRA function

| Test Command | Response |
|--|---|
| AT+CGPSXE=? | Response +CGPSXE: (list of supported<on/off>s) OK |
| Read Command AT+CGPSXE? | Response +CGPSXE: <on/off> OK |
| Write Command AT+CGPSXE=<on/off> | Response OK or ERROR |

Defined Values

| | |
|-----------------------|-----------------------------|
| <on/off> | <u>0</u> – Disable GPS XTRA |
| | 1 – Enable GPS XTRA |

Example

AT+CGPSXE=?
+CGPSXE: (0-1)

OK
AT+CGPSXE=0
OK

NOTE

- XTRA function must download the assistant file from network by HTTP, so the APN must be set by AT+CGDCONT command.

17.2.14 AT+CGPSXD Download XTRA assistant file

| AT+CGPSXD Download XTRA assistant file | |
|--|---|
| Test Command AT+CGPSXD=? | Response +CGPSXD: (list of supported<server>) OK |
| Read Command AT+CGPSXD? | Response +CGPSXD: <server> OK |
| Write Command AT+CGPSXD=<server> | Response OK +CGPSXD : <resp> or +CGPSXD : <resp> ERROR |

Defined Values

| | |
|----------|---|
| <server> | 0 – XTRA primary server (precedence) 1 – XTRA secondary server 2 – XTRA tertiary server |
| <resp> | refer to Unsolicited XTRA download Codes |

Example

```

AT+CGPSXD=?
+CGPSXD: (0-2)

OK
AT+CGPSXD=0
OK
+CGPSXD: 0
  
```

17.2.15 AT+CGPSXDAUTO Download XTRA assistant file automatically

| AT+CGPSXDAUTO Download XTRA assistant file automatically | |
|--|--|
| Test Command AT+CGPSXDAUTO=? | Response +CGPSXDAUTO: (list of supported<on/off>) OK |
| Read Command AT+CGPSXDAUTO? | Response +CGPSXDAUTO: <on/off> OK |
| Write Command AT+CGPSXDAUTO=<on/off> | Response OK Or ERROR |

Defined Values

| | |
|----------|------------------------------------|
| <on/off> | 0 – disable download automatically |
| | 1 – enable download automatically |

Example

```
AT+CGPSXDAUTO=?
+CGPSXD: (0,1)

OK
AT+CGPSXDAUTO=0
OK
```

NOTE

- Some URCs will report when downloading, it's same as AT+CGPSXD command.

17.2.16 AT+CGPSINFOCFG Download Report GPS NMEA-0183 sentence

| AT+CGPSINFOCFG Download Report GPS NMEA-0183 sentence | |
|---|--|
| Test Command AT+CGPSINFOCFG=? | Response +CGPSINFOCFG: (scope of <time>),(scope of <config>) |

| | |
|--|--|
| Read Command AT+CGPSINFOCFG? | OK Response +CGPSINFOCFG: <time>,<config> |
| Write Command AT+CGPSINFOCFG=<time>[,<config>] | OK Response OK (NMEA-0183 Sentence) OK(if<time>=0>) |

Defined Values

| | |
|-----------------------|--|
| <time> | The range is 0-255, unit is second, after set <time> will report the GPS NMEA sentence every the seconds. If <time>=0 , module stop reporting the NMEA sentence. |
| <config> | Range – 0 to 262143 Each bit enables an NMEA sentence output as follows: <u>Bit 0</u> – GPGGA (global positioning system fix data) <u>Bit 1</u> – GPRMC (recommended minimum specific GPS/TRANSIT data) <u>Bit 2</u> – GPGSV (GPS satellites in view) <u>Bit 3</u> – GPGSA (GPS DOP and active satellites) <u>Bit 4</u> – GPVTG (track made good and ground speed) <u>Bit 5</u> – PQXFI (Global Positioning System Extended Fix Data.) <u>Bit 6</u> – GLGSV (GLONASS satellites in view GLONASS fixes only) <u>Bit 7</u> – GNGSA (1. GPS/2. Glonass/3. GALILE DOP and Active Satellites.) <u>Bit 8</u> – GNGNS (fix data for GNSS receivers;output for GPS,GLONASS,GALILEO) <u>Bit 9</u> – Reserved <u>Bit 10</u> – GAGSV (GALILEO satellites in view) <u>Bit 11</u> –Reserved <u>Bit 12</u> –Reserved <u>Bit 13</u> –Reserved <u>Bit 14</u> –Reserved <u>Bit 15</u> –Reserved, <u>Bit 16</u> –BDGSA/PQGSA (BEIDOU/QZSS DOP and active satellites) <u>Bit 17</u> –BDGSV/PQGSV (BEIDOUQZSS satellites in view) Set the desired NMEA sentence bit(s). If multiple NMEA sentence formats are desired, “OR” the desired bits together. Reserved default 0, set invalid. |

Example

AT+CGPSINFOCFG=?

+CGPSINFO: (0-255),(0-262143)

OK

AT+CGPSINFOCFG=10,31

OK

\$GPGSV,4,1,16,04,53,057,44,02,55,334,44,10,61,023,44,05,45,253,43*7D

\$GPGSV,4,2,16,25,10,300,40,17,25,147,40,12,22,271,38,13,28,053,38*77

\$GPGSV,4,3,16,26,09,187,35,23,06,036,34,24,,,,,27,,, *7A

\$GPGSV,4,4,16,09,,,,,31,,,,,30,,,,,29,,, *7D

\$GPGGA,051147.0,3113.320991,N,12121.248076,E,1,10,0.8,47.5,M,0,M,, *45

\$GPVTG,NaN,T,,M,0.0,N,0.0,K,A*42

\$GPRMC,051147.0,A,3113.320991,N,12121.248076,E,0.0,0.0,211211,,,A*66

\$GPGSA,A,3,02,04,05,10,12,13,17,23,25,26,,,1.4,0.8,1.2*3B

17.2.17 AT+CGPSPMD Configure positioning mode

AT+CGPSPMD Configure positioning mode

| Test Command | Response |
|--|---|
| AT+CGPSPMD=? | +CGPSPMD: (scope of <mode>) OK |
| Read Command AT+CGPSPMD? | Response +CGPSPMD: <mode> OK |
| Write Command AT+CGPSPMD =<mode> | Response OK or ERROR |

Defined Values

| | |
|--------|---|
| <mode> | Default - 65407 Range - 1 to 65407 Each bit enables a supported positioning mode as follows: Bit 0 – Standalone Bit 1 – UP MS-based |
|--------|---|

Bit 2 – UP MS-assisted
 Bit 3 – CP MS-based (2G)
 Bit 4 – CP MS-assisted (2G)
 Bit 5 – CP UE-based (3G)
 Bit 6 – CP UE-assisted (3G)
 Bit 7 – NOT USED
 Bit 8 – UP MS-based (4G)
 Bit 9 – UP MS-assisted(4G)
 Bit 10 – CP MS-based (4G)
 Bit 11 – CP MS-assisted (4G)

Set the desired mode sentence bit(s). If multiple modes are desired, “OR” the desired bits together.
 Example, support standalone, UP MS-based and UP MS-assisted, set Binary value 0000 0111, is 7.

Example

```
AT+CGPSPMD=127
OK
```

NOTE

- Need to restart the module after setting the mode.

17.2.18 AT+CGPSMSB Configure based mode switch to standalone

AT+CGPSMSB Configure based mode switch to standalone

| | |
|--|---|
| Test Command AT+CGPSMSB=? | Response +CGPSMSB: (scope of <mode>) OK |
| Read Command AT+CGPSMSB? | Response +CGPSMSB: <mode> OK |
| Write Command AT+CGPSMSB =<mode> | Response OK or ERROR |

Defined Values

| | |
|---------------------|---|
| <mode> | 0 – Don't switch to standalone mode automatically |
| | 1 – Switch to standalone mode automatically |

Example

```
AT+CGPSMSB=0
OK
```

NOTE

- This command must be executed after GPS stopped.

17.2.19 AT+CGPSHOR Configure positioning desired accuracy

AT+CGPSHOR Configure positioning desired accuracy

| Test Command | Response |
|---|---|
| AT+CGPSHOR=? | +CGPSHOR: (scope of <acc>),(scope of <acc_f>) OK |
| Read Command AT+CGPSHOR? | +CGPSHOR: <acc>,<acc_f> OK |
| Write Command AT+CGPSHOR=<acc>,[,<acc_f>] | OK or ERROR |

Defined Values

| | |
|----------------------|---|
| <acc> | Range – 0 to 1800000 Default value is 50 |
| <acc_f> | Reserved |

Example

```
AT+CGPSHOR=50
OK
```

NOTE

- This command must be executed after GPS stopped.

17.2.20 AT+CGPSNOTIFY LCS respond positioning request

AT+CGPSNOTIFY LCS respond positioning request

| | |
|--|--|
| Test Command AT+CGPSNOTIFY=? | Response +CGPSNOTIFY: (list of supported <resp>s) OK |
| Write Command AT+CGPSNOTIFY=<resp> | Response OK or ERROR |

Defined Values

| | |
|---------------------|---|
| <resp> | 0 – LCS notify verify accept 1 – LCS notify verify deny 2 – LCS notify verify no response |
|---------------------|---|

Example

```

AT+CGPSNOTIFY=?
+CGPSNOTIFY: (0-2)

OK
AT+CGPSNOTIFY=0
OK
  
```

17.2.21 AT+CGNSSINFO LCS Get GNSS fixed position information

AT+CGNSSINFO Get GNSS fixed position information

| | |
|---------------------------------------|---|
| Test Command AT+CGNSSINFO=? | Response +CGNSSINFO: (scope of <time>) OK |
| Read Command AT+CGNSSINFO? | Response +CGNSSINFO: <time> |

| | |
|---|---|
| Write Command AT+CGNSSINFO=<time> | <p>OK</p> <p>Response</p> <p>OK</p> <p>+CGNSSINFO:</p> <p>[<mode>],[<GPS-SVs>],[<GLONASS-SVs>],[<BEIDOU-SVs>], [<lat>],[<N/S>],[<log>],[<E/W>],[<date>],[<UTC-time>],[<alt>], [<speed>],[<course>],[<PDOP>],[<HDOP>],[<VDOP>]</p> <p>OK (if <time>=>0)</p> |
| Execution Command AT+CGNSSINFO | <p>Response</p> <p>+CGNSSINFO:</p> <p>[<mode>],[<GPS-SVs>],[<GLONASS-SVs>],[<BEIDOU-SVs>], [<lat>],[<N/S>],[<log>],[<E/W>],[<date>],[<UTC-time>],[<alt>], [<speed>],[<course>],[<PDOP>],[<HDOP>],[<VDOP>]</p> <p>OK</p> |

Defined Values

| | |
|---------------|--|
| <mode> | Fix mode 2=2D fix 3=3D fix |
| <GPS-SVs> | GPS satellite valid numbers scope: 00-12 |
| <GLONASS-SVs> | GLONASS satellite valid numbers scope: 00-12 |
| <BEIDOU-SVs> | BEIDOU satellite valid numbers scope: 00-12 |
| <lat> | Latitude of current position. Output format is ddmm.mmmmmm |
| <N/S> | N/S Indicator, N=north or S=south |
| <log> | Longitude of current position. Output format is dddmm.mmmmmm |
| <E/W> | E/W Indicator, E=east or W=west |
| <date> | Date. Output format is ddmmyy |
| <UTC-time> | UTC Time. Output format is hhmmss.s |
| <alt> | MSL Altitude. Unit is meters. |
| <speed> | Speed Over Ground. Unit is knots. |
| <course> | Course. Degrees. |
| <PDOP> | Position Dilution Of Precision. |
| <HDOP> | Horizontal Dilution Of Precision. |
| <VDOP> | Vertical Dilution Of Precision. |

Example

```

AT+CGNSSINFO=?
+CGNSSINFO: (0-255)

OK
AT+CGNSSINFO?
+CGNSSINFO: 0

```

```

OK
AT+CGNSSINFO
+CGNSSINFO:
2,09,05,00,3113.330650,N,12121.262554,E,131117,091918.0,32.9,
0.0,255.0,1.1,0.8,0.7
OK
AT+CGNSSINFO (if not fix,will report null)
+CGNSSINFO: ,,,"
OK

```

17.2.22 AT+CGNSSMODE LCS Configure GNSS support mode

AT+CGNSSMODE Configure GNSS support mode

| Test Command | Response |
|---|--|
| AT+CGNSSMODE=? | +CGNSSMODE: (scope of <gnss_mode>),(scope of <dpo_mode>) OK |
| Read Command AT+CGNSSMODE? | Response +CGNSSMODE: <gnss_mode>,<dpo_mode> OK |
| Write Command AT+CGNSSMODE=<gnss_mode>[,<dpo_mode>] | Response OK or ERROR |

Defined Values

| | |
|-------------|--|
| <gnss_mode> | Range – 0 to 15 Bit0: GLONASS Bit1: BEIDOU Bit2: GALILEO Bit3: QZSS 1: enable 0:disable GPS always support |
| <dpo_mode> | 1: enable DPO 0: disable DPO |

Example

```
AT+CGNSSMODE=15,1
```

OK

NOTE

- Module should reboot to take effective.

17.2.23 AT+CGPSIPV6 Set AGPS IPV6 Addr&Port

AT+CGPSIPV6 Set AGPS IPV6 Addr&Port

| Test Command | Response |
|---|---|
| AT+CGPSIPV6=? | OK |
| Read Command AT+CGPSIPV6? | Response +CGPSIPV6: <ipv6_addr>,<port> OK |
| Write Command AT+CGPSIPV6=<ipv6_addr> ,<port> | Response OK or ERROR |

Defined Values

| | |
|-------------|--|
| <ipv6_addr> | AGPS IPV6 addr. It needs double quotation marks. |
| <port> | AGPS IPV6 port. |

Example

```

AT+CGPSIPV6="2001:0268:1AFF:0000:0000:0000:B6F8:A5D2",7
275
OK

AT+CGPSIPV6?
+CGPSIPV6: "2001:0268:1AFF:0000:0000:0000:B6F8:A5D2",727
5

OK

```

NOTE

- It will take effect only after restarting.

17.2.24 AT+CGPSXTRADATA Query the validity of the current gpsOne XTRA Data

| AT+CGPSXTRADATA Query the validity of the current gpsOne XTRA Data | |
|--|---|
| Test Command AT+CGPSXTRADATA=? | Response OK |
| Read Command AT+CGPSXTRADATA? | Response +CGPSXTRADATA: <xtradatadurtime>,<injecteddatatime> OK |

Defined Values

| | |
|---------------------------------|---|
| <xtradatadurtime> | Valid time of injected gpsOneXTRA data,unit:minute 0 No gpsOneXTRA file or gpsOneXTRA file is overdue 1-10080 Valid time of gpsOneXTRA file |
| <injecteddatatime> | Starting time of the valid time of XTRA data, format: “YYYY/MM/DD,hh:mm:ss”,e.g. “2019/09/26,15:31:20” |

Example

```

AT+CGPSXTRADATA=?
OK

AT+CGPSXTRADATA?
+CGPSXTRADATA: 168,"2019/09/25,05:00:00"

OK

```

NOTE

- It needs to execute AT+CGPSXE to enable before execute the AT+CGPSXTRADATA read.

18. AT Commands for LBS

18.1 Overview of AT Commands for LBS

| Command | Description |
|------------|---------------------------------|
| AT+CLBS | Base station Location |
| AT+CLBSCFG | Base station Location configure |

18.2 Detailed Description of AT Commands for LBS

18.3 AT Commands for Open/Close Network

18.3.1 Overview of AT Commands for Open/Close Network

| Command | Description |
|---------------|---------------------|
| AT+CNETSTART | Open network |
| AT+CNETSTOP | Close network |
| AT+CNETIPADDR | Inquire PDP address |

18.3.2 Detailed Description of AT Commands for Open/Close Network

18.3.2.1 AT+CNETSTART Open network

| AT+CNETSTART Open network | |
|--|--|
| Read Command AT+CNETSTART? | Response +CNETSTART: <net_stat> OK or ERROR |
| Execution Command AT+CNETSTART | Response OK +CNETSTART: <err> or +CNETSTART: <err> OK or +CNETSTART: <err> ERROR or ERROR |

Defined Values

| | |
|--------------------------|---|
| <net_state> | a numeric parameter that indicates the state of PDP context activation: 0 network close (deactivated) 1 network is opening 2 network open(activated) 3 network is closing |
| <err> | The result of operation, 0 is success, other value is failure. |

Example

```

AT+CNETSTART?
+CNETSTART: 0

OK
AT+CNETSTART
OK

+CNETSTART: 0
  
```

18.3.2.2 AT+CNETSTOP Close network

AT+CNETSTOP Close network

| Execution Command | Response |
|--------------------|-------------------------------|
| AT+CNETSTOP | OK |
| | +CNETSTOP: <err> |
| | or |
| | +CNETSTOP: <err> |
| | OK |
| | or |
| | +CNETSTOP: <err> |
| | ERROR |
| | or |
| | ERROR |

Defined Values

| | |
|--------------------|--|
| <err> | The result of operation, 0 is success, other value is failure. |
|--------------------|--|

Example

```
AT+CNETSTOP
+CNETSTOP: 0

OK
```

18.3.2.3 AT+CNETIPADDR Inquire PDP address

AT+CNETIPADDR Inquire PDP address

| Read Command | Response |
|-----------------------|--|
| AT+CNETIPADDR? | +CNETIPADDR: <ip_address> |
| | OK |
| | or |
| | +CNETIPADDR: <err_info> |

ERROR
or
ERROR

Defined Values

| | |
|--------------|---|
| <ip_address> | A string parameter that identifies the IP address of current active socket PDP. |
| <err_info> | A string parameter that displays the cause of occurring error. |

Example

```
AT+CNETIPADDR?
+CNETIPADDR: 10.71.155.118

OK
```

18.3.3 Unsolicited Open/Close network command <err> Codes

| Code of <err> | Description |
|---------------|-------------------------|
| 0 | Operation succeeded |
| 1 | Unknown error |
| 2 | Open network failed |
| 3 | Close network failed |
| 4 | Network not opened |
| 5 | Operation not support |
| 6 | Busy |
| 7 | Network has been opened |
| 8 | Network is also in use |

18.3.3.1 AT+CLBS Base station Location

| AT+CLBS Base station Location | |
|----------------------------------|--|
| Test Command AT+CLBS=? | Response +CLBS: (list of supported <type>s),(range of supported <cid>s),(range of supported <longitude>s),(range of supported <latitude>s),(list of supported <lon_type>s) |

| | |
|--|---|
| Write Command AT+CLBS=<type>,<cid>,[[<longitude>,<latitude>],[<lon_type>]] | <p>OK</p> <p>Response</p> <p>1)<type>=1,get longitude and latitude +CLBS: <locationcode>[,<longitude>,<latitude>,<acc>]</p> <p>OK</p> <p>2)<type>=4,get longitude latitude and date time +CLBS: <locationcode>[,<longitude>,<latitude>,<acc>,<date>,<time>]</p> <p>OK</p> <p>If error is related to ME functionality: +CME ERROR: <err></p> |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-----------------------------|---|
| <type> | <p>1 Use 3 cell's information</p> <p>4 Get longitude latitude and date time</p> |
| <cid> | Bearer profile identifier, refer to <pdpidx> of AT+CNACT |
| <locationcode> | <p>0 Success</p> <p>If the operation failed, the location code is not 0, such as:</p> <p>1 Location Failed</p> <p>2 Time Out</p> <p>3 NET Error</p> <p>4 DNS Error</p> <p>5 Service Overdue</p> <p>6 Authenticate Failed</p> <p>7 Other Error</p> <p>80 Report LBS to server success</p> <p>81 Report LBS to server parameter error</p> <p>82 Report LBS to server failed</p> |
| <longitude> | <p>Current longitude in degrees.</p> <p>-180.000000-180.000000</p> |
| <latitude> | <p>Current latitude in degrees</p> <p>-90.000000-90.000000</p> |
| <acc> | Positioning accuracy |
| <lon_type> | <p>The type of longitude and latitude</p> <p>0 WGS84</p> <p>1 GCJ02</p> |
| <times> | Access service times |
| <date> | Service date |

| | |
|--------|--------------|
| <time> | Service time |
|--------|--------------|

Example

```
AT+CLBS=?
+CLBS:
(1,3,4,9),(0-3),(-180.000000-180.000000),(-90.0
00000-90.000000),(0,1)

OK
```

NOTE

- If customers feel that the positioning error is too large, <type>=9 can be used to report this information. The error can be improved by this information.

18.3.3.2 AT+CLBSCFG Base station Location configure

AT+CLBSCFG Base station Location configure

| | |
|---|---|
| Test Command AT+CLBSCFG=? | Response +CLBSCFG: (list of supported <operate>s),(range of supported <para>s),<len_value> OK |
| Write Command AT+CLBSCFG=<operate>,<para>[,<value>] | Response +CLBSCFG: 0,<para>,<value> OK or OK If error is related to ME functionality: +CME ERROR: <err> |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-----------|-----------------------------------|
| <operate> | 0 Read operator 1 Set operator |
|-----------|-----------------------------------|

| | |
|-------------|---|
| <para> | <ol style="list-style-type: none"> 1 Customer ID 2 Times have used positioning command 3 Server's address <ul style="list-style-type: none"> lbs-simcom.com:3001 lbs-simcom.com:3000 lbs-simcom.com:3002 (Default) |
| <value> | <p>String type. The value of parameter</p> <p>If <operate> is 1 and <para> is 3, <value> can be set.</p> |
| <len_value> | Max length of <value> |

Example

AT+CLBSCFG?

+CLBSCFG: (0-1),3,"Param Value"

OK

NOTE

- Server's address of "lbs-simcom.com:3002" is free. The other two servers are charged.
- If you want to use the charged address, the IMEI, customer information and software version must be provided to SIMCom.

19. AT Commands for Hardware

19.1 Overview of AT Commands for Hardware Related

| Command | Description |
|-------------|---|
| AT+CVALARM | Low and high voltage Alarm |
| AT+CVAUXS | Set state of the pin named VREG_AUX1 |
| AT+CVAUXV | Set voltage value of the pin named VREG_AUX1 |
| AT+CADC | Read ADC value |
| AT+CADC2 | Read ADC2 value |
| AT+CMTE | Control the module whether power shutdown when the module's temperature upon the critical temperature |
| AT+CPMVT | Low and high voltage Power Off |
| AT+CDELTA | Set the module go to recovery mode |
| AT+CRIIC | Read values from register of IIC device |
| AT+CWIIIC | Write values to register of IIC device |
| AT+CBC | Read the voltage value of the power supply |
| AT+CPMUTEMP | Read the temperature of the module |
| AT+CFDISK | SD Card/EMMC Flash |

19.2 Detailed Description of AT Commands for Hardware Related

| Command | Description |
|------------|---|
| AT+CVALARM | Low and high voltage Alarm |
| AT+CVAUXS | Set state of the pin named VREG_AUX1 |
| AT+CVAUXV | Set voltage value of the pin named VREG_AUX1 |
| AT+CADC | Read ADC value |
| AT+CADC2 | Read ADC2 value |
| AT+CMTE | Control the module whether power shutdown when the module's temperature upon the critical temperature |
| AT+CPMVT | Low and high voltage Power Off |
| AT+CDELTA | Set the module go to recovery mode |
| AT+CRIIC | Read values from register of IIC device |

| | |
|-------------|--|
| AT+CWIC | Write values to register of IIC device |
| AT+CBC | Read the voltage value of the power supply |
| AT+CPMUTEMP | Read the temperature of the module |
| AT+CFDISK | SD Card/EMMC Flash |

19.2.1 AT+CVALARM Low and high voltage Alarm

| AT+CVALARM Low and high voltage Alarm | |
|--|---|
| Test Command AT+CVALARM=? | Response +CVALARM: (list of supported <enable>s), (list of supported <low voltage>s), (list of supported high <high voltage>s) OK |
| Read Command AT+CVALARM? | Response +CVALARM: <enable>,<low voltage>,<high voltage> OK |
| Write Command AT+CVALARM=<enable>[,<low voltage>],[<high voltage>] | Response OK or ERROR |

Defined Values

| | |
|-----------------------------|--|
| <enable> | 0: Close 1: Open. If voltage < <low voltage>, it will report "UNDER-VOLTAGE WARNING" every 10s. If voltage > <high voltage>, it will report "OVER-VOLTAGE WARNING" every 10s. |
| <low voltage> | Between 3300mV and 4000mV. Default value is 3300. |
| <high voltage> | Between 4000mV and 4300mV. Default value is 4300. |

Example

```
AT+CVALARM?
+CVALARM: 1,3400,4300
OK
```

```
AT+CVALARM=?
+CVALARM: (0,1),(3300-4000),(4000-4300)
OK
```

```
AT+CVALARM=1,3400,4300
```

OK

19.2.2 AT+CVAUXS Set state of the pin named VREG_AUX1

AT+CVAUXS Set state of the pin named VREG_AUX1

| | |
|---|---|
| Test Command AT+CVAUXS=? | Response +CVAUXS: (list of supported <state>s) OK |
| Read Command AT+CVAUXS? | Response +CVAUXS: <state> OK |
| Write Command AT+CVAUXS=<state> | Response OK Or ERROR |

Defined Values

| | |
|---------|--|
| <state> | 0: the pin is closed. 1: the pin is open(namely, open the pin). |
|---------|--|

Example

AT+CVAUXS?

+CVAUXS: 1

OK

AT+CVAUXS =1

OK

NOTE

- For SIM7600E-H-M2/SIM7600SA-H-M2/SIM7600A-H-M2, the default value is 0.

19.2.3 AT+CVAUXV Set voltage value of the pin named VREG_AUX1

AT+CVAUXV Set voltage value of the pin named VREG_AUX1

| | |
|---|---|
| Test Command AT+CVAUXV=? | Response +CVAUXV: (list of supported <voltage>s) OK |
| Read Command AT+CVAUXV? | Response +CVAUXV: <voltage> OK |
| Write Command AT+CVAUXV=<voltage> | Response OK or ERROR |

Defined Values

| | |
|------------------------|---|
| <voltage> | Voltage value of the pin which is named VREG_AUX1. The unit is in mV. And the value must be the multiple of 50mV. |
|------------------------|---|

Example

```
AT+CVAUXV =?
+CVAUXV: (1700-3050)
OK
```

```
AT+CVAUXV =2800
OK
```

```
AT+CVAUXV?
+CVAUXV: 2800
OK
```

19.2.4 AT+CADC Read ADC value

AT+CADC Read ADC value

| | |
|---|--|
| Test Command AT+CADC=? | Response +CADC: (range of supported <adc>s) OK |
| Write Command AT+CADC=<adc> | Response +CADC: <value> |

OK
or
ERROR

Defined Values

| | |
|----------------------|--|
| <adc> | ADC type: 0 – raw type. 2 – voltage type(mv) |
| <value> | Integer type value of the ADC. |

Example

AT+CADC=?

+CADC: (0,2)

OK

AT+CADC =0

+CADC: 187

OK

19.2.5 AT+CADC2 Read ADC2 value

AT+CADC2 Read ADC2 value

Test Command

AT+CADC2=?

Response

+CADC2: (range of supported <adc>s)

OK

Write Command

AT+CADC2=<adc>

Response

+CADC2: <value>

OK

or

ERROR

Defined Values

| | |
|----------------------|---|
| <adc> | ADC2 type: 0 – raw type. 2 – voltage type(mv) |
| <value> | Integer type value of the ADC2. |

Example

AT+CADC2=?

+CADC2: (0,2)

OK

AT+CADC2=0

+CADC2: 187

OK

19.2.6 AT+CMTE Control the module whether power shutdown when the module's temperature upon the critical temperature

AT+CMTE Control the module whether power shutdown when the module's temperature upon the critical temperature

Test Command

AT+CMTE=?

Response

+CMTE: (list of supported<on/off>s)

OK

Read Command

AT+CMTE?

Response

+CMTE: <on/off >

OK

Write Command

AT+CMTE=<on/off >

Response

OK

or

ERROR

Defined Values

<on/off>

0 – Disable temperature detection

1 – Enable temperature detection

Example

AT+CMTE?

+CMTE: 1

OK

AT+CMTE =1

OK

AT+CMTE=?

+CMTE: (0/1)

OK

NOTE

- When temperature is extreme high or low, product will power off.
- URCs indicating the alert level "+CMTE:-1" or "+CMTE:1" are intended to enable the user to take appropriate precaution, such as protect the module from exposure to extreme conditions, or save or back up data etc
- Level "+CMTE:-2" or "+CMTE:2" URCs are followed by immediate shutdown.

19.2.7 AT+CPMVT Low and high voltage Power Off

AT+CPMVT Low and high voltage Power Off

Test Command

AT+CPMVT=?

Response

+CPMVT: (list of supported <enable>s), (list of supported <low voltage>s), (list of supported <high voltage>s)

OK

Read Command

AT+CPMVT?

Response

+CPMVT: <enable>, <low voltage>, <high voltage>

OK

Write Command

AT+CPMVT=<enable>[,<low voltage>],[<high voltage>]

Response

OK

Or

ERROR

Defined Values

<enable>

0: Close

1: Open. If voltage < <low voltage>, it will report "UNDER-VOLTAGE WARNING POWER DOWN" and power off the module. If voltage > <high voltage>, it will report "OVER-VOLTAGE WARNING POWER DOWN" and power off the module

<low voltage>

Between 3200mV and 4000mV. Default value is 3200.

<high voltage>

Between 4000mV and 4300mV. Default value is 4300.

Example

AT+CPMVT=1,3400,4300

OK

AT+CPMVT?

+CVALARM: 1,3400,4300

OK

AT+CPMVT=?

+CVALARM: (0,1),(3300-4000),(4000-4300)

OK

19.2.8 AT+CDELTA Set the module go to recovery mode

AT+CDELTA Set the module go to recovery mode

Write Command

AT+CDELTA

Response

OK

or

ERROR

Example

AT+CDELTA

OK

NOTE

- the command will write flag to the module and reboot the module, then the module will reboot and read the flag and enter recovery mode to update the firmware.

19.2.9 AT+CRIIC Read values from register of IIC device

AT+CRIIC Read values from register of IIC device

Test Command

AT+CRIIC=?

Response

OK

Write Command

AT+CRIIC=<addr>,<reg>,<len>

Response

+CRIIC: <data>

OK

or
ERROR

Defined Values

| | |
|--------|---|
| <addr> | Device address. Input format must be hex, such as 0xFF. |
| <reg> | Register address. Input format must be hex, such as 0xFF. |
| <len> | Read length. Range:1-4; unit:byte. |
| <data> | Data read. Input format must be hex, such as 0xFF. |

Example

```
AT+CR1IC=0x34, 0x02, 2
```

```
+CR1IC: 0x01,0x5d
```

```
OK
```

19.2.10 AT+CW1IC Write values to register of IIC device

AT+CW1IC Write values to register of IIC device

| | |
|---|---|
| Test Command AT+CW1IC=? | Response OK |
| Write Command AT+CW1IC=<addr>,<reg>,<d ata>,<len> | Response OK or ERROR |

Defined Values

| | |
|--------|--|
| <addr> | Device address. Input format must be hex, such as 0xFF. |
| <reg> | Register address. Input format must be hex, such as 0xFF. |
| <len> | Read length. Range: 1-4; unit: byte. |
| <data> | Data written. Input format must be hex, such as 0xFF – 0xFFFFFFFF. |

Example

```
AT+CW1IC=0x34, 0x03, 0x5d, 1
```

```
OK
```

19.2.11 AT+CBC Read the voltage value of the power supply

AT+CBC Read the voltage value of the power supply

| Read Command | Response |
|---------------|---|
| AT+CBC | +CBC: <vol> OK or ERROR |

Defined Values

| | |
|-------|---------------------------------|
| <vol> | The voltage value, such as 3.8. |
|-------|---------------------------------|

Example

```
AT+CBC
+CBC: 3.591V
OK
```

19.2.12 AT+CPMUTEMP Read the temperature of the module

AT+CPMUTEMP Read the temperature of the module

| Read Command | Response |
|--------------------|---|
| AT+CPMUTEMP | +CPMUTEMP: <temp> OK or ERROR |

Defined Values

| | |
|--------|------------------------------------|
| <temp> | The Temperature value, such as 29. |
|--------|------------------------------------|

Example

```
AT+CPMUTEMP
+CPMUTEMP: 29
OK
```

19.2.13 AT+CFDISK SD Card/EMMC Flash

| AT+CFDISK SD Card/EMMC Flash | |
|--|---|
| Test Command AT+CFDISK=? | Response +CFDISK: (1-4)[...] OK or ERROR |
| Read Command AT+CFDISK? | Response +CFDISK: <num>,<size> OK or ERROR |
| Write Command AT+CFDISK=<num>,<size>,<size>,<size> | Response OK or ERROR |
| Write Command (Formatting all partitions) AT+CFDISK | Response OK or ERROR |

Defined Values

| | |
|-------|-------------------------------|
| <num> | Partition size.The unit is KB |
|-------|-------------------------------|

Example

```
AT+CFDISK=?
+CFDISK: (1-4)[...]
OK
```

```
AT+CFDISK=4,50000,50000,50000
OK
```

```
AT+CFDISK
OK
```

```
AT+CFDISK?
+CFDISK: 1,50040
+CFDISK: 2,50048
+CFDISK: 3,50048
+CFDISK: 4,3708288
```

OK

NOTE

- The last partition size does not need to be set. The size of the last partition is the size of the disk remaining.

SIMCom
Confidential

20. AT Commands for File System

The file system is used to store files in a hierarchical (tree) structure, and there are some definitions and conventions to use the Module.

Local storage space is mapped to “C:”, “D:” for TF card, “E:” for multimedia, “F:” for cache.

NOTE

General rules for naming (both directories and files):

- ✧ The length of actual fully qualified names of directories and files can not exceed 254.
- ✧ Directory and file names can not include the following characters: \ : * ? “ < > | , ;
- ✧ Between directory name and file/directory name, use character “/” as list separator, so it can not appear in directory name or file name.
- ✧ The first character of names must be a letter or a numeral or underline, and the last character can not be period “.” and oblique “/”.
- ✧ 7600M1+1 can not support “D:”and “E:”, if all the following AT are executed, “ERROR” will be returned.

20.1 Overview of AT Commands for File System

| Command | Description |
|-------------|---|
| AT+FSCD | Select directory as current directory |
| AT+FSMKDIR | Make new directory in current directory |
| AT+FSRMDIR | Delete directory in current directory |
| AT+FSLS | List directories/files in current directory |
| AT+FSDEL | Delete file in current directory |
| AT+FSRENAME | Rename file in current directory |
| AT+FSATTRI | Request file attributes |
| AT+FSMEM | Check the size of available memory |
| AT+FSLOCA | Select storage place |
| AT+FSCOPY | Copy an appointed file |
| AT+CFTRANRX | Transfer a file to EFS |
| AT+CFTRANTX | Transfer a file from EFS to host |

20.2 Detailed Description of AT Commands for File System

20.2.1 AT+FSCD Select directory as current directory

This command is used to select a directory. The Module supports absolute path and relative path. Read Command will return current directory without double quotation marks. Support "C:", "D:", "E:", "F:".

| AT+FSCD Select directory as current directory | |
|---|--|
| Test Command AT+FSCD=? | Response OK |
| Read Command AT+FSCD? | Response +FSCD: <curr_path> |
| Write Command AT+FSCD=<path> | Response +FSCD: <curr_path> OK or ERROR |

Defined Values

| | |
|--------------------------|--|
| <path> | String without double quotes, directory for selection. |
| <curr_path> | String without double quotes, current directory. |

NOTE

If **<path>** is ".", it will go back to previous level of directory.

Example

```
AT+FSCD=C:
+FSCD: C:/

OK
AT+FSCD=C:/
+FSCD: C:/
```

```

OK
AT+FSCD?
+FSCD: C:/

OK
AT+FSCD=..
+FSCD: C:/

OK
AT+FSCD=D:
+FSCD: D:/

OK
AT+FSCD?
+FSCD: D:/

OK

```

20.2.2 AT+FSMKDIR Make new directory in current directory

This command is used to create a new directory in current directory. Support "C:", "D:", "E:", "F:".

AT+FSMKDIR Make new directory in current directory

| Test Command | Response |
|--|---|
| AT+FSMKDIR=? | OK |
| Write Command AT+FSMKDIR=<dir> | Response OK or ERROR |

Defined Values

| | |
|--------------------|---|
| <dir> | String without double quotes, directory name which does not already exist in current directory. |
|--------------------|---|

Example

```

AT+FSMKDIR=SIMTech
OK
AT+FSCD?
+FSCD: E:/

```

| | |
|------------------------------|--|
| OK | |
| AT+FSLs | |
| +FSLs: SUBDIRECTORIES | |
| Audio | |
| SIMTech | |
| OK | |

20.2.3 AT+FSRMDIR Delete directory in current directory

This command is used to delete existing directory in current directory. Support "C:", "D:", "E:", "F:".

| AT+FSRMDIR Delete directory in current directory | |
|---|---|
| Test Command AT+FSRMDIR=? | Response OK |
| Write Command AT+FSRMDIR=<dir> | Response OK or ERROR |

Defined Values

| | |
|-------|-------------------------------|
| <dir> | String without double quotes. |
|-------|-------------------------------|

Example

| | |
|------------------------------|--|
| AT+FSRMDIR=SIMTech | |
| OK | |
| AT+FSCD? | |
| +FSCD: E:/ | |
| OK | |
| AT+FSLs | |
| +FSLs: SUBDIRECTORIES | |
| Audio | |
| OK | |

20.2.4 AT+FSL S List directories/files in current directory

This command is used to list information of directories and/or files in current directory. Support "C:", "D:", "E:", "F:".

| AT+FSL S List directories/files in current directory | |
|--|---|
| Test Command AT+FSL S=? | Response +FSL S: (list of supported <type>) OK |
| Read Command AT+FSL S? | Response +FSL S: SUBDIRECTORIES<dir_num>,FILES:<file_num> OK |
| Write Command AT+ FSL S=<type> | Response [+FSL S: SUBDIRECTORIES: <list of subdirectories> <CR><LF>] [+FSL S: FILES: <list of files> <CR><LF>] OK |
| Execution Command AT+ FSL S | Response [+FSL S: SUBDIRECTORIES: <list of subdirectories> <CR><LF>] [+FSL S: FILES: <list of files> <CR><LF>] OK |

Defined Values

| | |
|-------------------------|--|
| <dir_num> | Integer type, the number of subdirectories in current directory. |
| <file_num> | Integer type, the number of files in current directory. |
| <type> | <ul style="list-style-type: none"> <u>0</u> – list both subdirectories and files 1 – list subdirectories only 2 – list files only |

Example

```
AT+FSL S?
+FSL S: SUBDIRECTORIES:2,FILES:2
```

```
OK
AT+FSLs
+FSLs: SUBDIRECTORIES:
FirstDir
SecondDir
```

```
+FSLs: FILES:
image_0.jpg
image_1.jpg
```

```
OK
AT+FSLs=2
+FSLs: FILES:
image_0.jpg
image_1.jpg
```

```
OK
```

20.2.5 AT+FSDEL Delete file in current directory

This command is used to delete a file in current directory. Before do that, it needs to use AT+FSCD select the father directory as current directory. Support "C:", "D:", "E:", "F:".

AT+FSDEL Delete file in current directory

| Test Command | Response |
|----------------------------------|---------------------------------|
| AT+FSDEL=? | OK |
| Write Command | Response |
| AT+FSDEL=<filename> | OK or ERROR |

Defined Values

| | |
|-------------------------|---|
| <filename> | String with or without double quotes, file name which is relative and already existing. If <filename> is *.* , it means delete all files in current directory. If the file path contains non-ASCII characters, the filename parameter should contain a prefix of {non-ascii} and the quotation mark. |
|-------------------------|---|

Example

```
AT+FSDEL=image_0.jpg
OK
```

20.2.6 AT+FSRENAME Rename file in current directory

This command is used to rename a file in current directory. Support "C:", "D:", "E:", "F:".

AT+FSRENAME Rename file in current directory

| Test Command | Response |
|---|---------------------------------|
| AT+FSRENAME=? | OK |
| Write Command | Response |
| AT+FSRENAME=<old_name> >,<new_name> | OK or ERROR |

Defined Values

| | |
|-------------------------|---|
| <old_name> | String with or without double quotes, file name which is existed in current directory. If the file path contains non-ASCII characters, the file path parameter should contain a prefix of {non-ascii} and the quotation mark. |
| <new_name> | New name of specified file, string with or without double quotes. If the file path contains non-ASCII characters, the file path parameter should contain a prefix of {non-ascii} and the quotation mark. |

Example

```
AT+FSRENAME=image_0.jpg, image_1.jpg
OK
AT+FSRENAME="my {non-ascii}"E6B58BE8AF95E99984E4BBB62E6A7067" test.jpg",
OK
```

20.2.7 AT+FSATTRI Request file attributes

This command is used to request the attributes of file which exists in current directory. Support "C:", "D:", "E:", "F:".

AT+FSATTRI Request file attributes

| | |
|--|---|
| Test Command AT+FSATTRI=? | Response OK |
| Write Command AT+FSATTRI=<dir> | Response +FSATTRI: <file_size>,<create_date> OK or ERROR |

Defined Values

| | |
|----------------------------|---|
| <filename> | String with or without double quotes, file name which is in current directory. If the file path contains non-ASCII characters, the file path parameter should contain a prefix of {non-ascii} and the quotation mark. |
| <file_size> | The size of specified file, and the unit is in Byte. |
| <create_date> | Create date and time of specified file, the format is YYYY/MM/DD HH:MM:SS Week. Week – Mon, Tue, Wed, Thu, Fri, Sat, Sun |

Example

```
AT+FSATTRI=image_0.jpg
+FSATTRI: 8604, 2008/04/28 10:24:46 Tue

OK
AT+FSATTRI={non-ascii}"E6B58BE8AF95E99984E4BBB62E6A7067"
+FSATTRI: 6296, 2012/01/06 00:00:00 Sun

OK
```

20.2.8 AT+FSMEM Check the size of available memory

This command is used to check the size of available memory. The response will list total size and used size of local storage space if present and mounted. Support "C:", "D:", "E:", "F:".

| AT+FSMEM Check the size of available memory | |
|--|--|
| Test Command AT+FSMEM=? | Response OK |
| Write Command AT+FSMEM | Response +FSMEM: <loctype>:(<total>, <used>) |

OK

Defined Values

| | |
|-----------|---|
| <loctype> | Support "C:", "D:", "E:", "F:". |
| <total> | The total size of local storage space. The unit of storage space size is in Byte. |
| <used> | The used size of local storage space. The unit of storage space size is in Byte. |

Example

```
AT+FSMEM
+FSMEM: C:(11348480, 2201600)

OK
```

20.2.9 AT+FSLOCA Select storage place

This command is used to set the storage place for media files. Support "C:".

AT+FSLOCA Select storage place

| Test Command | Response |
|--|---|
| AT+FSLOCA=? | +FSLOCA: (list of supported <loca>s) OK |
| Read Command AT+FSLOCA? | +FSLOCA: <loca> OK |
| Write Command AT+FSLOCA=<loca> | Response OK or ERROR |

Defined Values

| | |
|--------|--|
| <loca> | 0 – store media files to local storage space (namely "C:") |
|--------|--|

Example

```
AT+FSLOCA=0

OK
```

AT+FSLOCA?

+FSLOCA: 0

OK

20.2.10 AT+FSCOPY Copy an appointed file

This command is used to copy an appointed file on C:/ to an appointed directory on C:/, the new file name should give in parameter. Support "C:", "D:", "E:", "F:", but copying from "C:" to "D:", "E:", "F:" or from "D:", "E:", "F:" to "C:" is not supported.

AT+FSCOPY Copy an appointed file

Test Command

AT+FSCOPY=?

Response

OK

Write Command

**AT+FSCOPY=<file1>,<file2>
[,<sync_mode>]**

Response

Sync mode

+FSCOPY: <percent><CR><LF>

[+FSCOPY: <percent><CR><LF>]

OK

Async mode

OK

+FSCOPY: <percent><CR><LF>

[+FSCOPY: <percent><CR><LF>]

+FSCOPY: END<CR><LF>

Or

When error, shows one of the following errors and ERROR

SD CARD NOT PLUGGED IN

FILE IS EXISTING

FILE NOT EXISTING

DIRECTORY IS EXISTED

DIRECTORY NOT EXISTED

FORBID CREATE DIRECTORY UNDER \"C:\"

FORBID DELETE DIRECTORY

INVALID PATH NAME

INVALID FILE NAME

SD CARD HAVE NO ENOUGH MEMORY

EFS HAVE NO ENOUGH MEMORY

FILE CREATE ERROR

READ FILE ERROR

WRITE FILE ERROR

ERROR

Defined Values

| | |
|--------------------------|---|
| <file1> | The sources file name or the whole path name with sources file name. If the file path contains non-ASCII characters, the file path parameter should contain a prefix of {non-ascii} and the quotation mark. |
| <file2> | The destination file name or the whole path name with destination file name. If the file path contains non-ASCII characters, the file path parameter should contain a prefix of {non-ascii} and the quotation mark. |
| <percent> | The percent of copy done. The range is 0.0 to 100.0 |
| <sync_mode> | The execution mode of the command: 0 – synchronous mode 1 – asynchronous mode |

NOTE

1. The **<file1>** and **<file2>** should give the whole path and name, if only given file name, it will refer to current path (**AT+FSCD**) and check the file's validity.
2. If **<file2>** is a whole path and name, make sure the directory exists, make sure that the file name does not exist or the file name is not the same name as the sub folder name, otherwise return error.
3. **<percent>** report refer to the copy file size. The big file maybe report many times, and little file report less.
4. If **<sync_mode>** is 1, the command will return **OK** immediately, and report final result with **+FSCOPY: END**.

Example

```

AT+FSCD?
+FSCD: C:/

OK
AT+FSCOPY= C:/TESTFILE,COPYFILE (Copy file TESTFILE on C:/ to C:/COPYFILE)
+FSCOPY: 1.0

+FSCOPY: 100.0

OK
AT+FSCOPY= "my test.jpg", {non-ascii}"E6B58BE8AF95E99984E4BBB62E6A7067"
+FSCOPY:1.0

```

+FSCOPY:100.0

OK

20.2.11 AT+CFTRANRX Transfer a file to EFS

This command is used to transfer a file to EFS.Support SDCard.

AT+CFTRANRX Transfer a file to EFS

| Test Command | Response |
|---|---|
| AT+CFTRANRX=? | +CFTRANRX: [{{non-ascii}}]"FILEPATH" OK |
| Write Command AT+CFTRANRX="<filepath> <len> | Response > OK or > ERROR or ERROR |

Defined Values

| | |
|-------------------------|---|
| <filepath> | The path of the file on EFS. |
| <len> | The length of the file data to send. The range is from 0 to 2147483647. |

NOTE

The **<filepath>** must be a full path with the directory path.

Example

AT+CFTRANRX="c:/MyDir/t1.txt",10

><input data here>

OK

AT+CFTRANRX="d:/MyDir/t1.txt",10

><input data here>

OK

20.2.12 AT+CFTRANTX Transfer a file from EFS to host

This command is used to transfer a file from EFS to host. Before using this command, the AT+CATR must be used to set the correct port used. Support SDCard.

AT+CFTRANTX Transfer a file from EFS to host

| Test Command | Response |
|--|--|
| AT+CFTRANTX=? | +CFTRANTX: [{{non-ascii}}]"FILEPATH" OK |
| Write Command AT+CFTRANTX =<filepath>",<location>,<size> | Response [+CFTRANTX: DATA,<len> ... +CFTRANTX: DATA,<len>] +CFTRANTX: 0 OK or ERROR |

Defined Values

| | |
|-------------------------|--|
| <filepath> | The path of the file on EFS. |
| <len> | The length of the following file data to output. |
| <location> | The beginning of the file data to output. |
| <size> | The length of the file data to output. |

NOTE

The **<filepath>** must be a full path with the directory path.

Example

```
AT+CFTRANTX="c:/MyDir/t1.txt"
OK
+CFTRANTX: DATA, 11
```

Testcontent

+CFTRANTX: 0

OK

AT+CFTRANTX="d:/MyDir/t1.txt",1,4

+CFTRANTX: DATA, 4

estc

+CFTRANTX: 0

OK

SIMCom
Confidential

21. AT Commands for AUDIO

21.1 Overview of AT Commands for AUDIO

| Command | Description |
|----------------|-----------------------------|
| AT+CREC | Record wav audio file |
| AT+CRECAMR | Record amr audio file |
| AT+CCMXPLAYWAV | Play wav audio file |
| AT+CCMXSTOPWAV | Stop playing wav audio file |
| AT+CCMXPLAY | Play audio file |
| AT+CCMXSTOP | Stop playing audio file |

21.2 Detailed Description of AT Commands for AUDIO

21.2.1 AT+CREC Record wav audio file

| AT+CREC Record wav audio file | |
|--|--|
| Read Command AT+CREC? | Response + CREC: <status> OK |
| Write Command AT+CREC=<record_path>,<filename> | Response +CREC:1 OK or ERROR |
| Write Command AT+CREC=<mode> | Response +CREC:0 OK +RECSTATE: crec stop |
| Parameter Saving Mode | - |
| Maximum Response Time | - |

Reference -

Defined Values

| | |
|---------------|--|
| <status> | Indicate whether the recording is going on. 0 – free, not recording 1 – busy, recording |
| <record_path> | Source of recorded sound 1 – local path 2 – remote path 3 – local and remote sound mixing |
| <filename> | The location and name of wav file. |
| <mode> | Stop recording wav audio file 0 –stop |

NOTE

- <filename>,The file should be put into the “E:/”. Maximum filename length is 240 bytes. (including “”)
- <record_path>,Only during the call, <record_path> can be set to 2 or 3

Example

```

AT+CREC=1,"e:/rec.wav"
+CREC:1

OK
AT+CREC=0
+CREC:0

OK

+RECSTATE: crec stop

```

21.2.2 AT+CRECAMR Record amr audio file

AT+CRECAMR Record amr audio file

| | |
|---|---|
| Read Command AT+CRECAMR? | Response +CRECAMR: <status> OK |
| Write Command AT+CRECAMR=<record_path>,<filename> | Response +CRECAMR:<status> OK or ERROR |
| Write Command AT+CRECAMR=<mode> | Response +CRECAMR:<status> OK +RECSTATE: crecamr stop |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|----------------------------|---|
| <status> | Indicate whether the recording is going on. 0 – free, not recording 1 – busy, recording |
| <record_path> | Source of recorded sound 1 – local path 2 – remote path |
| <filename> | The location and name of amr file. |
| <mode> | Stop recording wav audio file 0 –stop |

NOTE

- **<filename>**,The file should be put into the “E:”. Maximum filename length is 240 bytes. (including “”)
- **<record_path>**,Only during the call, **<record_path>** can be set to 2

Example

```
AT+CRECAMR=1,"e:/rec.amr"
+CRECAMR:1

OK
AT+CRECAMR=0
+CRECAMR:0
```

OK

+RECSTATE: crecamr stop

21.2.3 AT+CCMXPLAYWAV Play wav audio file

AT+CCMXPLAYWAV Play wav audio file

| | |
|--|--|
| Read Command AT+CCMXPLAYWAV? | Response +CCMXPLAYWAV:<play_path>,<repeat> OK |
| Write Command AT+CCMXPLAYWAV=<filename>,<play_path>[,<repeat>] | Response +WAVSTATE: wav play OK +WAVSTATE: wav play stop or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|--------------------------|--|
| <play_path> | Play to local or to remote. 1 – remote 2 – local |
| <repeat> | How much times can be played. Default 0 |
| <filename> | The location and name of wav file. |

NOTE

- **<filename>**,The wav audio file should be located at "E:". Maximum filename length is 240 bytes. (including "")
<play_path>,Only during the call, **<play_path>** can be set to 1 successfully.Only 8k 16bit wav audio can be played to remote successful at present.
<repeat>,This parameter is reserved, not used at present, you can input this parameter or not. (0--255)

Example

AT+CCMXPLAYWAV=?

+CCMXPLAYWAV: (1-2),(0-255)

OK

AT+CCMXPLAYWAV="E:/rec.wav",2

+WAVSTATE: wav play

OK

+WAVSTATE: wav play stop

21.2.4 AT+CCMXSTOPWAV Stop playing wav audio file

AT+CCMXSTOPWAV Stop playing wav audio file

Read Command

AT+CCMXSTOPWAV=?

Response

OK

Write Command

AT+CCMXSTOPWAV

Response

+CCMXSTOPWAV:

OK

+WAVSTATE: wav play stop

Parameter Saving Mode

-

Maximum Response Time

-

Reference

-

Defined Values

-

-

Example

AT+CCMXSTOPWAV

+CCMXSTOPWAV:

OK

+WAVSTATE: wav pl stop

21.2.5 AT+CCMXPLAY Play audio file

| AT+CCMXPLAY Play audio file | |
|---|---|
| Read Command AT+CCMXPLAY? | Response +CCMXPLAY:<play_path>,<repeat> OK |
| Write Command AT+CCMXPLAY=<filename>[,<play_path>][,<repeat>] | Response +CCMXPLAY: OK +AUDIOSTATE: audio play +AUDIOSTATE: audio play stop or ERROR or +CCMXPLAY: OK +AUDIOSTATE: audio play +AUDIOSTATE: audio play error |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|--------------------------|--|
| <play_path> | Play to local or to remote. Default 0 0 – local 1 – remote |
| <repeat> | How much times can be played. Default 0 |
| <filename> | The location and name of wav file. |

NOTE

<filename>,The wav audio file should be located at “E:”. Maximum filename length is 240 bytes. (including ""). Support audio file format mp3, aac, amr, wav.

<play_path>,Only during the call, **<play_path>** can be set to 1 successfully.Only 8k 16bit wav audio and amr audio can be played to remote at present.

<repeat>,This parameter is reserved, not used at present, you can input this parameter or not. (0--255)

Example


```

AT+CCMXPLAY=?
+CCMXPLAY: (0-1),(0-255)

OK
AT+CCMXPLAY="E:/rec.mp3",0,0
+CCMXPLAY:

OK

+AUDIOSTATE: audio play

+AUDIOSTATE: audio play stop
    
```

21.2.6 AT+CCMXSTOP Stop playing audio file

AT+CCMXSTOP Stop playing audio file

| Read Command | Response |
|-----------------------|--|
| AT+CCMXSTOP=? | OK |
| Write Command | Response |
| AT+CCMXSTOP | +CCMXSTOP: OK +AUDIOSTATE: audio play stop |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

-

Example

```

AT+CCMXSTOP
+CCMXSTOP:

OK

+AUDIOSTATE: audio play stop
    
```

22. AT Commands for TTS

22.1 Overview of AT Commands for TTS

| Command | Description |
|--------------|--------------------------------|
| AT+CDTAM | TTS play path, local or remote |
| AT+CTTS | TTS operation, play or stop |
| AT+CTTSPARAM | TTS parameters, set or get |

22.2 Detailed Description of AT Commands for TTS

22.2.1 AT+CDTAM TTS play path, local or remote

| AT+CDTAM TTS play path, local or remote | |
|---|---|
| Test Command AT+CDTAM=? | Response +CDTAM: (0-1) OK |
| Read Command AT+CDTAM? | Response + CDTAM: <status> OK |
| Write Command AT+CDTAM=<mode> | Response +CDTAM: OK or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|-----------------------|---|
| <status> | Indicate play path, play TTS to local or play to remote. 0 – Local path 1 – Remote path |
| <mode> | Set TTS play path, local or remote. Default value is 0. 0 – Local path 1 – Remote path |

Example

```
AT+CDTAM=1
+CDTAM:

OK
```

22.2.2 AT+CTTS TTS operation, play or stop

| AT+CTTS TTS operation, play or stop | |
|---|--|
| Test Command AT+CTTS=? | Response OK |
| Read Command AT+CTTS? | Response +CTTS: <status> OK |
| Write Command AT+CTTS=<mode>[,<text>] | Response If <mode> is 0, then <text> is not required. When TTS is playing, return: +CTTS:0 OK If <mode> is 0, then <text> is not required. When TTS is not playing, return: OK If <mode> is 1 or 2, then <text> is must be required. return: OK +CTTS:0 or ERROR |
| Write Command | Response |

| | |
|---|---|
| AT+CTTS=<mode>[,<text>][,<filename>] | If <mode> is 3 or 4, then <text> and <filename> are must be required. return: OK +CTTS:0 or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|-------------------------|---|
| <status> | Indicate playing thread status. Default value is 0 0 – NO_WORKING 1 – PLAY_WAV_WORKING 2 – AMR_WORKING 3 – MP3_WORKING 4 – AAC_WORKING 5 – WAV_WORKING 6 – TTS_WORKING 8 – CREC_WORKING |
| <mode> | Stop or play TTS. 0 – Stop TTS 1 – <text> is in UCS2 coding format, Start to synth and play 2 – <text> is in ASCII coding format for English, Chinese text is in GBK coding format. Start to synth and play 3 – <text> is in ASCII coding format for English, Chinese text is in GBK coding format. Start to synth and play, and save pcm data as wav file. 4 – <text> is in UCSII coding format . Start to synth and play, and save pcm data as wav file. |
| <filename> | Location and filename for wav file |

NOTE

- <text>, which is synthesized to speed to be played, maximum data length is 512 bytes. (including "")
- <filename>, The file should be put into the "E:/filename.wav". Maximum filename length is 240 bytes. (including "")

Example

```
AT+CTTS=1,"6B228FCE4F7F75288BED97F3540862107CFB7EDF"
```

```

OK

+CTTS:0

AT+CTTS=3,"欢迎使用语音合成系统","E:/ts.wav"
OK

+CTTS:0

AT+CTTS=0
OK

+CTTS:0
    
```

22.2.3 AT+CTTSPARAM TTS Parameters, set or get

| AT+CTTSPARAM TTS Parameters, set or get | |
|--|--|
| Test Command AT+CTTSPARAM=? | Response +CTTSPARAM: (0-2), (0-3),(0-3),(0-2),(0-2) |
| | OK |
| Read Command AT+CTTSPARAM? | Response +CTTS: <volume>,<sysvolume>,<digitmode>,<pitch>,<speed> |
| | OK |
| Write Command AT+CTTSPARAM=<volume> [,<sysvolume>[,<digitmode >[,<pitch>[,<speed>]]] | Response OK or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | - |

Defined Values

| | |
|--------------------------|---|
| <volume> | TTS Speech Volume, default: 2. 0 – The mix volume 1 – The normal volume 2 – The max volume |
| <sysvolume> | The module system volume, default: 3. 0 – The mix system volume |

| | |
|--------------------------|---|
| | <ul style="list-style-type: none"> 1 – The small system volume 2 – The normal system volume 3 – The max system volume |
| <digitmode> | <p>The digit read mode, default: 0</p> <ul style="list-style-type: none"> 0 – Auto read digit based on number rule first. 1 – Auto read digit bases on telegram rule first. 2 – Read digit based on telegram rule. 3 – Read digit based on number rule. |
| <pitch> | <p>The voice tone, default: 1</p> <ul style="list-style-type: none"> 0 – The mix voice tone. 1 – The normal voice tone. 2 – The max voice tone. |
| <speed> | <p>The voice speed, default: 1</p> <ul style="list-style-type: none"> 0 – The mix speed 1 – The normal speed 2 – The max speed |

NOTE

- **<sysvolume>**, It takes no effect to set **<sysvolume>**,reserved at present

Example

AT+CTTSPARAM=1,3,0,1,1

OK

23. AT Commands for FOTA

23.1 Overview of AT Commands for FOTA

| Command | Description |
|------------|---|
| AT+CAPFOTA | Start/Close FOTA Service |
| AT+CSCFOTA | Configure parameters and download upgrade package |

23.2 Detailed Description of AT Commands for FOTA

23.2.1 AT+CAPFOTA Start/Close FOTA Service

| AT+CAPFOTA Start/Close FOTA Service | |
|---|---|
| Test Command AT+CAPFOTA=? | Response +CAPFOTA: (list of supported <on/off>s) OK |
| Read Command AT+CAPFOTA? | Response +CAPFOTA: 1 OK |
| Write Command AT+CAPFOTA=<on/off> | Response OK or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|----------|--|
| <on/off> | The service status on/off, the default value is 0. |
| 0 | Close FOTA program |

1 Active FOTA program
The function will take effect immediately.

Example

AT+CAPFOTA?

+CAPFOTA: 1

OK

23.2.2 AT+CSCFOTA Configure parameters and download upgrade package

AT+CSCFOTA Configure parameters and download upgrade package

| | |
|---|---|
| Write Command | Response |
| AT+CSCFOTA=<OEM>,<models>,<productID>,<productSecret>,<target version> | If successfully: OK +CSCFOTA: <err> b)If failed: ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-------------------------------|---|
| <OEM> | The name of project design company. This name must be the same as the OEM created on the cloud platform. Otherwise, it will cause upgrade failed. |
| <models> | The name of the device model. This name must be the same as the device model created on the cloud platform. Otherwise, it will cause upgrade failed. |
| <productID> | The product ID that must be the same as the product ID generated on the cloud platform. |
| <productSecret> | The product secret is used to confirm the identity and usage rights of the user. It must be the same as the product secret generated on the cloud platform. |
| <target version> | The version that needs to be upgraded to. This version is published by the cloud platform. |
| <ERR> | |
| 1 | unknown error |
| 2 | Check version is finished |

| | |
|-----|--|
| 3 | Download is finished |
| 4 | Download partial finished |
| 5 | No matched version |
| 301 | No enough memory |
| 302 | Invalid parameter |
| 303 | Invalid operation |
| 304 | IO failed |
| 305 | IO timeout |
| 306 | Download file verification failed |
| 307 | got canceled |
| 308 | Interface nesting error |
| 401 | Invalid device information |
| 402 | Invalid platform information |
| 403 | Missing device information |
| 404 | Version number is not configured |
| 405 | Internal error (contact supplier) |
| 501 | Invalid URL |
| 502 | Unable to resolve domain name |
| 503 | cannot connect to the server |
| 504 | Invalid request, server returned error |
| 505 | Not in range |
| 506 | HTTP POST request error |
| 507 | Re-download start error |
| 508 | Operation is aborted |
| 509 | Operation not completed |
| 510 | Too many retargeting times |
| 511 | Unable to get data from SOCKET |
| 512 | Error sending data via SOCKET |
| 513 | Error receiving data via SOCKET |
| 514 | Invalid SOCKET connection |

Example

```
AT+CSCFOTA="SIMCOM","7600M21","15409
07004","f9bbb0d76f894da090b6b6925361656
1","SIM7600M21_LE11_181025_V2.00"
```

```
OK
+CSCFOTA: 2
+CSCFOTA: 3
```

24. AT Commands for UIM hotswap

24.1 Overview of AT Commands for UIM hotswap

| Command | Description |
|--------------------|------------------------------|
| AT+UIMHOTSWAPON | Set UIM hotswap function on |
| AT+UIMHOTSWAPLEVEL | Set UIM card detection level |

24.2 Detailed Description of AT Commands for UIM hotswap

24.2.1 AT+UIMHOTSWAPON Set UIM hotswap function on

| AT+UIMHOTSWAPON Set UIM hotswap function on | |
|---|---|
| Read Command AT+UIMHOTSWAPON? | Response +UIMHOTSWAPON: <onoff> |
| | OK |
| Write Command AT+UIMHOTSWAPON=<onoff> | Response OK or ERROR |

Defined Values

| | |
|---------|--|
| <onoff> | 0 The UIM hotswap function is disabled |
| | 1 The UIM hotswap function is enabled |

Example

```

AT+UIMHOTSWAPON?
+UIMHOTSWAPON: 0

OK

```

```
AT+UIMHOTSWAPON=1
OK
```

NOTE

- Module reset to take effect

24.2.2 AT+UIMHOTSWAPLEVEL Set UIM card detection level

AT+UIMHOTSWAPLEVEL Set UIM card detection level

| | |
|--|---|
| Read Command AT+UIMHOTSWAPLEVEL? | Response +UIMHOTSWAPLEVEL: <level> OK |
| Write Command AT+UIMHOTSWAPLEVEL=<level> | Response OK or ERROR |

Defined Values

| | |
|----------------------|---------------|
| <level> | 0 ACTIVE LOW |
| | 1 ACTIVE HIGH |

Example

```
AT+UIMHOTSWAPLEVEL?
+UIMHOTSWAPLEVEL: 0

OK
AT+UIMHOTSWAPLEVEL=1
OK
```

NOTE

- Module reset to take effect
- Set UIM card detection level to active low. //Refer to the used SIM card holder, usually it's a "normal open kind" one.
- The default value 1

SIMCom
Confidential

25. AT Commands for HSIC_LAN

25.1 Overview of AT Commands for HAIC_LAN

| Command | Description |
|---------------|-----------------------------------|
| AT+CENABLELAN | Enable LAN function |
| AT+CLANMODE | Set LAN mode |
| AT+CLANCTRL | Set LAN configure |
| AT+CHSICSLEEP | Allow Hsic Device Go to AutoSleep |

25.2 Detailed Description of AT Commands for HSIC_LAN

25.2.1 AT+CENABLELAN Enable LAN function

| AT+CENABLELAN Enable LAN function | |
|---|---|
| Write Command AT+CENABLELAN=<onoff> | Response OK or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|---------|---------------------|
| <onoff> | 0 Close the LAN9730 |
| | 1 Open the LAN9730 |

Example

```
AT+CENABLELAN=1
OK
```

NOTE

- LAN9730 is not opened in default, if want to open the LAN9730, you can run AT+CENABLELAN=1. After run this command, the module will restart automatically, then the LAN9730 will be opened.
- If want to close the LAN9730, you can run AT+CENABLELAN=0. After run this command, the module will restart automatically, then the LAN9730 will be closed.
- WIFI firmware doesn't care this AT command.

25.2.2 AT+CLANMODE Set LAN mode

| AT+CLANMODE Set LAN mode | |
|--|---|
| Test Command AT+CLANMODE=? | Response +CLANMODE: (list of supported <mode>s) OK |
| Read Command AT+CLANMODE? | Response +CLANMODE: <mode> OK |
| Write Command AT+CLANMODE=<mode> | Response OK or OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|--------|------------------|
| <mode> | 0 lan mode |
| | 1 wan mode |
| | 2 static ip mode |

Example

```

AT+CLANMODE?
+CLANMODE: (0,1)

OK
AT+CLANMODE=1

```

OK

NOTE

- Module works in lan mode in default. If want to use another mode, need to run `at+clanmode=<mode>`, after run this command, module will restart automatically, then the module will work in target mode.

25.2.3 AT+CLANCTRL Set LAN configure

AT+CLANCTRL Set LAN configure

| | |
|--|---|
| Test Command AT+CLANCTRL=? | Response +CLANCTRL: (list of supported <option>s) OK |
| Write Command AT+CLANCTRL=<option>,[<type/ip>],[netmask] | Response OK or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|------------|---|
| <option> | 0 uninstall driver 1 install driver 2 set mac address 3 set ip address 4 bring up eth0 5 bring down eth0 |
| <type> | 1 bcm898xx 2 at803x |
| <ip> | LAN ip address (Range: 192.168.*.*). |
| <netmask > | Range: 255.255.*.* if the parameter is not set, will use the default value:255.255.255.0 |

Example

AT+CLANCTRL=3,"192.168.1.1"

Set ip. The netmask is use default value
255.255.255.0

OK

AT+CLCANCTRL=3,"192.168.1.1","255.255.255.0"

Set ip and netmask. The netmask is
255.255.255.0

OK

NOTE

- Uninstall driver (option=0). Not support for HSIC LAN, Only Support SGMII LAN. Please don't run this command on HSIC LAN module
- Install driver (option=1). Not support for HSIC LAN, Only Support SGMII LAN.
- Set mac address (option=2). Support for HSIC LAN, But the module will auto set the Mac address. So there is no need to run the command.
- Set ip address (option=3). When module work in static ip mode. Use this command set ip and netmask.
- Bring up eth0 bring up eth0 (option=4). equal to "ifconfig eth0 up"
- Bring down eth0 (option=5). equal to "ifconfig eth0 down"

25.2.4 AT+CHSICSLEEP Allow HSIC Device Go to AutoSleep

AT+CHSICSLEEP Allow HSIC Device Go to AutoSleep

| | |
|---|--|
| Test Command AT+CHSICSLEEP=? | Response +CHSICSLEEP: (list of supported <state>s) OK |
| Read Command AT+CHSICSLEEP? | Response +CHSICSLEEP: <state> OK |
| Write Command AT+CHSICSLEEP=<state> | Response OK or ERROR |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

<state>

- 0 Don't allow the hsic device go to autosleep
- 1 Allow the hsic device go to autosleep

Example

```
AT+CHSICSLEEP =1
```

```
OK
```

```
AT+CHSICSLEEP?
```

```
+CHSICSLEEP: 1
```

```
OK
```

NOTE

- If the module needs to go to sleep, user needs to execute following steps:
 1. AT+CHSICSLEEP=1
 2. AT+CLANCTRL=5

26. AT Commands for Ecall

26.1 Overview of AT Commands for Ecall

| Command | Description |
|------------------|---|
| AT+CECALLS | Make e-call |
| AT+CECALLE | Hang up e-call |
| AT+CECALLCFG | Configure e-call MSD information |
| AT+CECALLPOS | Set position information |
| AT+CECALLTIME | Set timestamp |
| AT+CMSDVERSION | Set MSD serialize version |
| AT+CECALLTOUT | Set T5,T6,T7 timeout value |
| AT+CMSDMESSAGEID | Set the initiatory message identifier of msd data Description |
| AT+CMSDOIDDATA | Set the optional additional data |
| AT+CMSD | Input hex Minimum set of data(MSD) |
| AT+CMSDCONTROL | Set the control data in Minimum set of data |

26.2 Detailed Description of AT Commands for Ecall

26.2.1 AT+CECALLS Make e-call

The command is used to make an e-call.

| AT+CECALLS Make an e-call | |
|--|---|
| Test Command AT+CECALLS=? | Response +CECALLS: (scope of <cannedMSD>) |
| Write Command AT+CECALLS=<num>,<cannedMSD> | Response OK |

ERROR

Defined Values

| | |
|--------------------------|---|
| <num> | Dialing number. |
| | Use the canned GPS information or real GPS information. |
| <cannedMSD> | 0 — Send real MSD |
| | 1 — Send canned MSD |

Example

```
AT+CECALLS=15865451120,1
OK
```

26.2.2 AT+CECALLE Hang up e-call

The command is used to hang up the e-call.

AT+CECALLE Hang up an e-call

| | |
|--|--|
| Test Command AT+CECALLE=? | Response +CECALLS: (0-1) OK |
| Read Command AT+CECALLE? | Response +CECALLE: <n> OK |
| Write Command AT+CECALLE=<n> | Response OK VOICE CALL: END: <time> No call: OK |

Defined Values

| | |
|------------------|--|
| <n> | 0 — Stop an active eCall, change the state into "ECALL_APP_ECALL_INACTIVE" and clear callbackTimer. When set to 0, module cannot receive a MT ECALL from PSAP. |
| | 1 — End an active ecall, but keep state "ECALL_APP_IDLE_ALLOW_MT_ECALL", not clear callbackTimer. When set to 1, module can receive a MT ECALL from PSAP. |

<time> Voice call connection time.
Format – HHMMSS (HH: hour, MM: minute, SS: second)

Example

```
AT+CECALLE=0
OK
```

26.2.3 AT+CECALLCFG Configure e-call MSD information

The command is used to configure the MSD information.

| AT+CECALLCFG Configure e-call MSD information | |
|---|----------|
| Test Command | Response |
| AT+CECALLCFG=? | OK |
| Write Command | Response |
| AT+CECALLCFG=<vehicletype>,<storage>,<num>,<vin>,<vehicledirection>,<delta1_lon>,<delta1_lat>,<delta2_lon>,<delta2_lat> | OK |
| | ERROR |

Defined Values

<vehicletype>

- 1 — Passenger vehicle class M1
- 2 — Buses and coaches class M2
- 3 — Buses and coaches class M3
- 4 — Light commercial vehicles class N1
- 5 — Heavy duty vehicles class N2
- 6 — Heavy duty vehicles class N3
- 7 — Motorcycles class L1e
- 8 — Motorcycles class L2e
- 9 — Motorcycles class L3e
- 10 — Motorcycles class L4e
- 11 — Motorcycles class L5e
- 12 — Motorcycles class L6e
- 13 — Motorcycles class L7e

<storage> Propulsion storage: It should choice multi-storage. decimal number

NOTE Example: Choice “Electric energy storage” and “Diesel tank present”, the **<storage>** must be set by 18. (i.e. 2 or 16 equal 18)

- 0 — Unknown or other type of energy storage
- 1 — Hydrogen storage

| | |
|--------------------|--|
| | <p>2 — Electric energy storage 4 — Liquid propane gas 8 — Compressed natural gas 16 — Diesel tank present 32 — Gas online tank present</p> <p>Range is 0~63.</p> |
| <num> | Number of passenger. Range is 0~255. |
| <vin> | <p>Vehicle id number. Length of <vin> must be 17. VIN number according to ISO 3779. including: 1.World Manufacturer Index (WMI) 2.Vehicle Type Descriptor (VDS) 3.Vehicle Identification Sequence (VIS)</p> <p>The character in VIN must be the member of this table: ("A".. "H" "J".. "N" "P" "R".. "Z" "0".. "9")</p> |
| <vehicledirection> | <p>The direction of travel in 2°-degrees steps from magnetic north (0– 358, clockwise). Only values from 0 to 179 are valid. If direction of travel is invalid or unknown, the value 0xFF shall be used. Unit is 2 degree. Range of <vehicledirection> is 0~179.</p> |
| <delta1_lon> | <p>Description of recent vehicle longitude location before the incident. 1 Unit = 100 miliarcseconds, which is approximately 3m. Coded value range (-512..511) representing -51200 to +51100 miliarcseconds, or from 51,2"S to 51,1"N from the reference position.</p> |
| <delta1_lat> | <p>Description of recent vehicle latitude location before the incident. 1 Unit = 100 miliarcseconds, which is approximately 3m. Coded value range (-512..511) representing -51200 to +51100 miliarcseconds, or from 51,2"S to 51,1"N from the reference position.</p> |
| <delta2_lon> | <p>Description of recent vehicle latitude location before the incident. 1 Unit = 100 miliarcseconds, which is approximately 3m.</p> |
| <delta2_lat> | <p>Description of recent vehicle latitude location before the incident. 1 Unit = 100 miliarcseconds, which is approximately 3m. Coded value range (-512..511) representing -51200 to +51100 miliarcseconds, or from 51,2"S to 51,1"N from the reference position.</p> |

Example

```
AT+CECALLCFG=5,18,8,"WMJVDSVDSYA123456",14,10,-10,20,-20
OK
```

26.2.4 AT+CECALLPOS Set position information

The command is used to set position information.

AT+CECALLPOS Set position information

| | |
|---|---|
| Test Command AT+CECALLPOS=? | Response OK |
| Write Command AT+CECALLPOS=<lon>,<lat> > | Response OK ERROR |

Defined Values

| | |
|--------------------|---|
| <lon> | Longitude of current position, format is ddd.dddddd. Unit is degree. Range is -180~180. |
| <lat> | Latitude of current position, format is dd.dddddd. Unit is degree. Range is -90~90. |

Example

```
AT+CECALLPOS="121.354138","31.221938"
OK
```

26.2.5 AT+CECALLTIME Set timestamp

The command is used to set timestamp.

AT+CECALLTIME Set timestamp

| | |
|--|---|
| Test Command AT+CECALLTIME=? | Response OK |
| Write Command AT+CECALLTIME=<flag>[,<year>,<month>,<day>,<hour>,<minute>,<second>] | Response OK ERROR |

Defined Values

| | |
|----------------------|--|
| <flag> | 0 - use system time, not need to set <year>, <month>, <day>, <hour>, <minute>,<second> 1 - must set <year>,<month>,<day>,<hour>,<minute>,<second> |
| <year> | Year :integer Range is 1970~2100 |
| <month> | Month : integer Range is 1~12 |

| | |
|----------|---|
| <day> | Day : integer Input range : Jan \ Mar \ May \ Jul \ Aug \ Oct \ Dec: 1~31 Feb: 1~28 (1~29 if leap year) Apr \ Jun \ Sep \ Nov: 1~30 |
| <hour> | Hour : integer Range is 0~23 |
| <minute> | Minute : integer Range is 0~59 |
| <second> | Second : integer Rang is 0~59 |

Example

```
AT+CECALLTIME=1,2011,10,20,15,30,30
OK
```

26.2.6 AT+CECALLVERSION Set MSD serialize version

The command is used to set MSD pack format.

| AT+CECALLVERSION Set MSD serialize version | |
|--|---|
| Test Command AT+CECALLVERSION=? | Response +CMSDVERSION: (1-2) OK |
| Read Command AT+CECALLVERSION? | Response +CMSDVERSION: <ver> OK |
| Write Command AT+CMSDVERSION=<ver> | Response OK ERROR |

Defined Values

| | |
|-------|---|
| <ver> | 1 - set MSD serialize version 1 (qualcomm default version, other European country) 2 - set MSD serialize version 2 (just for Russia ecall) |
|-------|---|

Example

AT+CMSDVERSION=1
OK

26.2.7 AT+CECALLTOUT Set T5,T6,T7 timeout value

The command is used to set T5,T6,T7 timeout value.

| AT+CECALLTOUT Set T5,T6,T7 timeout value | |
|---|---|
| Read Command AT+CECALLVERSION? | Response +CECALLTOUT: T5=<timeoutvalue>, T6=<timeoutvalue>, T7=<timeoutvalue> OK |
| Write Command AT+CECALLTOUT=<TX>,<timeoutvalue> | Response OK ERROR |

Defined Values

- <TX>**
- T5 - The timer of IVS waiting for START, default timeout value is 2 seconds. The timeout value will not be saved to NV. You should set the timeout value before organizing the eCall. For further information about this timer, please refer to EN 16062.
Range is 2000-255000 ms. Default value 2000 ms
 - T6 - The timer of IVS waiting for HACK, default timeout value is 5 seconds. The timeout value will not be saved to NV. You should set the timeout value before organizing the eCall. For further information about this timer, please refer to EN 16062.
Range is 5000-255000 ms. Default value 5000 ms.
 - T7 - The timer for MSD transmission, default timeout value is 20 seconds. The timeout value will not be saved to NV. You should set the timeout value before organizing the eCall. For further information about this timer, please refer to EN 16062.
Range is 20000-255000 ms. Default value 20000 ms

Example

AT+CECALLTOUT="T5",4000

OK

26.2.8 AT+CMSDMESSAGEID Set the initiatory message identifier of msd data

Description

The command is used to set the initiatory message identifier of msd data.

AT+CMSDMESSAGEID Set the initiatory message identifier of msd data Description

| | |
|--|---|
| Test Command AT+CMSDMESSAGEID=? | Response +CMSDMESSAGEID: (list of supported <messageid>) OK |
| Read Command AT+CMSDMESSAGEID? | Response +CMSDMESSAGEID: <messageid> OK |
| Write Command AT+CMSDMESSAGEID=<messageid> | Response OK ERROR |

Defined Values

<messageid>

starting with 1 for each new eCall session and to be incremented with every application layer MSD retransmission following a new 'Send MSD' request after the incident event .(1-255)

Example

AT+CMSDMESSAGEID=1
OK

26.2.9 AT+CMSDOIDDATA Set the optional additional data

The command is used to set the optional additional data.

AT+CMSDOIDDATA Set the optional additional data

| | |
|--|---|
| Test Command AT+CMSDOIDDATA=? | Response OK |
| Write Command AT+CMSDOIDDATA=<oid>,<odata> | Response OK ERROR |

Defined Values

| | |
|----------------------|--|
| <oid> | Object identifier which uniquely identifies the format and meaning of the data which follows. (oid is decimal string x.x.xxx), the length must be 7. |
| <odata> | Transparent optional additional data. (odata is hex string) which maximum size is 100 bytes. |

Example

```
AT+CMSDOIDDATA="1.2.125","30304646"  
OK
```

26.2.10 AT+CMSD Input hex Minimum set of data

The command is used to input hex Minimum set of data.

| AT+CMSD Input hex Minimum set of data | |
|---|---|
| Test Command AT+CMSD=? | Response OK |
| Write Command AT+CMSDOIDDATA=<MSD>,<activationType>,<eCallType> | Response OK ERROR |

Defined Values

| | |
|---------------------------|---|
| <msd> | the hex msd data generated by user which maximum size is 140 bytes. |
| <activation> | 0 - Manual activation 1 - Automatic activation |
| <eCallType> | 0 - Emergency call 1 - Test call |

Example

```
AT+CMSD="015C0681508204420014264000420D101404E80DA4C89A3B2F09905B6440E829F682
9EC020301027D04303046460",0,1
OK
```

26.2.11 AT+CMSDCONTROL Set the control data in Minimum set of data

The command is used to set the control data in Minimum set of data(MSD).

AT+CMSDCONTROL Set the control data in Minimum set of data

| | |
|---|---------------------------------------|
| Test Command AT+CMSDCONTROL=? | Response OK |
| Write Command AT+CMSDCONTROL=<activationType>,<callType>,<positionCanBeTrusted> | Response OK ERROR |

Defined Values

| | |
|-------------------------------------|--|
| <activationType> | Manual activation(by pushing the emergency button) or automatic activation(by hitting sensors). 0 — Manual activation 1 — Automatic activation |
| <callType> | e-call type: 0 — Test call 1 — Emergency call |
| <positionCanBeTrusted> | 0 — low confidence in position 1 — Position can be trusted |

Example

```
AT+CMSDCONTROL=0,0,1
OK
```

27. AT Commands for MIFI

27.1 Overview of AT Commands for MIFI W58

| Command | Description |
|--------------|--|
| AT+CWMAP | Open/Close WIFI |
| AT+CWSSID | SSID setting |
| AT+CWBICAST | Broadcast setting |
| AT+CWAUTH | Authentication type, encrypt mode and password setting |
| AT+CWMOCH | 80211 mode and channel setting |
| AT+CWISO | Client isolation setting |
| AT+CWDHCP | Get the current DHCP configuration |
| AT+CWNAT | NAT type setting |
| AT+CWCLICNT | Get client number connected to the WIFI |
| AT+CWRSTD | Restore to default setting |
| AT+CWMAPCFG | WIFI configuration setting |
| AT+CWLANSRV | LAN SERVER setting |
| AT+CWLANMSG | Send message |
| AT+CWMACADDR | Get MAC address |
| AT+CWNCTCNCT | Query the connection to the network |
| AT+CWSTAIP | Get STA mode IP address |
| AT+CWSTASCAN | Scan WIFI network |
| AT+CWSTACFG | STA mode configuration setting |
| AT+CWUSRINFO | Auth info of wifi data call setting |

27.2 Overview of AT Commands for MIFI W58L(RTL)

| Command | Description |
|-------------|--|
| AT+CWMAP | Open/Close WIFI |
| AT+CWSSID | SSID setting |
| AT+CWBICAST | Broadcast setting |
| AT+CWAUTH | Authentication type, encrypt mode and password setting |

| | |
|--------------|---|
| AT+CWMOCH | 80211 mode and channel setting |
| AT+CWDHCP | Get the current DHCP configuration |
| AT+CWCLICNT | Get client number connected to the WIFI |
| AT+CWRSTD | Restore to default setting |
| AT+CWLANSRV | LAN SERVER setting |
| AT+CWLANMSG | Send message |
| AT+CWMACADDR | Get MAC address |
| AT+CWNCTCNCT | Query the connection to the network |
| AT+CWSTAIP | Get STA mode IP address |
| AT+CWSTASCAN | Scan WIFI network |
| AT+CWSTACFG | STA mode configuration setting |
| AT+CWSTAINIT | STA mode setting |
| AT+CWUSRINFO | Auth info of wifi data call setting |

27.3 Detailed Description of AT Commands for MIFI

27.3.1 AT+CWMAP Open/Close WIFI

| AT+CWMAP Open/Close WIFI | |
|---|--|
| Test Command AT+CWMAP=? | Response +CWMAP: (0-1) OK |
| Read Command AT+CWMAP? | Response +CWMAP: <flag> OK |
| Write Command AT+CWMAP=<flag> | Response OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|--------|---------|
| <flag> | 0 Close |
| | 1 Open |

Example

```
AT+CWMAP?
+CWMAP: 1

OK
AT+CWMAP=0
OK
```

27.3.2 AT+CWSSID SSID setting

| AT+CWSSID SSID setting | |
|--|--|
| Read Command AT+CWSSID? | Response +CWSSID: <ssid> |
| | OK |
| Write Command AT+CWSSID=<ssid> | Response OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|---------------------|---|
| <ssid> | <p>new ssid string</p> <ol style="list-style-type: none"> The max length of <ssid> is 32 bytes when the <ssid> include only ASCII characters. The max length of <ssid> is 20 bytes when <ssid> include only Chinese (One Chinese characters is 2 bytes, so the max Chinese count is 10). The max length of <ssid> is 22 bytes when <ssid> include ASCII and Chinese characters (One Chinese character is 2 bytes, one ASCII character is 1 byte). <p>The default value is SIM7600MIFI.</p> |
|---------------------|---|

Example

```
AT+CWSSID?
+CWSSID: "SIM7600MIFI"

OK
```

27.3.3 AT+CWBCAST Broadcast setting

| AT+CWBCAST Broadcast setting | |
|---|---|
| Test Command AT+CWBCAST=? | Response +CWBCAST: (0-1) OK |
| Read Command AT+CWBCAST? | Response +CWBCAST: <broadcast> OK |
| Write Command AT+CWBCAST=<broadcast > | Response OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-------------|------------|
| <broadcast> | 0 disabled |
| | 1 enabled |

Example

```

AT+CWBCAST?
+CWBCAST: 1

OK
AT+CWBCAST=0
OK

```

27.3.4 AT+CWAUTH Authentication setting

| AT+CWAUTH Authentication type, encrypt mode and password setting | |
|--|--|
| Read Command AT+CWAUTH? | Response +CWAUTH:<auth>,<encrypt>[,<password>] |

| | |
|---|-----------|
| | OK |
| Write Command | Response |
| AT+CWAUTH=<auth>,<encrypt> [,<password>] | OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | | |
|-------------------------|--|------------|
| <auth> | 0 | open/share |
| | 1 | open |
| | 2 | share |
| | 3 | wpa |
| | 4 | wpa2 |
| <encrypt> | 5 | wpa/wpa2 |
| | 0 | null |
| | 1 | WEP |
| | 2 | TKIP |
| | 3 | AES |
| <password> | 4 | TKIP-AES |
| | password string, the length is 5 or between 8 to 64. The char in the password is only allow the ASCII 's decimal code between 32 to 126. | |

NOTE

The parameter need to meet the following conditions:

1. If (auth = 0 or auth = 1) then (encrypt = 0 or encrypt = 1)
2. If (auth =2) then (encrypt = 1)
3. If (auth >=3) then (encrypt >=2)
4. If(encrypt = 0) then (password is null)
5. If(encrypt = 1) then
 - {
 - 1) password can't be set null
 - 2) password format: (5 ASCII character) or (10 hexadecimal number) or(13 ASCII character) or(26 hexadecimal number)
 - }
6. if(encrypt >= 2) then
 - {
 - 1) password can't be set null
 - 2) password format: (8~63 ASCII character or 64 hexadecimal number)
 - }

Example

```

AT+CWAUTH?
+CWAUTH: 0,1, "11111"

OK
AT+CWAUTH?
+CWAUTH: 5,4, "12345678"

OK
AT+CWAUTH=0,0
OK //Auth:open/share encrypt:null
AT+CWAUTH=0,1,"11111"
OK //Auth:open/share encrypt:WEP
AT+CWAUTH=2,1,"12345"
OK //Auth:share encrypt:WEP
(ASCII character password:12345)
AT+CWAUTH=2,1,"3132333435"
OK //Auth:share encrypt :WEP
(sixteen hexadecimal number:password 12345)
AT+CWAUTH=5,4,"abcd1234"
OK //Auth:WPA/WPA2 encrypt:TIKP-AES
  
```

27.3.5 AT+CWMOCH 80211 mode and channel setting

| AT+CWMOCH 80211 mode and channel setting | |
|--|--|
| Read Command AT+CWMOCH? | Response +CWMOCH: <mode>,<channel> |
| | OK |
| Write Command AT+CWMOCH=<mode>,<channel> | Response OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| <mode> | | |
|--------|-------|-----------|
| 2 | b | 2.4G mode |
| 3 | b/g | 2.4G mode |
| 4 | b/g/n | 2.4G mode |

| | | |
|-----------|------|-------------------------|
| <channel> | 0 | auto select |
| | 1~11 | 2.4Gmode channel number |

Example

```

AT+CWMOCH?
+ CWMOCH: 4,0

OK
AT+CWMOCH=3,1
OK

```

27.3.6 AT+CWISO Client isolation setting

AT+CWISO Client isolation setting

| | |
|--|--|
| Test Command AT+CWISO=? | Response +CWISO: (0-1) OK |
| Read Command AT+CWISO? | Response +CWISO: <isolation> OK |
| Write Command AT+CWISO=<isolation> | Response OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | | |
|-------------|---|-------|
| <isolation> | 0 | close |
| | 1 | open |

Example

```

AT+CWISO?
+CWISO: 1

OK
AT+CWISO=0

```

OK

27.3.7 AT+CWDHCP Get the current DHCP configuration

AT+CWDHCP Get the current DHCP configuration

| | |
|-----------------------------------|---|
| Read Command AT+CWDHCP? | Response +CWDHCP:<host_ip>,<range_start_ip>,<range_end_ip>,<leasetime> OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-------------------------------|--|
| <host_ip> | the AP IP |
| <range_start_ip> | the start IP of the IP range that assigned to the client |
| <range_end_ip> | the end IP of the IP range that assigned to the client |
| <leasetime> | the lease time |

Example

```
AT+CWDHCP?
+CWDHCP: "192.168.1.250","192.168.1.128","192.168.1.249",240h
OK
```

27.3.8 AT+CWNAT NAT type setting

AT+CWNAT NAT type setting

| | |
|-----------------------------------|--|
| Test Command AT+CWNAT=? | Response +CWNAT: (0-1) OK |
| Read Command AT+CWNAT? | Response +CWNAT: <type> OK |

| Write Command | Response |
|------------------------------|-----------|
| AT+CWNAT=<type> | OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|--------|-------------|
| <type> | 0 Symmetric |
| | 1 Cone |

Example

AT+CWNAT?

+CWNAT: 1

OK

AT+CWNAT=0

OK

27.3.9 AT+CWCLICNT Get client number connected to the WIFI

AT+CWCLICNT Get the client number connected to the WIFI

| Read Command | Response |
|-----------------------|-------------------------------|
| AT+CWCLICNT? | +CWCLICNT: <cnt> |
| | OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-------|--|
| <cnt> | the connected client count, range is from 0 to 31. |
|-------|--|

Example

AT+CWCLICNT?

+CWCLICNT: 1

OK

27.3.10 AT+CWRSTD Restore to default setting

| AT+CWRSTD Restore all MIFI setting to default | |
|---|-----------------------|
| Write Command AT+CWRSTD | Response OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Example

```
AT+CWRSTD
OK
```

27.3.11 AT+CWMAPCFG WIFI configuration setting

| AT+CWMAPCFG WIFI mode, configuration AP ID setting | |
|--|---|
| Test Command AT+CWMAPCFG=? | Response +CWMAPCFG: ("enablenessid2","configselect"),(0-2) OK |
| Read Command AT+CWMAPCFG? | Response +CWMAPCFG: <enablenessid2_value>,<configselect_value> OK |
| Write Command AT+CWMAPCFG=<option>,<value> | Response OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|------------------------------------|-----------------------------|
| <enablenessid2_value> | 0 AP mode |
| | 1 AP-AP mode |
| | 2 STA-AP mode |
| <configselect_value> | Current AP ID (0 or 1 or 2) |

| | |
|----------|---|
| <option> | "enablessid2" set WIFI mode "configselect" set the current AP ID |
| <value> | the value of the options. |

NOTE

If (option="enablessid2")

- 0 AP mode
- 1 AP-AP mode
- 2 STA-AP mode

If (option="configselect")

Current AP ID (0 or 1 or 2) to be set.

When current AP ID is 0, the

AT+CWSSID/AT+CWBCAST/AT+CWAUTH/AT+CWMOCH/AT+CWISO/AT+CWDHCP/AT+CWCLICNT/AT+CWMACADDR will modify the first AP's settings;

When current AP ID is 1, the

AT+CWSSID/AT+CWBCAST/AT+CWAUTH/AT+CWMOCH/AT+CWISO/AT+CWDHCP/AT+CWCLICNT/AT+CWMACADDR will modify the second AP's settings;

When current AP ID is 2, the

AT+CWSSID/AT+CWBCAST/AT+CWAUTH/AT+CWMOCH/AT+CWISO/AT+CWDHCP/AT+CWCLICNT/AT+CWMACADDR will modify the third AP's settings, the AT+CWSTAIP/AT+CWSTASCAN/AT+CWSTACFG will modify the STA's settings.

NOTE

1. It can't set the configselect value to 1 when enablessid2 is 0.
2. The configselect value will be changed due to enablessid2.

enablessid2 configselect

| | |
|---|--------|
| 0 | 0 |
| 1 | 0 or 1 |
| 2 | 2 |

Example

AT+CWMAPCFG=?

+CWMAPCFG: ("enablessid2","configselect"),(0-2)

OK

AT+CWMAPCFG?

+CWMAPCFG: 0,0

OK

AT+CWMAPCFG="enablessid2",1 // Set enablessid2

OK

AT+CWMAPCFG="configselect",0 // Set configselect

OK

27.3.12 AT+CWLANSRV LAN SERVER setting

AT+CWLANSRV LAN server setting

| | |
|---|---|
| Read Command AT+CWLANSRV? | Response +CWLANSRV: <server_ip >,<server_port>,<recv_mode> OK |
| Write Command AT+CWLANSRV=<value> | Response OK |
| Write Command AT+CWLANSRV=0,<server_port>[,<recv_mode>] | Response OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|----------------------------|---|
| <server_ip> | Default 192.168.225.1 |
| <server_port> | Default 5555 The range of permitted values is 1024 to 65535. |
| <recv_mode> | <u>0</u> Report messages directly with URC(+CWLANMSG) 1 Report cached bytes when new messages are received (+CWLANMSG: <cached_len>).And use AT+CWLANMGET to get cached bytes. |
| <value> | <u>0</u> close the server 1 open the server |

Example

```

AT+CWLANSRV?
+CWLANSRV: 192.168.225.1,5555,0

OK
AT+CWLANSRV=1
OK

+CWLANMSG: 123456789
    
```

```

AT+CWLANSRV=0,44444,1
OK
AT+CWLANSRV?
+CWLANSRV: 192.168.225.1,44444,1

OK
AT+CWLANSRV=1
OK

+CWLANMSG: 10

+CWLANMSG: 20

+CWLANMSG: 30

+CWLANMSG: 40

+CWLANMSG: 50

AT+CWLANMGET=30
+CWLANMGET: 030,123456789012345678901234567890

OK
AT+CWLANMGET=30
+CWLANMGET: 020,12345678901234567890

OK

```

27.3.13 AT+CWLANMSG Send message

Must open the lan server first (AT+CWLANSRV=1).

| AT+CWLANMSG Send message | |
|--|-----------|
| Write Command | Response |
| AT+CWLANMSG=<tx_msg> | OK |
| Received urc message | |
| +CWLANMSG: <rx_msg><tail> | |
| Received urc message | |
| +CWLANMSG: <cached_len> | |
| Parameter Saving Mode | - |

| | |
|-----------------------|---|
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|--------------|--|
| <tx_msg> | Hexadecimal string.The max length of message is 512. |
| <rx_msg> | ASCII string. (1)The message must end with 0x0A from the client. (2)The max length of <message> is 1024,and ignore others. |
| <tail> | 0x0D0A0D0D0A Normal tail. 0x0D0D0A The message has 0x00. |
| <cached_len> | Cached bytes. The max length is 10*1024. |

Example

```
AT+CWLANSRV=1
OK
AT+CWLANMSG="31323434"
OK

+CWLANMSG: 1234\r\n\r\n\r\n
```

27.3.14 AT+CWLANMGET Manual get cached bytes

Must open the lan server first (AT+CWLANSRV=1).

| AT+CWLANMGET Manual get cached bytes | |
|--|---|
| Read Command AT+CWLANMGET? | Response +CWLANMGET: <cached_len> OK |
| Write Command AT+CWLANMGET=<len> | Response +CWLANMGET: <len> <msg> OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

Example

```
AT+CWMACADDR?
0,00:0A:F5:88:88:8F
1,74:23:44:8f:64:fd

OK
```

27.3.16 AT+CWNENCTNCT Query the connection to the network

AT+CWNENCTNCT Query the connection to the network

| | |
|---------------------------------------|--|
| Read Command AT+CWNENCTNCT? | Response +CWNENCTNCT: <flag> |
| | OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|---------------------|--------------|
| <flag> | 0 disconnect |
| | 1 connect |

Example

```
AT+CWNENCTNCT?
+CWNENCTNCT: 1

OK
```

27.3.17 AT+CWSTAIP Get STA mode IP address

AT+CWSTAIP Get STA mode IP address

| | |
|------------------------------------|---|
| Read Command AT+CWSTAIP? | Response [+CWSTAIP: <ip address>] |
| | OK |
| Parameter Saving Mode | - |

| | |
|-----------------------|---|
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|--------------|------------------------|
| <ip address> | the station IP address |
|--------------|------------------------|

Example

```
AT+CWSTAIP?
+CWSTAIP: 192.168.11.27

OK
```

27.3.18 AT+CWSTASCAN Scan WIFI network

| AT+CWSTASCAN Scan WIFI network | |
|--|---|
| Read Command AT+CWSTASCAN? | Response +CWSTASCAN: <flag_show_signal> OK |
| Write Command AT+CWSTASCAN=<flag_show_signal > | Response OK |
| Read Command AT+CWSTASCAN | Response [+CWSTASCAN: <bssid>,<ssid>[,signal] [... ...]] OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|--------------------|--|
| <flag_show_signal> | 0 – Don't show the signal level. It's the default value. 1 – Show the signal level. |
| <bssid> | The MAC address of external wireless network. |
| <ssid> | The SSID name of external wireless network. |
| <signal> | The signal level of external wireless network. |

Example

```

AT+CWSTASCAN
+CWSTASCAN:
4c:e6:76:49:2a:48, simtest

OK
AT+CWSTASCAN=1
OK
AT+CWSTASCAN?
+CWSTASCAN: 1

OK
AT+CWSTASCAN
+CWSTASCAN:
f4:83:cd:d8:24:c8,TP-LINK_24C8,-52
80:89:17:10:e6:23,TP-LINK_SW2,-58
14:2d:27:24:98:61,Public,-58
bc:46:99:38:e2:ca,TP-LINK_E2CA,-64
0c:72:d9:49:25:8b,nubia-WD670-258B,-92
50:2b:73:c0:aa:d9,Tenda_C0AAD9,-68

OK

```

27.3.19 AT+CWSTACFG STA mode configuration setting

AT+CWSTACFG STA mode configuration setting

| | |
|---|--|
| Read Command AT+CWSTACFG? | Response +CWSTACFG: <ssid>[,<security>,<proto>,<psk>] OK |
| Write Command AT+CWSTACFG=<ssid>[,<security>,<proto>,<psk>] | Response OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|------------|---|
| <ssid> | The SSID name of external wireless network. |
| <security> | Reserved value. |

| | |
|---------|--|
| <proto> | Reserved value. |
| <psk> | The password of external wireless network. |

NOTE

1. The configselect value must set to 2;
2. The <security> and <proto> are reserved value which is in ort to compatible with previous versions. These 2 parameters can be entered NULL or any combination.

Example

```

AT+CWSTACFG= "simtest",2,1,"1234567890"
OK
AT+CWSTACFG?
+CWSTACFG: "simtest",,"1234567890"

OK
AT+CWSTACFG= "simtest",,"1234567890"
OK
AT+CWSTACFG?
+CWSTACFG: "simtest",,"1234567890"

OK
AT+CWSTACFG= "simtest",,""
OK
AT+CWSTACFG?
+CWSTACFG: "simtest"

OK
AT+CWSTACFG= "simtest"
OK
AT+CWSTACFG?
+CWSTACFG: "simtest"

OK

```

27.3.20 AT+CWSTAINIT STA mode setting

AT+CWSTAINIT STA mode setting

| Test Command | Response |
|-----------------------|--------------------------|
| AT+CWSTAINIT=? | +CWSTAINIT: (0-1) |

| | |
|---|---|
| | OK |
| Read Command AT+CWSTAINIT? | Response +CWSTAINIT: <type> |
| | OK |
| Write Command AT+CWSTAINIT=<type> | Response OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|--------|---|
| <type> | 0 close station mode 1 open station mode |
|--------|---|

Example

```

AT+CWSTAINIT=?
+CWSTAINIT: (0-1)

OK
AT+CWSTAINIT=0
OK
AT+CWSTAINIT?
+CWSTAINIT: 0

OK
  
```

27.3.21 AT+CWUSRINFO Auth info of wifi data call setting

The username and password are only for CDMA/EVDO network mode.

| AT+CWUSRINFO Auth information of wifi data call setting | |
|--|--|
| Test Command AT+CWUSRINFO=? | Response +CWUSRINFO: (1-127),(1-127) |
| | OK |
| Read Command AT+CWUSRINFO? | Response +CWUSRINFO: <username>,<password> |

| | |
|---|----------|
| | OK |
| Write Command | Response |
| AT+CWUSRINFO=<username>,<password> | OK |
| Parameter Saving Mode | - |
| Maximum Response Time | - |
| Reference | |

Defined Values

| | |
|-------------------------|---|
| <username> | username string. The length is from 1 to 127. |
| <password> | password string. The length is from 1 to 127. |

NOTE

1. It need to reset when set the username and password.
2. If not set the username and password, the default value is "ctnet@mycdma.cn" and "vnet.mobi".

Example

```

AT+CWUSRINFO=?
+CWUSRINFO: (1-127),(1-127)

OK
AT+CWUSRINFO?
+CWUSRINFO: "ctnet@mycdma.cn","vnet.mobi"

OK
AT+CWUSRINFO="username","pwd"
OK
  
```


28. AT Commands for BT

28.1 Overview of AT Commands for BT

| Command | Description |
|---------------------|---|
| AT+BTPOWER | Open/Close BT |
| AT+BTHOST | Get/Set host name |
| AT+BTSCAN | Scan BT devices |
| AT+BTIOCAP | IOCAP Mode Setting |
| AT+BTPAIR | Pair with the paired BT devices |
| AT+BTUNPAIR | Unpair with the paired BT devices |
| AT+BTPAIRED | Get Paired BT devices |
| AT+BTSPPSRV | Active/Deactive spp server |
| AT+BTSPPPROF | Get remote device spp status |
| AT+BTSPPCONN | SPP connect/disconnect |
| AT+BTSPSEND | SPP send data |
| AT+BTGATTREG | GATT Register |
| AT+BTGATTACT | GATT Active |
| AT+BTGATTCREDB | GATT Create DB |
| AT+BTGATTCRESRV | GATT Create Service |
| AT+BTGATTCRECHAR | Create Service characteristic |
| AT+BTGATTCRECHARDES | Create Service characteristic description |
| AT+BTGATTSRVADD | DB Add To GATT Server |
| AT+BTGATTREADCFM | Response to BTGATTREADIND |
| AT+BTGATTWRCFM | Response to BVTGATTWRIND |
| AT+BTGATTNOTIFY | Send Notification to client |
| AT+BTGATTSENDIND | Send Indication to client |
| +BTSPPRECV | SPP receive data |
| +BTGATTCONN | Client connect status |
| +BTGATTREADIND | Receive client read request |
| +BTGATTWRIND | Receive client write request |

28.2 Detailed Description of AT Commands for BT

| Command | Description |
|---------------------|---|
| AT+BTPOWER | Open/Close BT |
| AT+BTHOST | Get/Set host name |
| AT+BTSCAN | Scan BT devices |
| AT+BTIOCAP | IOCAP Mode Setting |
| AT+BTPAIR | Pair with the paired BT devices |
| AT+BTUNPAIR | Unpair with the paired BT devices |
| AT+BTPAIRED | Get Paired BT devices |
| AT+BTSPPSRV | Active/Deactive spp server |
| AT+BTSPPPROF | Get remote device spp status |
| AT+BTSPPCONN | SPP connect/disconnect |
| AT+BTSPSEND | SPP send data |
| AT+BTGATTREG | GATT Register |
| AT+BTGATTACT | GATT Active |
| AT+BTGATTCREDB | GATT Create DB |
| AT+BTGATTCRESRV | GATT Create Service |
| AT+BTGATTCRECHAR | Create Service characteristic |
| AT+BTGATTCRECHARDES | Create Service characteristic description |
| AT+BTGATTSRVADD | DB Add To GATT Server |
| AT+BTGATTREADCFM | Response to BTGATTREADIND |
| AT+BTGATTWRCFM | Response to BVTGATTWRIND |
| AT+BTGATTNOTIFY | Send Notification to client |
| AT+BTGATTSENDIND | Send Indication to client |
| +BTSPPRECV | SPP receive data |
| +BTGATTCONN | Client connect status |
| +BTGATTREADIND | Receive client read request |
| +BTGATTWRIND | Receive client write request |

28.2.1 AT+BTPOWER Open/Close BT

| AT+BTPOWER Open/Close BT | |
|-------------------------------------|---|
| Test Command AT+BTPOWER=? | Response +BTPOWER: (0-1) OK |
| Read Command | +BTPOWER: <flag> |

| AT+BTPOWER? | |
|---|---------------------------------|
| Write Command | Response |
| AT+BTPOWER=<flag>[,<debug_switch>] | OK or ERROR |

Defined Values

| | |
|------------------------------|--|
| <flag > | 0: Stop bt csr app 1: Start bt csr app |
| <debug_switch > | Only allowed set to 1, means to save bt log file after csr app is start. |

Example

```

AT+BTPOWER?
+BTPOWER: 1
OK
AT+BTPOWER=0
OK
AT+BTPOWER=1,1
OK

```

NOTE

- When **<flag>** set to 0, **<debug_switch>** can not be set.

28.2.2 AT+BTHOST Get/Set host name

| AT+BTHOST Get/Set host name | |
|------------------------------------|--|
| Read Command | Response |
| AT+BTHOST? | +BTHOST: <host_name>,<host mac addr> OK |
| Write Command | Response |
| AT+BTHOST=<"bname"> | OK or ERROR |

Defined Values

| | |
|------------------------------|--|
| <btname> | new Bluetooth name string. Support Chinese characters. Max length 64 |
| <host mac addr> | Bluetooth mac address format(xx:xx:xx:xx:xx:xx), x(0-9,A-F) The default value is SIM7600_BT_xxxxxx(mac addr 3 lower bytes). |

Example

```

AT+BTHOST?
+BTHOST: SIM7600_BT_AC8DD9, 00:02:5B:AC:8D:D9

OK
AT+BTHOST ="abc"
OK

```

28.2.3 AT+BTSCAN Scan BT devices

| AT+BTSCAN Scan BT devices | |
|--|---|
| Test Command AT+BTSCAN=? | Response +BTSCAN: (0-1),(0-1),(6-60) OK |
| Write Command AT+BTSCAN=<"doscan">[,<mode>][,<timeout>]] | Response OK +BTSCAN: <scan status>, <index1>, <BT name>, <Mac Addr>, <RSSI level> +BTSCAN: <scan status>, <index2>, <BT name>, <Mac Addr>, <RSSI level> [...] +BTSCAN: 1 //scan end flag or ERROR |

Defined Values

| | |
|------------------------|--|
| <doscan> | 0:stop scan 1:scan |
| <mode> | 0:don't hide paired devices 1:hide paired devices |
| <timeout> | Timeout seconds. Default value is 10 |

| | |
|---------------|---|
| <scan status> | 0:scanning 1:scan ended |
| <index> | The index of remote bluetooth device, the value start with 1. |
| <BT name> | The bluetooth name of remote device. |
| <Mac Addr> | The bluetooth mac address of the remote device. |
| <RSSI level> | the rssi level of the device |

Example

```

AT+BTSCAN=1,0,10
OK
+BTSCAN: 0, 1, MKRJ2B-GONGYONG, B8:86:87:43:4B:6A, 186
+BTSCAN: 0, 2, MK-JUMPING, 00:19:86:00:08:60, 184
+BTSCAN: 0, 3, OPPO A57, 4C:18:9A:89:88:7E, 174
+BTSCAN: 0, 4, ww炸, C4:0B:CB:3E:68:62, 173
+BTSCAN: 0, 5, ofo, F7:51:3B:1F:AF:B5, 165
+BTSCAN: 1
AT+BTSCAN=0,0,10
OK

```

28.2.4 AT+BTIOCAP IOCAP Mode Setting

AT+BTIOCAP IOCAP Mode Setting

| | |
|---|---|
| Test Command AT+BTIOCAP=? | Response +BTIOCAP: (0-3) OK |
| Write Command AT+BTIOCAP=<mode> | Response +BTIOCAP: 1 OK or ERROR |

Defined Values

| | |
|--------|--|
| <mode> | 0:Display Only Device 1:Display and Yes and No Capable 2:Keyboard Only 3:No Display or Input Device |
|--------|--|

Example

```
AT+BTIOCAP=3
+BTIOCAP: 1

OK
```

28.2.5 AT+BTPAIR Pair with other BT device

| AT+BTPAIR Pair with other BT device | |
|--|--|
| Test Command AT+BTPAIR=? | Response +BTPAIR: (index) OK |
| Pair Command AT+BTPAIR=0,<scan index> | Response OK +BTPAIRING: <mode>, <device name>,<device mac>,[<passkey>] or ERROR |
| Accept Command AT+BTPAIR=<mode>,<accept>[,<pakey>] | Response OK +BTPAIR: <pair result>[,<device name>,<device mac>] or ERROR |

Defined Values

| | |
|----------------------------|---|
| <mode> | 1:Compare mode need user send accept command 2:Passkey mode need user send accept command and passkey 3:Rebond mode need user send accept command 4:Notify mode just notify user pairing status, user do nothing 5:Just work mode will not receive this mode, user do nothing 6:Pin code mode need user send accept command and pin code |
| <passkey> | Random generate 6 numeric code |
| <scan index> | BTSCAN response index |
| <device name> | The bluetooth name of connected device |
| <device mac> | The bluetooth mac address of the connected device |
| <pair result> | 0:fail |

| | |
|----------|-----------|
| | 1:success |
| <accept> | 0:reject |
| | 1:accept |

Example

```
AT+BTSCAN=1,0,10
+BTSCAN: 0, 1, OPPO R7Plusm, 2C:5B:B8:1A:33:3C, 189
+BTSCAN: 0, 2, MK-JUMPING, 00:19:86:00:08:60, 183
+BTSCAN: 0, 3, MI Band 2, C8:EB:37:B3:56:57, 179
+BTSCAN: 0, 4, BU3-ZHANGWEI, 00:1A:7D:DA:71:11, 178
+BTSCAN: 0, 5, ww, C4:0B:CB:3E:68:62, 174
+BTSCAN:1
```

OK

```
AT+BTPAIR=0,5
```

OK

```
+BTPAIRING: 1, ww, C4:0B:CB:3E:68:62, 623850
```

```
AT+BTPAIR=1,1
```

OK

```
+BTPAIR: 1, ww, C4:0B:CB:3E:68:62
```

NOTE

- The time out of pairing is about 30 seconds
- Whether the pairing is initiative or passive, "AT+BTPAIR" Accept command must be execute after "+BTPAIRING: <mode>, <device name>, <device mac>, [<passkey>]" urc was reported.

28.2.6 AT+BTUNPAIR Unpair with other BT device

AT+BTUNPAIR Unpair with other BT device

| | |
|--|---|
| Test Command AT+BTUNPAIR=? | Response +BTUNPAIR: (index) |
| | OK |
| Write Command AT+BTUNPAIR=<paired index> | Response OK +BTUNPAIR: <status> or ERROR |

Defined Values

| | |
|----------|--------------------------------------|
| <index> | Integer, the response of AT+BTPAIED. |
| <status> | 0:fail 1:success |

Example

```
AT+BTUNPAIR=1
+BTUNPAIR: 1

OK
```

28.2.7 AT+BTPAIED Get paired with BT device

AT+BTPAIED Get paired with BT device

| | |
|------------------------------------|--|
| Read Command AT+BTPAIED? | Response OK +BTPAIED: <paired devices num>,<index>,<BT name>,<MAC addr> |
|------------------------------------|--|

Defined Values

| | |
|----------------------|------------------------------------|
| <paired devices num> | The total number of bonded devices |
| <index> | The index of current bond device |
| <BT name> | refer to AT+BTSCAN |
| <MAC addr> | refer to AT+BTSCAN |

Example

```
AT+BTPAIED?
OK
+BTPAIED: 2, 1, Honor V8, 60:83:34:82:CC:A3
+BTPAIED: 2, 2, ww C4:0B:CB:3E:68:62
```

28.2.8 AT+BTSPSRV Active/Deactive spp server

AT+BTSPPSRV Active/Deactive spp server

| | |
|--|---|
| Test Command AT+BTSPPSRV=? | Response +BTSPPSRV: (0-1) OK |
| Read Command AT+BTSPPSRV? | Response +BTSPPSRV: <status> OK |
| Write Command AT+BTSPPSRV=<flag> | Response OK +BTSPPSRV: <status> or ERROR |

Defined Values

| | |
|-----------------------|------------------------------|
| <flag> | 0:deactive 1:active |
| <status> | 0:deactivated 1:activated |

Example

```

AT+BTSPPSRV?
+BTSERVER: 0
OK
AT+BTSPPSRV=1
OK
+BTSPPSRV: 1
    
```

28.2.9 AT+BTSPPPROF Get remote device spp status

AT+BTSPPPROF Get remote device spp status

| | |
|---|--|
| Read Command AT+BTSPPPROF=<index> | Read Command +BTSPPPROF: <status> OK or ERROR |
|---|--|

Defined Values

| | |
|----------|--|
| <index> | the index of response list of AT+BTPAIED command |
| <status> | 0:device SPP service is not active 1:device SPP service is active |

Example

```

AT+BTPAIED?
OK
+BTPAIED: 2, 1, Honor V8, 60:83:34:82:CC:A3
+BTPAIED: 2, 2, ww C4:0B:CB:3E:68:62
AT+BTSPPPROF=2
OK
+BTSPPPROF:1

```

28.2.10 AT+BTSPPCONN SPP connect/disconnect

AT+BTSPPCONN SPP connect/disconnect

| | |
|---|--|
| Test Command AT+BTSPPCONN=? | Response +BTSPPCONN: (0-1) OK |
| Read Command AT+BTSPPCONN? | Response +BTSPPCONN: <status> OK |
| Write Command AT+BTSPPCONN=<action>[,<paired index>] | Response OK +BTSPPCONN: <status>[,<max frame size>][,<device mac>] or ERROR |

Defined Values

| | |
|----------------|--|
| <action> | 0:disconnect 1:connect |
| <paired index> | The response of AT+BTPAIED. The max value is 64. |
| <status> | 0:disconnected 1:connected |

Example

```

AT+BTSPPCONN?
+BTSPPCONN: 0
OK
AT+BTSPPCONN=1,1
OK
+BTSPPCONN: 1, 990, C4:07:2F:C5:D1:8A
  
```

NOTE

- The device may receive **+BTSPPCONN:<status>[,<max frame size>] [,<device mac>]** when other device connected successfully.

28.2.11 AT+BTSPSEND SPP send data

AT+BTSPSEND SPP send data

| Write Command | Response |
|---------------------------------|---|
| AT+BTSPSEND=<data> | OK +BTSPSEND: <result> |
| | or ERROR |

Defined Values

| | |
|-----------------------|---|
| <data> | Format : ucs2 "ucs2": 16-bit universal multiple-octet coded character set; UCS2 character strings are converted to hexadecimal number from 0000 to FFFF. For examples : If we want to send a string "123abc" The data is : 003100320033006100620063 |
| <result> | 0:send fail 1:send success |

Example

```

AT+BTSPSEND=003100320033006100620063
OK
AT+BTSPSEND: 1
  
```

28.2.12 AT+BTGATTREG GATT Register

AT+BTGATTREG GATT Register

| | |
|---|--|
| Write Command AT+BTGATTREG=<status> | Response +BTGATTREG: <status> OK or ERROR |
|---|--|

Defined Values

| | |
|-----------------------|------------------------------|
| <status> | 1: register 0: unregister |
|-----------------------|------------------------------|

Example

```
AT+BTGATTREG=1
+BTGATTREG: 1

OK
```

28.2.13 AT+BTGATTACT GATT Active

AT+BTGATTACT GATT Active

| | |
|--|--|
| Execution Command AT+BTGATTACT | Response +BTGATTACT: <status> OK or ERROR |
| Write Command AT+BTGATTACT=<auto_broadcast>[,<perferredMTU>] | Response OK or ERROR |

Defined Values

| | |
|------------------|--|
| <status> | 1:active 0:not avtive |
| <auto_broadcast> | 0 - disable auto activate GATT after a connection was closed 1 - enable auto activate GATT after a connection was closed |
| <perferedMTU> | A integer value from 24 to 512, means to the maximum size of any packet sent between a client and a server. If not set, default packet size is 23bytes. The details refer to Note. |

Example

```
AT+BTGATTACT
+BTGATTACT: 1

OK
```

28.2.14 AT+BTGATTCREDB GATT Create DB

AT+BTGATTCREDB GATT Create DB

| Execution Command | Response |
|-------------------|------------------------|
| AT+BTGATTCREDB | +BTGATTCREDB: <status> |
| | OK or ERROR |

Defined Values

| | |
|----------|--------------------|
| <status> | 1:sucess 0:fail |
|----------|--------------------|

Example

```
AT+BTGATTCREDB
+BTGATTCREDB: 1

OK
```

28.2.15 AT+BTGATTCRESRV GATT Create Service

| AT+BTGATTCRESRV GATT Create Service | |
|---|---|
| Write Command AT+BTGATTCRESRV=<uuid> > | Response +BTGATTCRESRV: <status> OK or ERROR |

Defined Values

| | |
|----------|--|
| <uuid> | Service id,4 Hex character or 32 Hex character |
| <status> | 1:sucess 0:fail |

Example

```
AT+BTGATTCRESRV=34A3
+BTGATTCRESRV: 1

OK
```

28.2.16 AT+BTGATTRECHAR Create Service characteristic

| AT+BTGATTRECHAR Create Service characteristic | |
|--|---|
| Write Command AT+BTGATTRECHAR=<uu id>,<property>,<permission> > | Response +BTGATTRECHAR: <status>,<0Xuuid>,<handle> OK or ERROR |

Defined Values

| | |
|--------------|---|
| <uuid> | UUID of this characteristic. A string with hex value. The length of it only can be set 4 or 32. |
| <property> | Properties of this characteristic. |
| <permission> | Permission of this characteristic. |

| | |
|----------|----------------------------|
| <status> | 1:sucess 0:fail |
| <handle> | Int, Characteristic handle |

Example

```
AT+BTGATTCRECHAR=34567,2,16
+BTGATTCRECHAR: 1,0X4567,13
```

OK

28.2.17 AT+BTGATTCRECHARDES Create Service characteristic description

AT+BTGATTCRECHARDES Create Service characteristic description

| | |
|--|---|
| Excution Command AT+BTGATTCRECHARDES | Response +BTGATTCRECHARDES: <status> OK or ERROR |
|--|---|

Defined Values

| | |
|----------|--------------------|
| <status> | 1:sucess 0:fail |
|----------|--------------------|

Example

```
AT+BTGATTCRECHARDES
+BTGATTCRECHARDES: 1
```

OK

28.2.18 AT+BTGATTSRVADD DB Add To GATT Server

AT+BTGATTSRVADD DB Add To GATT Server

| | |
|--|--|
| Excution Command AT+BTGATTSRVADD | Response +BTGATTSRVADD: <status> |
|--|--|

OK
or
ERROR

Defined Values

| | |
|----------|--------------------|
| <status> | 1:sucess 0:fail |
|----------|--------------------|

Example

```
AT+BTGATTSRVADD
+BTGATTSRVADD: 1
```

OK

28.2.19 AT+BTGATTREADCFM Response to BTGATTREADIND

AT+BTGATTREADCFM Response to BTGATTREADIND

| | |
|--|---|
| Write Command AT+BTGATTREADCFM=<respCode>,<data> | Response +BTGATTREADCFM: 1 OK or ERROR |
|--|---|

Defined Values

| | |
|------------|--|
| <respCode> | Response result for client request. The range is 0-255. 0: sucess Others: not support, invalid parameter |
| <data> | character, Response data to BTGATTREADIND,if data length less than maxlen(BTGATTREADIND return), data will be send immediately to client , if data length equal to maxlen , the module will receive BTGATTREADIND again till data length less than maxlen. |

Example

```
+BTGATTREADIND: 13,22
```

```
AT+BTGATTREADCFM=0,123456
```



```
+BTGATTREADCFM:1
```

```
OK
```

28.2.20 AT+BTGATTWRCFM Response to BTGATTWRIND

AT+BTGATTWRCFM Response to BTGATTWRIND

| Write Command | Response |
|--------------------------------------|-------------------------------------|
| AT+BTGATTWRCFM=<result> | +BTGATTWRCFM: <status> |
| <t> | OK |
| | or |
| | ERROR |

Defined Values

| | |
|-----------------------|------------|
| <result> | 0: success |
| <status> | 1: success |

Example

```
+BTGATTWRIND: 15,DB12C8
```

```
AT+BTGATTWRCFM=0
```

```
+BTGATTWRCFM: 1
```

```
OK
```

28.2.21 AT+BTGATTNOTIFY Send Notification to client

AT+BTGATTNOTIFY Send Notification to client

| Write Command | Response |
|--|--------------------------------------|
| AT+BTGATTNOTIFY=<handle>,<data> | +BTGATTNOTIFY: <status> |
| | OK |
| | or |
| | ERROR |

Defined Values

| | |
|----------|--|
| <handle> | Int, Characteristic handle, (2.17 response returns, and the characteristic's property is indication) |
| <data> | character, Data to be send, (max length is 20) |
| <status> | 1:sucess 0:fail |

Example

```
AT+BTGATTNOTIFY=17,34567
+BTGATTNOTIFY:1
```

```
OK
```

28.2.22 AT+BTGATTSENDIND Send Indication to client

AT+BTGATTSENDIND Send Indication to client

| | |
|--|--|
| Write Command AT+BTGATTSENDIND=<handle>,<data> | Response +BTGATTSENDIND: <status> OK or ERROR |
|--|--|

Defined Values

| | |
|----------|--|
| <handle> | Int, Characteristic handle, (2.17 response returns, and the characteristic's property is indication) |
| <data> | character, Data to be send, (max length is 20) |
| <status> | 1:sucess 0:fail |

Example

```
AT+BTGATTSENDIND=19,34567
+BTGATTSENDIND: 1
```

```
OK
```

28.2.23 +BTSPPRECV SPP receive data

+BTSPPRECV SPP receive data

Response

+BTSPPRECV: <data len>,<data>

Defined Values

| | |
|------------|---|
| <data len> | Integer type, 0 - 100 |
| <data> | Format : ucs2 For examples : If we have received a string 003100320033006100620063 Means receive a string "123abc" |

Example

```
+BTSPPRECV=12, 003100320033006100620063
+BTGATSENDIND: 1
```

28.2.24 +BTGATTCONN Client connect status

+BTGATTCONN Client connect status

Response

+BTGATTCONN: <status>,<device mac>

Defined Values

| | |
|----------|-------------------------------|
| <status> | 1:connected 0:disconnected |
|----------|-------------------------------|

Example

```
+BTGATTCONN: 1, 68:68:79:6D:75:26
```

28.2.25 +BTGATTREADIND Receive client read request

+BTGATTREADIND Receive client read request

Response

+BTGATTREADIND: <handle>,<maxlen>

Defined Values

| | |
|-----------------------|---|
| <handle> | Int, Characteristic handle |
| <maxlen> | The maximum length that the value of the attribute must have. |

Example

+BTGATTREADIND: 13,22

28.2.26 +BTGATTWRIND Receive client write request

+BTGATTWRIND Receive client write request

Response

+BTGATTWRIND: <handle>,<data>

Defined Values

| | |
|-----------------------|-----------------------------------|
| <handle> | Int, Characteristic handle |
| <data> | Data to be writed (Hex charcters) |

Example

+BTGATTWRIND: 15,DB12C8